

Geometric Algebra Power Theory in Time Domain

Francisco G. Montoya
Escuela Superior de Ingenieria
University of Almeria
pagilm@ual.es

Javier Roldán
IMDEA Energy Institute
javier.rolan@imdea.org

Alfredo Alcayde
Escuela Superior de Ingenieria
University of Almeria
aalcayde@ual.es

Francisco M. Arrabal-Campos
Escuela Superior de Ingenieria
University of Almeria
fmarrabal@ual.es

Raúl Baños
Escuela Superior de Ingenieria
University of Almeria
rbanos@ual.es

February 14, 2020

Abstract

In this short communication, the power flow in electrical systems is modelled in the time domain by using Geometric Algebra and the Hilbert Transform. The use of this mathematical framework unifies different approaches already raised so far to explain instantaneous power flows. Also, it overcomes some of the limitations shown by the existing methodologies under distorted supply. The proposed method can be applied for sinusoidal and non-sinusoidal regimes, non-linear loads, in single- and multi-phase systems, and it provides meaningful results with a compact formulation.

Index terms— Time-domain power theories, geometric algebra, Hilbert transform.

1 Introduction

Pioneer power theories for analysing electrical systems were developed by Steinmetz, Kennelly and Heaviside, among others, by the end of the XIX century [1, 2, 3]. Nowadays, these theories are still a source of discussion and debate concerning their correctness and physical interpretation [4]. Some of them were formulated in the frequency domain, such as those proposed by Budeanu [5] and Czarnecki [6], while other ones were formulated in the time domain, like those presented by Fryze [7], Akagi [8] and Depenbrock [9]. More recently, Lev-Ari [10] and Salmerón [11] have made relevant contributions to the field by using the Hilbert transform and tensor algebra, respectively. All these theories are devoted to explain the power-transfer process between complex electrical systems and they establish mathematical concepts associated to fictitious powers (e.g. reactive power), which are of a great value from the engineering point of view. Unfortunately, none of the existing proposals can be used to separate current components in the time domain under any type of voltage distortion, asymmetry, non-linearity of the load or combinations thereof. Some of these limitations have been reported in the literature [4, 12]. In this work, a new proposal is presented to overcome these limitations by applying two powerful math tools: Geometric Algebra (GA) and the Hilbert Transform (HT). GA is the key tool to be used in this paper. Due to its versatility, GA has been identified as a unified language for physics and mathematics [13]. The application of GA would make it possible to separate current components that have a relevant engineering meaning for systems with any number of phases (including single-phase systems) [14, 15]. Current decomposition is addressed from both instantaneous and averaged points of view, for systems with and without stored energy. Moreover, thanks to the use of the HT, the

proposed theory can be applied to single-phase systems seamlessly, which is a relevant advantage compared to the existing theories. Mathematical demonstrations are omitted in this paper for the sake of conciseness.

2 Geometric Algebra and Power Theory

2.1 Hilbert Transform and Geometric Algebra Fundamentals

Consider a multi-phase system where $u(t)$ is the voltage and $i(t)$ is the current. Both signals are vectors of multiple dimensions associated to a Hilbert space. Current and voltages are periodic and T is the period value. The HT of $u(t)$ is

$$\mathcal{H}[u(t)] = \frac{1}{\pi} PV \int_{-\infty}^{+\infty} \frac{u(\tau)}{t - \tau} d\tau \quad (1)$$

where PV is the Cauchy principal value. The HT is a crucial tool that will be applied later in the paper to calculate quadrature signals and to define the impedance in the time domain [10].

Consider now an orthonormal base $\sigma = \{\sigma_1, \sigma_2, \dots, \sigma_n\}$ defined for a vector space in \mathcal{R}^n . Then, it is possible to establish a new geometric vector space \mathcal{G}^n . Under these assumptions, a vector can be represented as:

$$\mathbf{a} = \sum_n a_n \sigma_n = a_1 \sigma_1 + \dots + a_n \sigma_n \quad (2)$$

In this new space, the geometric product between two vectors (\mathbf{a} and \mathbf{b}) can be defined as:

$$\mathbf{M} = \mathbf{a}\mathbf{b} = \mathbf{a} \cdot \mathbf{b} + \mathbf{a} \wedge \mathbf{b} \quad (3)$$

which can be seen as the sum of the traditional scalar or inner product plus the so-called wedge or Grassmann product [13]. The latter fulfils the following property:

$$\mathbf{a} \wedge \mathbf{b} = -\mathbf{b} \wedge \mathbf{a} \quad (4)$$

This new geometrical entity is commonly known as *bivector* and it cannot be found in traditional linear algebra [13].

2.2 Geometric Power in Time Domain

For a n -phase electrical system, a vector containing the instantaneous voltages can be defined as follows:

$$\vec{u}(t) = [u_1(t), u_2(t), \dots, u_n(t)] \quad (5)$$

where each voltage is referred to a virtual star point that might not be the same as the neutral conductor. Also, a vector that includes the line currents is defined:

$$\vec{i}(t) = [i_1(t), i_2(t), \dots, i_n(t)] \quad (6)$$

In order to simplify the notation, $u_k(t) = u_k$ and $i_k(t) = i_k$. The expression for the instantaneous power consumed by the circuit is widely known, and it can be calculated as:

$$p(t) = u_1 i_1 + u_2 i_2 + \dots + u_n i_n \quad (7)$$

which is the inner product between $\vec{u}(t)$ and $\vec{i}(t)$.

By using the HT, $\vec{u}(t)$ and $\vec{i}(t)$ can be represented in the geometric domain as the geometric vectors \mathbf{u} and \mathbf{i} , respectively:

$$\begin{aligned} \mathbf{u} &= u_1 \sigma_1 - \mathcal{H}[u_1] \sigma_2 + \dots + u_n \sigma_{2n-1} - \mathcal{H}[u_n] \sigma_{2n} \\ \mathbf{i} &= i_1 \sigma_1 - \mathcal{H}[i_1] \sigma_2 + \dots + i_n \sigma_{2n-1} - \mathcal{H}[i_n] \sigma_{2n} \end{aligned} \quad (8)$$

The negative signs have been included so that an inductive element leads to a positive value of reactive power consumption, while a capacitive element leads to a negative one. The use of the HT in (8) becomes essential to overcome the shortcomings of existing power theories and it is one of the main contribution of

this work. Note that HT is only required for time average single-phase calculations and it can be omitted in the case of systems with more than one phase.

The norm of the geometric voltage and current vectors is:

$$\begin{aligned}\|\mathbf{u}\| &= \sqrt{\mathbf{u}\mathbf{u}} = \sqrt{\mathbf{u} \cdot \mathbf{u}} = \sqrt{\sum_{k=1}^n u_k^2 + \mathcal{H}^2[u_k]} \\ \|\mathbf{i}\| &= \sqrt{\mathbf{i}\mathbf{i}} = \sqrt{\mathbf{i} \cdot \mathbf{i}} = \sqrt{\sum_{k=1}^n i_k^2 + \mathcal{H}^2[i_k]}\end{aligned}\quad (9)$$

The instantaneous geometric power is defined as the product of voltage and current vectors, thus

$$\mathbf{M} = \mathbf{u}\mathbf{i} = \mathbf{u} \cdot \mathbf{i} + \mathbf{u} \wedge \mathbf{i} \quad (10)$$

The inspection of (10) reveals the potential of GA applied to electrical circuits. This expression encompasses the existing knowledge developed by different authors and by using different techniques (complex numbers, matrices, vector calculus, quaternions, tensors, etc.), but in a very compact way.

It is relevant to highlight that (10) consists of two terms that have a different nature, i.e., a scalar and a bivector term. This mathematical entity is a multivector and it can be written as

$$\mathbf{M} = M_p + \mathbf{M}_q \quad (11)$$

where

$$\begin{aligned}M_p &= \mathbf{u} \cdot \mathbf{i} = \sum_{k=1}^n u_k i_k + \mathcal{H}[u_k] \mathcal{H}[i_k] = u_1 i_1 + \mathcal{H}[u_1] \mathcal{H}[i_1] + \dots + u_n i_n + \mathcal{H}[u_n] \mathcal{H}[i_n] \\ \mathbf{M}_q &= \mathbf{u} \wedge \mathbf{i} = \begin{vmatrix} \sigma_1 & \sigma_2 & \dots & \sigma_{2n-1} & \sigma_{2n} \\ u_1 & -\mathcal{H}[u_1] & \dots & u_n & -\mathcal{H}[u_n] \\ i_1 & -\mathcal{H}[i_1] & \dots & i_n & -\mathcal{H}[i_n] \end{vmatrix}\end{aligned}\quad (12)$$

M_p is the scalar part and includes the instantaneous active power $p(t)$. It will be referred to as the *parallel geometric power*. \mathbf{M}_q is the bivector part and will be named quadrature geometric power. It comprises the well-known *instantaneous reactive power* in the *IRP* theory and its further refinements [16, 17, 18, 11]. In (12), the determinant can be calculated by using Leibniz or Laplace formula.

The instantaneous geometric power \mathbf{M} can also be written in terms of a commutative and anti-commutative part:

$$M_p = \frac{1}{2} (\mathbf{u}\mathbf{i} + \mathbf{i}\mathbf{u}) = \frac{1}{2} (\mathbf{M} + \mathbf{M}^\dagger) \quad (13)$$

$$\mathbf{M}_q = \frac{1}{2} (\mathbf{u}\mathbf{i} - \mathbf{i}\mathbf{u}) = \frac{1}{2} (\mathbf{M} - \mathbf{M}^\dagger) \quad (14)$$

where \mathbf{M}^\dagger is the reverse of the instantaneous geometric power. It is worth noting that no matrices nor tensors are used in the definitions of powers presented in (10)–(14). This leads to a very compact formulation and simplifies mathematical expressions.

2.3 Current Decomposition

If $i(t)$ is the instantaneous current demanded by a load, it can be separated into meaningful engineering components by operating (10). Indeed, left multiplying by the inverse of the voltage vector leads to:

$$\mathbf{u}^{-1} \mathbf{M} = \mathbf{u}^{-1} \mathbf{u}\mathbf{i} = \mathbf{i} \quad (15)$$

since $\mathbf{u}^{-1}\mathbf{u} = 1$.

The inverse of a vector in the geometric domain is:

$$\mathbf{u}^{-1} = \frac{\mathbf{u}}{\|\mathbf{u}\|^2} \quad (16)$$

which can be used in (15) to find the current decomposition. By replacing (11) in (15):

$$\mathbf{i} = \mathbf{u}^{-1}\mathbf{M} = \frac{\mathbf{u}}{\|\mathbf{u}\|^2}\mathbf{M} = \frac{\mathbf{u}}{\|\mathbf{u}\|^2}(M_p + M_q) = \frac{\mathbf{u}}{\|\mathbf{u}\|^2}M_p + \frac{\mathbf{u}}{\|\mathbf{u}\|^2}M_q = \mathbf{i}_p + \mathbf{i}_q \quad (17)$$

The term \mathbf{i}_p is commonly known as *instantaneous geometric parallel current*, while the term \mathbf{i}_q is the *instantaneous geometric quadrature current* and is orthogonal to \mathbf{i}_p . It should be noted that \mathbf{i}_q is not a *reactive current* since it is not related to any physical phenomenon such as energy oscillations in reactive elements like inductors or capacitors [19]. In fact, it includes the effects generated by asymmetries of voltage sources and load unbalance.

The Fryze current can also be defined by using GA:

$$\mathbf{i}_F = \frac{\bar{M}_p}{\|\bar{\mathbf{u}}\|^2}\mathbf{u} \quad (18)$$

where \bar{M}_p is the mean value of the geometric parallel power and $\|\bar{\mathbf{u}}\|$ is the RMS value of the geometric voltage. It can be readily demonstrated that $\bar{M}_p = 2P$, where P is the active power. Moreover, the reactive current defined by Budeanu and supported by Willems [20], Lev-Ari [10] and Jeltsema [21] (among others) is:

$$\mathbf{i}_B = \frac{\bar{M}_q}{\|\bar{\mathbf{u}}\|^2}\mathcal{H}[\mathbf{u}] \quad (19)$$

where \bar{M}_q is the mean value of the quadrature geometric power. Similarly, $\bar{M}_q = 2Q$, where Q is the reactive power defined by Budeanu. Therefore, the current expression can be fully decomposed as follows:

$$\mathbf{i} = \mathbf{i}_p + \mathbf{i}_q = \mathbf{i}_F + \mathbf{i}_f + \mathbf{i}_B + \mathbf{i}_b \quad (20)$$

where \mathbf{i}_f is the Fryze complementary current required to conform the parallel current. Similarly, \mathbf{i}_b is the Budeanu complementary current required to conform the quadrature current. The asymmetry or unbalance current is included in \mathbf{i}_f and \mathbf{i}_b .

The use of GA allows a natural decomposition of currents without requiring additional tools such as Clarke or Park transformations. The proposed methodology can be seamlessly applied to any distorted system since no constraints have been imposed to the waveforms of voltages and currents in this regard. This theory can be applied to any circuit with an arbitrary number of phases, including single-phase systems. This is not possible so far with other theories such as the *IRP* and it is a relevant feature of this proposal.

The transformation of a given current in a n -phase system from the geometric to the time domain can be written as:

$$i(t) = \sum_{k=1}^n [\mathbf{i}]_{2k-1} \quad (21)$$

where $[\cdot]_k$ refers to the k -th component of the geometric vector of the current \mathbf{i} .

2.4 Properties of \mathbf{M} and \mathbf{i}

The instantaneous geometric power \mathbf{M} and the instantaneous geometric current \mathbf{i} fulfil a number of mathematical properties that reinforce the geometric interpretation of the proposed theory. These are explained below.

2.4.1 Orthogonality of the components of M

The parallel geometric power M_p is a scalar number, while the quadrature geometric power M_q is a bivector. Therefore, their internal product is zero and this implies orthogonality:

$$M_p \cdot M_q = 0 \quad (22)$$

In addition, the norm of the instantaneous geometric power is:

$$\|M\| = \sqrt{\langle MM^\dagger \rangle_0} = \|\mathbf{u}\| \|\mathbf{i}\| \quad (23)$$

which can further be developed, yielding:

$$\|M\|^2 = \left\langle (M_p + M_q) (M_p + M_q)^\dagger \right\rangle_0 = \|M_p\|^2 + \|M_q\|^2$$

2.4.2 Orthogonality of the components of i

As shown in (17), the instantaneous geometric current i can be decomposed into two vectors, i_p and i_q . Based on (22), these vectors are orthogonal:

$$i_p \cdot i_q = \frac{\mathbf{u}}{\|\mathbf{u}\|^2} M_p \cdot \frac{\mathbf{u}}{\|\mathbf{u}\|^2} M_q = \frac{1}{\|\mathbf{u}\|^2} M_p \cdot M_q = 0 \quad (24)$$

Also, it can be demonstrated that all the terms in (20) are also orthogonal to each other.

3 Instantaneous Geometric Impedance

The instantaneous relationship between the voltage and current for each phase is defined for the first time in this paper as *instantaneous geometric impedance*. For each phase, the current and voltage can be represented in polar form as:

$$\begin{aligned} [\mathbf{u}]_k &= u_k \sigma_{2k-1} - \mathcal{H} [u_k] \sigma_{2k} = U e^{\varphi_k^v \sigma_{(2k-1)(2k)}} \sigma_{2k-1} \\ [i]_k &= i_k \sigma_{2k-1} - \mathcal{H} [i_k] \sigma_{2k} = I e^{\varphi_k^i \sigma_{(2k-1)(2k)}} \sigma_{2k-1} \end{aligned} \quad (25)$$

and therefore:

$$\begin{aligned} \mathbf{Z}_k &= [\mathbf{u}]_k [i]_k^{-1} = U e^{\varphi_k^v \sigma_{(2k-1)(2k)}} \sigma_{2k-1} I^{-1} e^{\varphi_k^i \sigma_{(2k-1)(2k)}} \sigma_{2k-1} \\ &= \frac{U}{I} e^{(\varphi_k^v - \varphi_k^i) \sigma_{(2k-1)(2k)}} = Z_k \angle \varphi_k = R_k + X_k \sigma_{(2k-1)(2k)} \end{aligned} \quad (26)$$

4 Conclusion

In this work, the power flow in electrical circuits has been redefined by using GA and HT. It has been shown that the use of these tools greatly simplify mathematical expressions, leading to a very compact formulation. The proposed formulation can be applied to single- and multi-phase systems, and it provides a robust engineering interpretation that is in good agreement with other power theories. Current decomposition can be easily carried out and the results match with those previously obtained in the literature. Further research will be focus on the application of this new theory to calculate power flows in distorted electrical networks with non-linear loads.

References

- [1] C. P. Steinmetz, Complex quantities and their use in electrical engineering, in: Proceedings of the International Electrical Congress, 1893, pp. 33–74.

- [2] A. Kennelly, Impedance, Transactions of the American Institute of Electrical Engineers 10 (1893) 172–232.
- [3] O. Heaviside, Electrical Papers, Vol. 2, Macmillan and Company, 1892.
- [4] L. S. Czarnecki, Instantaneous reactive power pq theory and power properties of three-phase systems, IEEE Transactions on Power Delivery 21 (1) (2005) 362–367.
- [5] C. Budeanu, Puissances reactives et fictives, no. 2, Impr. Cultura nationala, 1927.
- [6] L. S. Czarnecki, Currents’ physical components (cpc) concept: A fundamental of power theory, in: Nonsinusoidal Currents and Compensation, 2008. ISNCC 2008. International School on, IEEE, 2008, pp. 1–11.
- [7] S. Fryze, Wirk-, blind- und scheinleistung in elektrischen stromkreisen mit nichtsinusförmigem verlauf von strom und spannung, Elektrotechnische Zeitschrift 25 (569-599) (1932) 33.
- [8] H. Akagi, Y. Kanazawa, A. Nabae, Instantaneous reactive power compensators comprising switching devices without energy storage components, IEEE Transactions on industry applications (3) (1984) 625–630.
- [9] M. Depenbrock, The fbd-method, a generally applicable tool for analyzing power relations, IEEE Transactions on Power Systems 8 (2) (1993) 381–387.
- [10] H. Lev-Ari, A. M. Stankovic, A decomposition of apparent power in polyphase unbalanced networks in nonsinusoidal operation, IEEE Transactions on Power Systems 21 (1) (2006) 438–440.
- [11] P. Salmerón, R. Herrera, Instantaneous reactive power theory—a general approach to poly-phase systems, Electric Power Systems Research 79 (9) (2009) 1263–1270.
- [12] P. Haley, Limitations of cross vector generalized pq theory, in: 2015 International School on Nonsinusoidal Currents and Compensation (ISNCC), IEEE, 2015, pp. 1–5.
- [13] D. Hestenes, G. Sobczyk, Clifford algebra to geometric calculus: a unified language for mathematics and physics, Vol. 5, Springer Science & Business Media, 2012.
- [14] F. G. Montoya, R. Baños, A. Alcayde, F. M. Arrabal-Campos, E. Viciano, Analysis of non-active power in non-sinusoidal circuits using geometric algebra, International Journal of Electrical Power & Energy Systems 116 (2020) 105541.
- [15] H. Lev-Ari, A. M. Stankovic, Instantaneous power quantities in polyphase systems—a geometric algebra approach, in: 2009 IEEE Energy Conversion Congress and Exposition, 2009, pp. 592–596.
- [16] H. Akagi, E. H. Watanabe, M. Aredes, Instantaneous Power Theory and Applications to Power Conditioning, Wiley, 2007.
- [17] J. L. Willems, A new interpretation of the akagi-nabae power components for nonsinusoidal three-phase situations, IEEE Transactions on Instrumentation and Measurement 41 (4) (1992) 523–527.
- [18] X. Dai, G. Liu, R. Gretschek, Generalized theory of instantaneous reactive quantity for multiphase power system, IEEE Transactions on Power Delivery 19 (3) (2004) 965–972.
- [19] F. De Leon, J. Cohen, Ac power theory from poynting theorem: Accurate identification of instantaneous power components in nonlinear-switched circuits, IEEE Trans. on Pow. Del. 25 (4) (2010) 2104–2112.
- [20] J. L. Willems, Budeanu’s reactive power and related concepts revisited, IEEE Transactions on Instrumentation and Measurement 60 (4) (2010) 1182–1186.
- [21] D. Jeltsema, Budeanu’s concept of reactive and distortion power revisited, in: 2015 IEEE International School on Nonsinusoidal Currents and Compensation (ISNCC), 2015, pp. 1–6.