# General Method for Conversion Between Multimode Network Parameters

Alexander Zhuravlev and Juan D. Baena, Member, IEEE

Abstract-Different types of network parameters have been used in electronics since long ago. The most typical network parameters, but not the only ones, are S, T, ABCD, Z, Y, and h that relate input and output signals in different ways. There exist practical formulas for conversion between them. Due to the development of powerful software tools that can deal efficiently and accurately with higher-order modes in each port, researchers need conversion rules between multimode network parameters. However, the usual way to get each conversion rule is just developing cumbersome algebraic manipulations which, at the end, are useful only for some specific conversion. Here, we propose a general algebraic method to obtain any conversion rule between different multimode network parameters. It is based on the assumption of a state vector space and each conversion rule between network parameters can be interpreted as a simple change of basis. This procedure explains any conversion between multimode network parameters under the same algebraic steps.

Index Terms-Network parameters, multimode network, multiport network, microwave network, antenna.

### I. INTRODUCTION

Microwave devices play a crucial role in modern telecommunication systems, because they provide necessary manipulations with fields to receive and process a signal: filtering, beamforming, polarization control, amplifying, and signal mixing, among others. To model and measure the performance of a microwave device, engineers and researchers usually use network parameters that connect fields (electric and magnetic fields) or certain integrals of them (effective voltage and current) at the terminals of the device. Among the most used network parameters used in practice, there are the scattering S, transfer T, chain ABCD, impedance Z, and admittance Y parameters [1], [2]. For microwave networks, the scattering parameters S are commonly used and measurable using any commercial vector network analyzer. In antenna engineering, the impedance Z and admittance Y network parameters might be preferred to control the input impedance of an antenna. In addition, they can be calculated using the induced electromotive force method presented in [3]. For an arrangement of several connected networks, the ABCD matrix or the T matrix can be very useful because the parameters of all parts can be multiplied in the cascade to obtain the matrix of the overall structure. Then the resulting T or ABCD matrices can be converted to any other type of network parameters. Although the parameters T and ABCD are usually difficult to measure, they can be derived from measured S parameters. By the way, T and ABCD network parameters are usually used to calibrate and remove the effects of cables and connectors that connect the device under test to the vector network analyzer.

We can conclude that conversion rules between different network parameters play an important role in engineering and research prac-

Copyright was transferred to IEEE.

This paper was produced by the IEEE Publication Technology Group. They are in Piscataway, NJ.

This work was supported by the Russian Science Foundation (Project No. 24-45-02020).

A. Zhuravlev is with the School of Physics and Engineering, ITMO University, St. Petersburg, Russia (e-mail: a.zhuravlev@metalab.ifmo.ru).

J. D. Baena is with the Department of Physics, Universidad Nacional de Colombia, Bogota 111321, Colombia (e-mail: jdbaenad@unal.edu.co).

tice. Usually, tables of practical conversion rules are presented in microwave engineering textbooks [2] or research papers [4]. However, they consider monomode 2-port network parameters and thus ignore the effect of higher-order modes. For example, it may be important for densely packed structures such as those studied in [5]–[15]. It is worth noting that a multimode network can also be treated as a multiport network and vice versa because each mode can be associated with some transmission line with its own characteristic impedance. Some conversion rules were presented in [16] for  $S \leftrightarrow T$  and [17] for  $S \leftrightarrow ABCD$ . Finally, the work [18] extends all the conversion rules of [4] to the multiport case. However, this paper contains the final formulas but no general algorithm that could facilitate conversion between others. Our work suggests a simple algorithm to convert multimode network parameters that can be easily extended to any possible conversion between multimode network parameters.

### II. DEFINITIONS OF MULTIMODE NETWORK PARAMETERS

Consider a network connected to multiple modes from each side as sketched in Fig. 1(a). The voltage amplitudes of the incoming / outgoing signals are shown in Fig. 1(b). It is convenient to arrange them together in the following vectors:  $\mathbf{V}_s^{\pm} = \begin{bmatrix} V_{s1}^{\pm} \dots V_{sm}^{\pm} \dots V_{sM}^{\pm} \end{bmatrix}^{\mathrm{T}}$ , where s = 1, 2 indicates one side of the network, the superscript +(-) refers to incoming (outgoing) signals, m is the mode, and M the total number of modes. Alternatively, the system can also be described using the net voltages and currents at the edge of the network for each mode, as shown in Fig. 1(c), where

$$\mathbf{V}_s = \mathbf{V}_s^+ + \mathbf{V}_s^-$$
  
$$\mathbf{I}_s = \mathbf{Y}_s \cdot (\mathbf{V}_s^+ - \mathbf{V}_s^-)$$
 (1)

Here  $\mathbf{Y}_s = \text{Diag}[Y_{0s1}, \dots, Y_{0sm}, \dots, Y_{0sM}]$  is a diagonal matrix containing the mode admittances of all modes from the side s. In other words,  $V_{sm} = V_{sm}^+ + V_{sm}^-$  and  $I_{sm} = Y_{0sm}(V_{sm}^+ - V_{sm}^-)$  for each mode. By combining the two equations in (1), it can also be written as

$$\mathbf{V}_{s}^{\pm} = \frac{1}{2} (\mathbf{V}_{s} \pm \mathbf{Z}_{s} \cdot \mathbf{I}_{s})$$
(2)

where  $\mathbf{Z}_s = \mathbf{Y}_s^{-1}$  is just a diagonal matrix formed with the mode impedances. Now, using the voltages and currents defined in Fig. 1, several multimode network parameters can be defined as follows:

• scattering matrix S

$$\begin{bmatrix} \mathbf{V}_1^- \\ \mathbf{V}_2^- \end{bmatrix} = \underbrace{\begin{bmatrix} \mathbf{S}_{11} & \mathbf{S}_{12} \\ \mathbf{S}_{21} & \mathbf{S}_{22} \end{bmatrix}}_{\mathbf{S}} \cdot \begin{bmatrix} \mathbf{V}_1^+ \\ \mathbf{V}_2^+ \end{bmatrix}$$
(3)

• transfer matrix T

$$\begin{bmatrix} \mathbf{V}_1^+ \\ \mathbf{V}_1^- \end{bmatrix} = \underbrace{\begin{bmatrix} \mathbf{T}_{11} & \mathbf{T}_{12} \\ \mathbf{T}_{21} & \mathbf{T}_{22} \end{bmatrix}}_{\mathbf{T}} \cdot \begin{bmatrix} \mathbf{V}_2^- \\ \mathbf{V}_2^+ \end{bmatrix}$$
(4)

• chain matrix ABCD

$$\begin{bmatrix} \mathbf{V}_1 \\ \mathbf{I}_1 \end{bmatrix} = \underbrace{\begin{bmatrix} \mathbf{A} & \mathbf{B} \\ \mathbf{C} & \mathbf{D} \end{bmatrix}}_{\mathbf{ABCD}} \cdot \begin{bmatrix} \mathbf{V}_2 \\ -\mathbf{I}_2 \end{bmatrix}$$
(5)



Fig. 1. Diagram of a multimode network. In (a) a general view shows M modes attached on each side, while (b) and (c) only show the portion containing the m-th modes for a better visualization of voltages and currents used in definitions of network parameters.

TABLE I COORDINATE SYSTEMS OF THE STATE SPACE SUITABLE FOR EACH TYPE OF NETWORK PARAMETERS

S-coord.	T-coord.	ABCD- -coord.	Z-coord.	Y-coord.	h-coord.		
$\begin{bmatrix} \mathbf{V}_1 \\ \mathbf{V}_2 \end{bmatrix}$	$\begin{bmatrix} \mathbf{V}_1^+ \\ \mathbf{V}_1^- \end{bmatrix}$	$\begin{bmatrix} \mathbf{V}_1 \\ \mathbf{I}_1 \end{bmatrix}$	$\begin{bmatrix} \mathbf{V}_1 \\ \mathbf{V}_2 \end{bmatrix}$	$\begin{bmatrix} \mathbf{I}_1 \\ \mathbf{I}_2 \end{bmatrix}$	$\begin{bmatrix} \mathbf{V}_1 \\ \mathbf{I}_2 \end{bmatrix}$		
$\begin{bmatrix} \mathbf{V}_1^+ \\ \mathbf{V}_2^+ \end{bmatrix}$	$\begin{bmatrix} \mathbf{V}_2^- \\ \mathbf{V}_2^+ \end{bmatrix}$	$\begin{bmatrix} \mathbf{V}_2 \\ -\mathbf{I}_2 \end{bmatrix}$	$\begin{bmatrix} \mathbf{I}_1 \\ \mathbf{I}_2 \end{bmatrix}$	$\begin{bmatrix} \mathbf{V}_1 \\ \mathbf{V}_2 \end{bmatrix}$	$\begin{bmatrix} \mathbf{I}_1 \\ \mathbf{V}_2 \end{bmatrix}$		

• impedance matrix Z

$$\begin{bmatrix} \mathbf{V}_1 \\ \mathbf{V}_2 \end{bmatrix} = \underbrace{\begin{bmatrix} \mathbf{Z}_{11} & \mathbf{Z}_{12} \\ \mathbf{Z}_{21} & \mathbf{Z}_{22} \end{bmatrix}}_{\mathbf{Z}} \cdot \begin{bmatrix} \mathbf{I}_1 \\ \mathbf{I}_2 \end{bmatrix}$$
(6)

• admittance matrix Y

$$\begin{bmatrix} \mathbf{I}_1 \\ \mathbf{I}_2 \end{bmatrix} = \underbrace{\begin{bmatrix} \mathbf{Y}_{11} & \mathbf{Y}_{12} \\ \mathbf{Y}_{21} & \mathbf{Y}_{22} \end{bmatrix}}_{\mathbf{Y}} \cdot \begin{bmatrix} \mathbf{V}_1 \\ \mathbf{V}_2 \end{bmatrix}$$
(7)

• hybrid matrix h

$$\begin{bmatrix} \mathbf{V}_1 \\ \mathbf{I}_2 \end{bmatrix} = \underbrace{\begin{bmatrix} \mathbf{h}_{11} & \mathbf{h}_{12} \\ \mathbf{h}_{21} & \mathbf{h}_{22} \end{bmatrix}}_{\mathbf{h}} \cdot \begin{bmatrix} \mathbf{I}_1 \\ \mathbf{V}_2 \end{bmatrix}$$
(8)

It should be noted that these definitions are similar to the standard 2-port network parameters [4] and are direct extensions for the study of multimode networks. Basically, each scalar parameter has been replaced with a matrix parameter ( $\mathbf{S}_{ij}, \mathbf{T}_{ij}, \mathbf{A}, \ldots$ ) of size  $M \times M$ , being M the number of modes. In fact, to highlight their matrix nature, they are written in bold here. Therefore, the multimode network parameters (**S**, **T**, **ABCD**, ...) have size  $2M \times 2M$ .

### III. STATE VECTOR SPACE OF THE NETWORK

The state of a network corresponds to the full information of the incoming and outgoing signals. Once a network has been specified, the outgoing signals depend only on the incoming signals, and thus the dimension of the state vector space is just 2M. In other words, only half of the state coordinates are really free. In fact, it could be said that it is the reason why all previous definitions of network

parameters have size  $2M \times 2M$ . Taking into account the standard network matrices introduced in (3–8), it is natural to define the coordinate systems contained in Table I. The vectors shown in this table were all made by staking in a single column the two vectors around each network matrix, so that each contains 4M complex components.

As usual, a basis of the state space vector could be defined. Table II shows six possible bases of the state space, each suitable for each type of network matrix. All places in the same column of the table contain the same basis, but expressed in different coordinate systems. Let us explain how this table is made. In a first stage, the bases of the diagonal places of the table (shadowed places) were arbitrarily filled using zeros and ones in the two lower components that correspond to the vector on the right side of equations (3-8). The upper half can then be filled using the same equations in such a way that it shows the corresponding network parameter. It should be noted that the two columns of each cell of the table actually represent 2M columns (one for each basis vector), as well as the bold style 0 and 1 are the zero matrix and the identity matrix of size  $M \times M$ . In a second stage, using the definitions of coordinate systems in Table II and the transformations (1) and (2), the six previous bases were rewritten in all coordinate systems. It is not worth adding that this table could easily be extended if some new network matrix was defined.

#### IV. CONVERSION BETWEEN TWO NETWORK MATRICES

The last stage, and goal of this paper, is to get the conversion rules. Consider any couple of two multimode network parameters **M** and **N**, which have been chosen among **S**, **T**, **ABCD**, **Z**, **Y**, and **h**, or whatever new definition. Since each basis vector in Table II must satisfy all network matrices, it is possible to write

$$\begin{bmatrix} Upper half of \\ M-basis expressed \\ in N-coordinates \end{bmatrix} = \mathbf{N} \cdot \begin{bmatrix} Lower half of \\ M-basis expressed \\ in N-coordinates \end{bmatrix}$$
(9)

where the upper and lower halves mean the first two rows and the last two rows of the matrices given in Table II, respectively. From this, the general formula for converting from M to N is the following:

$$\mathbf{N} = \begin{bmatrix} \text{Upper half of} \\ \mathbf{M}\text{-basis expressed} \\ \text{in } \mathbf{N}\text{-coordinates} \end{bmatrix} \cdot \begin{bmatrix} \text{Lower half of} \\ \mathbf{M}\text{-basis expressed} \\ \text{in } \mathbf{N}\text{-coordinates} \end{bmatrix}^{-1}$$
(10)

For example, using the S-basis expressed in T-CS shown in Table II (2nd row, 1st column), we can write the conversion rule from S to T as follows:

$$\begin{bmatrix} \mathbf{T}_{11} & \mathbf{T}_{12} \\ \mathbf{T}_{21} & \mathbf{T}_{22} \end{bmatrix} = \begin{bmatrix} \mathbf{1} & \mathbf{0} \\ \mathbf{S}_{11} & \mathbf{S}_{12} \end{bmatrix} \cdot \begin{bmatrix} \mathbf{S}_{21} & \mathbf{S}_{22} \\ \mathbf{0} & \mathbf{1} \end{bmatrix}^{-1}$$
(11)

		BASES OF THE NETWORK STATE SPACE											
	S-basis		T-basis		ABCD-basis		Z-basis		Y-basis		h-basis		
ACE	S-coordinates	$\mathbf{S}_{11}$	$\mathbf{S}_{12}$	$\mathbf{T}_{21}$	<b>T</b> <sub>22</sub>	$\frac{1}{2}(\mathbf{A}-\mathbf{Z}_{1}\cdot\mathbf{C})$	$\frac{1}{2}(\mathbf{B}-\mathbf{Z}_1\cdot\mathbf{D})$	$\frac{1}{2}(\mathbf{Z}_{11}\textbf{-}\mathbf{Z}_{1})$	$\frac{1}{2}\mathbf{Z}_{12}$	$\frac{1}{2}(1-\mathbf{Z}_{1}\cdot\mathbf{Y}_{11})$	$-\frac{1}{2}\mathbf{Z}_{1}\cdot\mathbf{Y}_{12}$	$\frac{1}{2}(\mathbf{h}_{11}-\mathbf{Z}_{1})$	$\frac{1}{2}\mathbf{h}_{12}$
		$\mathbf{S}_{21}$	$\mathbf{S}_{22}$	1	0	$\frac{1}{2}$ <b>1</b>	$\frac{1}{2}\mathbf{Z}_2$	$\frac{1}{2}\mathbf{Z}_{21}$	$\frac{1}{2}(\mathbf{Z}_{22}-\mathbf{Z}_{2})$	$-\frac{1}{2}\mathbf{Z}_{2}\cdot\mathbf{Y}_{21}$	$\frac{1}{2}(1 \cdot \mathbf{Z}_2 \cdot \mathbf{Y}_{22})$	$-\frac{1}{2}\mathbf{Z}_{2}\cdot\mathbf{h}_{21}$	$\frac{1}{2}(1 \cdot \mathbf{Z}_2 \cdot \mathbf{h}_{22})$
		1	0	$\mathbf{T}_{11}$	<b>T</b> <sub>12</sub>	$\frac{1}{2}(\mathbf{A}+\mathbf{Z}_{1}\cdot\mathbf{C})$	$\frac{1}{2}(\mathbf{B} + \mathbf{Z}_1 \cdot \mathbf{D})$	$\frac{1}{2}(\mathbf{Z}_{11}^{+}\mathbf{Z}_{1}^{-})$	$\frac{1}{2}\mathbf{Z}_{12}$	$\frac{1}{2}(1+\mathbf{Z}_{1}\cdot\mathbf{Y}_{11})$	$\frac{1}{2}\mathbf{Z}_{1}\cdot\mathbf{Y}_{12}$	$\frac{1}{2}(\mathbf{h}_{11}+\mathbf{Z}_{1})$	$\frac{1}{2}\mathbf{h}_{12}$
		0	1	0	1	$\frac{1}{2}$ <b>1</b>	$-\frac{1}{2}\mathbf{Z}_2$	$\frac{1}{2}\mathbf{Z}_{21}$	$\frac{1}{2}(\mathbf{Z}_{22}^{+}\mathbf{Z}_{2})$	$\frac{1}{2}\mathbf{Z}_{2}\cdot\mathbf{Y}_{21}$	$\frac{1}{2}(1+\mathbf{Z}_{2}\cdot\mathbf{Y}_{22})$	$\frac{1}{2}\mathbf{Z}_2 \cdot \mathbf{h}_{21}$	$\frac{1}{2}(1+\mathbf{Z}_{2}\cdot\mathbf{h}_{22})$
	T-coordinates	1	0	<b>T</b> <sub>11</sub>	<b>T</b> <sub>12</sub>	$\frac{1}{2}(\mathbf{A} \cdot \mathbf{Z}_1 \cdot \mathbf{C})$	$\frac{1}{2}(\mathbf{B} + \mathbf{Z}_1 \cdot \mathbf{D})$	$\frac{1}{2}(\mathbf{Z}_{11}^{+}\mathbf{Z}_{1})$	$\frac{1}{2}\mathbf{Z}_{12}$	$\frac{1}{2}(1+\mathbf{Z}_{1}\cdot\mathbf{Y}_{11})$	$\frac{1}{2}\mathbf{Z}_{1}\cdot\mathbf{Y}_{12}$	$\frac{1}{2}(\mathbf{h}_{11}^{+}\mathbf{Z}_{1})$	$\frac{1}{2}\mathbf{h}_{12}$
		$\mathbf{S}_{11}$	$\mathbf{S}_{12}$	<b>T</b> <sub>21</sub>	<b>T</b> <sub>22</sub>	$\frac{1}{2}(\mathbf{A} \cdot \mathbf{Z}_1 \cdot \mathbf{C})$	$\frac{1}{2}(\mathbf{B}-\mathbf{Z}_{1}\cdot\mathbf{D})$	$\frac{1}{2}(\mathbf{Z}_{11}-\mathbf{Z}_{1})$	$\frac{1}{2}\mathbf{Z}_{12}$	$\frac{1}{2}(1-\mathbf{Z}_{1}\cdot\mathbf{Y}_{11})$	$-\frac{1}{2}\mathbf{Z}_{1}\cdot\mathbf{Y}_{12}$	$\frac{1}{2}(\mathbf{h}_{11} - \mathbf{Z}_{1})$	$\frac{1}{2}\mathbf{h}_{12}$
		$\mathbf{S}_{21}$	$\mathbf{S}_{22}$	1	0	$\frac{1}{2}$ <b>1</b>	$\frac{1}{2}\mathbf{Z}_2$	$\frac{1}{2}\mathbf{Z}_{21}$	$\frac{1}{2}(\mathbf{Z}_{22}-\mathbf{Z}_{2})$	$-\frac{1}{2}\mathbf{Z}_{2}\cdot\mathbf{Y}_{21}$	$\frac{1}{2}(1 \cdot \mathbf{Z}_2 \cdot \mathbf{Y}_{22})$	$-\frac{1}{2}\mathbf{Z}_2\cdot\mathbf{h}_{21}$	$\frac{1}{2}(1 - \mathbf{Z}_2 \cdot \mathbf{h}_{22})$
TE SI		0	1	0	1	$\frac{1}{2}$ <b>1</b>	$-\frac{1}{2}\mathbf{Z}_2$	$\frac{1}{2}\mathbf{Z}_{21}$	$\frac{1}{2}(\mathbf{Z}_{22}^{+}\mathbf{Z}_{2})$	$\frac{1}{2}\mathbf{Z}_{2}\mathbf{Y}_{21}$	$\frac{1}{2}(1+\mathbf{Z}_{2}\cdot\mathbf{Y}_{22})$	$\frac{1}{2}\mathbf{Z}_{2}\cdot\mathbf{h}_{21}$	$\frac{1}{2}(1+\mathbf{Z}_2\cdot\mathbf{h}_{22})$
STA	ABCD-coordinates	$1 + S_{11}$	$\mathbf{S}_{12}$	$T_{11} + T_{21}$	$T_{12} + T_{22}$	Α	В	$\mathbf{Z}_{11}$	$\mathbf{Z}_{12}$	1	0	$\mathbf{h}_{11}$	<b>h</b> <sub>12</sub>
<b>ORK</b>		$Y_{1} \cdot (1 - S_{11})$	$-\mathbf{Y}_{1} \cdot \mathbf{S}_{12}$	$\mathbf{Y}_{1} \cdot (\mathbf{T}_{11} - \mathbf{T}_{21})$	$\mathbf{Y}_{1} \cdot (\mathbf{T}_{12} - \mathbf{T}_{22})$	С	D	1	0	$\mathbf{Y}_{11}$	<b>Y</b> <sub>12</sub>	1	0
<b>IETW</b>		$\mathbf{S}_{21}$	1+S <sub>22</sub>	1	1	1	0	$\mathbb{Z}_{21}$	$\mathbf{Z}_{22}$	0	1	0	1
THEN		$\mathbf{Y}_{2} \cdot \mathbf{S}_{21}$	$Y_{2}(S_{22}-1)$	<b>Y</b> <sub>2</sub>	- <b>Y</b> <sub>2</sub>	0	1	0	-1	- <b>Y</b> <sub>21</sub>	- <b>Y</b> <sub>22</sub>	<b>-h</b> <sub>21</sub>	- <b>h</b> <sub>22</sub>
OFT	<b>Z</b> -coordinates	$1+S_{11}$	$\mathbf{S}_{12}$	$T_{11} + T_{21}$	$T_{12} + T_{22}$	Α	В	$\mathbf{Z}_{11}$	$\mathbf{Z}_{12}$	1	0	$\mathbf{h}_{11}$	<b>h</b> <sub>12</sub>
EMS		$\mathbf{S}_{21}$	$1 + S_{22}$	1	1	1	0	$\mathbb{Z}_{21}$	$\mathbb{Z}_{22}$	0	1	0	1
SYST		$Y_1 (1-S_{11})$	$-\mathbf{Y}_{\!\!1}\!\!\cdot\mathbf{S}_{\!12}$	$\mathbf{Y}_{1} \cdot (\mathbf{T}_{11} - \mathbf{T}_{21})$	$Y_1 (T_{12} - T_{22})$	С	D	1	0	$\mathbf{Y}_{11}$	$\mathbf{Y}_{12}$	1	0
ATE		$-\mathbf{Y}_{2} \cdot \mathbf{S}_{21}$	$Y_{2}(1-S_{22})$	- <b>Y</b> <sub>2</sub>	<b>Y</b> <sub>2</sub>	0	-1	0	1	<b>Y</b> <sub>21</sub>	<b>Y</b> <sub>22</sub>	<b>h</b> <sub>21</sub>	<b>h</b> <sub>22</sub>
RDIN	<b>Y</b> -coordinates	$Y_1 \cdot (1 - S_{11})$	$-\mathbf{Y}_{1} \cdot \mathbf{S}_{12}$	$\mathbf{Y}_{1} \cdot (\mathbf{T}_{11} - \mathbf{T}_{21})$	$\mathbf{Y}_{1} \cdot (\mathbf{T}_{12} - \mathbf{T}_{22})$	С	D	1	0	$\mathbf{Y}_{11}$	<b>Y</b> <sub>12</sub>	1	0
COO		$-\mathbf{Y}_{2} \cdot \mathbf{S}_{21}$	$Y_{2}(1-S_{22})$	- <b>Y</b> <sub>2</sub>	$\mathbf{Y}_2$	0	-1	0	1	$\mathbf{Y}_{21}$	<b>Y</b> <sub>22</sub>	$\mathbf{h}_{21}$	<b>h</b> <sub>22</sub>
		$1 + S_{11}$	$\mathbf{S}_{12}$	$T_{11} + T_{21}$	$T_{12} + T_{22}$	Α	В	$\mathbf{Z}_{11}$	$\mathbf{Z}_{12}$	1	0	$\mathbf{h}_{11}$	<b>h</b> <sub>12</sub>
		$\mathbf{S}_{21}$	1+S <sub>22</sub>	1	1	1	0	$\mathbf{Z}_{21}$	$\mathbf{Z}_{22}$	0	1	0	1
	h-coordinates	$1 + S_{11}$	$\mathbf{S}_{12}$	$T_{11} + T_{21}$	$T_{12} + T_{22}$	Α	В	$\mathbf{Z}_{11}$	$\mathbf{Z}_{12}$	1	0	$\mathbf{h}_{11}$	<b>h</b> <sub>12</sub>
		$-\mathbf{Y}_{2} \cdot \mathbf{S}_{21}$	$Y_{2}(1-S_{22})$	- <b>Y</b> <sub>2</sub>	$\mathbf{Y}_2$	0	-1	0	1	$\mathbf{Y}_{21}$	<b>Y</b> <sub>22</sub>	$\mathbf{h}_{21}$	<b>h</b> <sub>22</sub>
		$Y_{1}(1-S_{11})$	$-\mathbf{Y}_{1} \cdot \mathbf{S}_{12}$	$\mathbf{Y}_{1} \cdot (\mathbf{T}_{11} - \mathbf{T}_{21})$	$\mathbf{Y}_{1} \cdot (\mathbf{T}_{12} - \mathbf{T}_{22})$	С	D	1	0	$\mathbf{Y}_{11}$	<b>Y</b> <sub>12</sub>	1	0
		$\mathbf{S}_{21}$	1+S <sub>22</sub>	1	1	1	0	$\mathbf{Z}_{21}$	$\mathbf{Z}_{22}$	0	1	0	1

TABLE II Bases of the state vector space expressed in the coordinate systems defined in Table I

Reciprocally, we can use the **T**-basis in **S**-CS also shown in Table I (1st row, 2nd column) to convert **T** into **S** through the following formula:

$$\begin{bmatrix} \mathbf{S}_{11} & \mathbf{S}_{12} \\ \mathbf{S}_{21} & \mathbf{S}_{22} \end{bmatrix} = \begin{bmatrix} \mathbf{T}_{21} & \mathbf{T}_{22} \\ \mathbf{1} & \mathbf{0} \end{bmatrix} \cdot \begin{bmatrix} \mathbf{T}_{11} & \mathbf{T}_{12} \\ \mathbf{0} & \mathbf{1} \end{bmatrix}^{-1}$$
(12)

Finally, any other conversion formula can be obtained in a similar fashion using (10) together with the corresponding basis contained in Table II.

## V. CONCLUSION

A general method to convert any multimode network matrix into another has been presented. The method is based on the assumption of a network state vector space and the setting of several bases expressed in different coordinate systems, which have been defined in accordance with the standard definitions of network matrices. The main advantage compared to previous works is that all conversion rules can be demonstrated by following the same steps. It significantly reduces the number of algebraic manipulations and, in addition, provides very compact conversion formulas. With the aid of (10) together with Table II, it is possible to write down up to 30 different conversion rules, while previous works [16]–[18] presented a lower number of conversion formulas which could make it necessary to use intermediate conversions to go from one network matrix to another.

Besides, different normalizations of equivalent voltages and currents can lead to different definitions of the network matrices (Smatrix for power waves [1], [2], [19] and pseudo-waves [20], normalized Z-matrix [1], among others), and thus different rules of conversion. In fact, the present work is important not only because of the practical conversion formulas shown here but also because complete demonstrations have been provided here in such a way that extensions to any other definition of network matrix could easily be incorporated following the same methodology.

#### REFERENCES

- R. Collin, Foundations for Microwave Engineering. Electrical engineering series, McGraw-Hill, 1992.
- [2] D. Pozar, Microwave Engineering. Wiley, 2012.
- [3] D. Otto, "A note on the induced emf method for antenna impedance," *IEEE Transactions on Antennas and Propagation*, vol. 17, no. 1, pp. 101–102, 1969.
- [4] D. Frickey, "Conversions between S, Z, Y, h, ABCD, and T parameters which are valid for complex source and load impedances," *IEEE Transactions on Microwave Theory and Techniques*, vol. 42, no. 2, pp. 205– 211, 1994.
- [5] S. Amari, R. Vahldieck, J. Bornemann, and P. Leuchtmann, "Spectrum of corrugated and periodically loaded waveguides from classical matrix eigenvalues," *IEEE Trans. Microw. Theory Techn.*, vol. 48, no. 3, pp. 453–460, 2000.
- [6] B. Bandlow, R. Schuhmann, G. Lubkowski, and T. Weiland, "Analysis of single-cell modeling of periodic metamaterial structures," *IEEE Trans. Magn.*, vol. 44, no. 6, pp. 1662–1665, 2008.
- [7] F. Bongard, J. Perruisseau-Carrier, and J. R. Mosig, "Enhanced Periodic Structure Analysis Based on a Multiconductor Transmission Line Model and Application to Metamaterials," *IEEE Trans. Microw. Theory Techn.*, vol. 57, no. 11, pp. 2715–2726, 2009.
- [8] E. Martini, G. M. Sardi, and S. Maci, "Homogenization processes and retrieval of equivalent constitutive parameters for multisurfacemetamaterials," *IEEE Trans. Antennas Propag.*, vol. 62, no. 4, pp. 2081– 2092, 2014.
- [9] J. P. S. Wong, A. Epstein, and G. V. Eleftheriades, "Reflectionless wideangle refracting metasurfaces," *IEEE Antennas and Wireless Propagation Letters*, vol. 15, pp. 1293–1296, 2016.
- [10] F. Mesa, R. Rodríguez-Berral, and F. Medina, "On the computation of the dispersion diagram of symmetric one-dimensionally periodic structures," *Symmetry*, vol. 10, no. 8, p. 307, 2018.
- [11] M. Bagheriasl, O. Quevedo-Teruel, and G. Valerio, "Bloch analysis of artificial lines and surfaces exhibiting glide symmetry," *IEEE Trans. Microw. Theory Techn.*, vol. 67, no. 7, pp. 2618–2628, 2019.
- [12] F. Mesa, G. Valerio, R. Rodríguez-Berral, and O. Quevedo-Teruel, "Simulation-assisted efficient computation of the dispersion diagram of periodic structures: A comprehensive overview with applications to filters, leaky-wave antennas and metasurfaces," *IEEE Antennas Propag. Mag.*, vol. 63, no. 5, pp. 33–45, 2021.
- [13] F. Giusti, Q. Chen, F. Mesa, M. Albani, and O. Quevedo-Teruel, "Efficient Bloch analysis of general periodic structures with a linearized multimodal transfer-matrix approach," *IEEE Trans. Antennas Propoag.*, vol. 70, no. 7, pp. 5555–5562, 2022.
- [14] A. C. Escobar, F. Mesa, O. Quevedo-Teruel, and J. D. Baena, "Homogenization of periodic structures using the multimodal transfer matrix method," *IEEE Transactions on Antennas and Propagation*, vol. 71, no. 6, pp. 4976–4989, 2023.
- [15] F. Giusti, E. Martini, S. Maci, and M. Albani, "Comparison between different approaches for the design of anomalous refractors," *IEEE Transactions on Antennas and Propagation*, vol. 72, no. 4, pp. 3495– 3506, 2024.
- [16] J. Frei, X.-D. Cai, and S. Muller, "Multiport S-parameter and Tparameter conversion with symmetry extension," *IEEE Transactions on Microwave Theory and Techniques*, vol. 56, no. 11, pp. 2493–2504, 2008.
- [17] M. Ma, F. You, M. Wei, T. Qian, Y. Chen, M. Pan, Y. Wang, C. Shen, R. Qin, T. Wu, and S. He, "A generalized multiport conversion between S parameter and ABCD parameter," in 2022 International Conference on Microwave and Millimeter Wave Technology (ICMMT), pp. 1–3, 2022.

- [18] T. Reveyrand, "Multiport conversions between S, Z, Y, h, ABCD, and T parameters," in 2018 International Workshop on Integrated Nonlinear Microwave and Millimetre-wave Circuits (INMMIC), pp. 1–3, 2018.
- [19] K. Kurokawa, "Power waves and the scattering matrix," *IEEE Transactions on Microwave Theory and Techniques*, vol. 13, no. 2, pp. 194–202, 1965.
- [20] R. B. Marks and D. F. Williams, "A general waveguide circuit theory," J. Res. Natl. Inst. Stand. Technol., vol. 97, pp. 533–561, 1992.