

# Analytical formula and measurement technique for the built-in potential of practical diffused semiconductor junctions

Miron J. Cristea, "Politehnica" University of Bucharest, Romania

Tel :0040-21402-4915 Fax: 0040-214-300-555 E-mail: [mcris@lydo.org](mailto:mcris@lydo.org)

## Abstract

Based on the Gauss law for the electric field, a new integral formula is deduced together with one of its possible applications, in the area of semiconductor junctions, specifically an analytical formula for the built-in potential of diffused semiconductor junctions. The measurement technique for the determination of the built-in potential is also described.

**Keywords:** built-in potential; diffused junctions; space-charge region; electric field, barrier capacitance, measurement technique.

## 1.Theory

The Gauss law for the electric field over an electrically charged space region is [1]:

$$\frac{dE}{dx} = \frac{\rho(x)}{\epsilon} \quad (1)$$

where  $E$  is the electric field,  $\rho$  is the electric space charge density and  $\epsilon$  the electrical permittivity. One-dimensional case is assumed, also linear, non-dispersive, isotropic material.

The electric field  $E$  is connected with the electric potential  $u$  in accordance with [1]:

$$E = -\frac{du}{dx} \quad (2)$$

By writing (1) as

$$dE = \frac{\rho(x)}{\epsilon} dx \quad (3)$$

multiplying the equation by  $x$ , and taking into account that

$$d(xE) = x dE + E dx \quad (4)$$

the next equation is obtained:

$$\frac{\rho(x)}{\epsilon} x dx = d(xE) - E dx \quad (5)$$

The integration of (5) over the space charge region (SCR) gives

$$\int_{SCR} \frac{x\rho(x)}{\epsilon} dx = \int_{SCR} d(xE) - \int_{SCR} E dx \quad (6)$$

and taking (2) into account, then

$$\int_{SCR} \frac{x\rho(x)}{\epsilon} dx = \int_{SCR} d(xE) + \int_{SCR} du \quad (7)$$

Since the electric field is zero at both ends of the SCR [2], the first term in the right hand of (7) vanishes, and the next equation is obtained:

$$\int_{SCR} \frac{x\rho(x)}{\epsilon} dx = V_{SCR} \quad (8)$$

where  $V_{SCR}$  is the total voltage drop across the space charge region.

## 2.The formula of the built-in potential

In the case of a semiconductor junction without external bias,  $V_{SCR}$  equals the built-in potential of the junction  $V_{bi}$ :

$$V_{bi} = \int_{SCR} \frac{x\rho(x)}{\epsilon} dx \quad (9)$$

For example, it is of interest to calculate the built-in potential of a diffused junction (i.e. having a Gaussian doping profile). For such junctions, the impurity profile, and in the depletion approximation, the space charge density (except for a factor of  $q$  – the elementary electric charge) are given by:

$$N_d(x) = N_0 \exp\left(-\frac{x^2}{L_d^2}\right) \quad (10)$$

where  $N_0$  is the surface concentration and  $L_d$  is the technological diffusion length [1]

$$L_d = 2\sqrt{D_i \cdot t_d} \quad (11)$$

with  $D_i$  - the doping impurity diffusion constant at certain diffusion temperature and  $t_d$  the diffusion time. Inserting (10) this into eq.(9), the following relation is obtained:

$$V_{bi} = \frac{qN_0L_d^2}{2\epsilon} \left[ 1 - \exp\left(-\frac{W_{sc0}^2}{L_d^2}\right) \right] \quad (12)$$

where  $W_{sc0}$  is the depletion region width of the junction at no external bias.

### 3.Particular cases

If  $W_{sc0} \ll L_d$ , the formula simplifies to:

$$V_{bi} = \frac{qN_0W_{sc0}^2}{2\epsilon} \quad (13)$$

Conversely, when  $W_{sc0} \gg L_d$ , (12) reduces to:

$$V_{bi} = \frac{qN_0L_d^2}{2\epsilon} \quad (14)$$

Since  $L_d$  is technologically determined, it is easy to discern between the limit cases (13) and (14).

### 4.Measuring the built-in potential

Since the zero-bias barrier capacitance per unit area of a junction is given by

$$C_{b0} = \frac{\epsilon}{W_{sc0}} \quad (15)$$

the barrier capacitance is measured in a standard circuit (that includes an AC-voltage generator), and then the built-in potential is calculated with the formula:

$$V_{bi} = \frac{qN_0L_d^2}{2\epsilon} \left[ 1 - \exp\left(-\frac{\epsilon^2}{L_d^2 C_{b0}^2}\right) \right] \quad (16)$$

If a calibrated DC-voltage source is also available, the measurement of the barrier capacitance can be realized at a determined reverse bias  $V_R$  of the junction, and the built-in potential will be determined from the formula

$$V_R + V_{bi} = \frac{qN_0L_d^2}{2\epsilon} \left[ 1 - \exp\left(-\frac{\epsilon^2}{L_d^2 C_b^2}\right) \right] \quad (17)$$

where  $C_b$  is the barrier capacitance corresponding to the reverse bias  $V_R$ .

## **Conclusion**

Based on the Gauss law for the electric field, a new integral formula was deduced in this work, together with one of its possible applications, in the area of semiconductor junctions, specifically a new formula for the built-in potential of diffused semiconductor junctions. The measurement technique for the determination of the built-in potential was also given.

## **References**

- [1] A.S. Grove, Physics and Technology of Semiconductor Devices, Wiley, New York, 1967
- [2] S.M. Sze, Semiconductor Devices: Physics and Technology, 2nd ed., Wiley, New York, 2001