

# Experimentation Procedure for Offloaded Mini-Apps Executed on Cluster Architectures with Xeon Phi Accelerators

Gary Lawson<sup>†</sup>, Vaibhav Sundriyal, Masha Sosonkina, and Yuzhong Shen  
Old Dominion University, Norfolk VA 23529, USA,  
Department of Modeling, Simulation, and Visualization Engineering,  
{ glaws003, vsundriy, msosonki, yshen } @odu.edu

**Abstract**—A heterogeneous cluster architecture is complex. It contains hundreds, or thousands of devices connected by a tiered communication system in order to solve a problem. As a heterogeneous system, these devices will have varying performance capabilities. To better understand the interactions which occur between the various devices during execution, an experimentation procedure has been devised to capture, store, and analyze important and meaningful data. The procedure consists of various tools, techniques, and methods for capturing relevant timing, power, and performance data for a typical execution. This procedure currently applies to architectures with Intel Xeon processors and Intel Xeon Phi accelerators. It has been applied to the Co-Design Molecular Dynamics mini-app, courtesy of the ExMatEx team. This work aims to provide end-users with a strategy for investigating codes executed on heterogeneous cluster architectures with Xeon Phi accelerators. A sample experiment is used to validate the procedure.

## I. INTRODUCTION

Measuring the performance and energy of an application can be a challenge. There are tools and methods for obtaining power and performance measurements, but accurately combining these with execution can be difficult. Further, from the point-of-view of a single developer, determination of the critical and non-critical execution points can be tedious or overwhelming. This work aims to provide an easy-to-reproduce procedure for accurately profiling a generic application with minimal code changes. This is beneficial to the solo developer looking to optimize an application, because key phases of execution within the application will fall into the authors outlined measurement scheme and promote isolation of these application phases. From the point-of-view of co-design, this work provides meaningful insights into the performance of an application; metrics such as memory bandwidth and computational throughput are used in place of application phases to describe execution time. However, obtaining these metrics does require execution, hence a well described procedure has been developed.

Accelerators are often adopted to reduce time-to-solution with low energy costs. From the work of Choi *et. al* [1], the Xeon Phi is capable of 11 GFLOPs/J and 880 MB/J for single-precision operations (measured throughput of 2 Tflops/s and 180 GB/s memory bandwidth). The Intel Xeon Phi is an accelerator that promotes high memory bandwidth (i.e. data movement) in addition to high computational throughput,

and that supports various execution modes [10], [16]. The Xeon Phi also offers user-level access to important power data, but poorly document how to utilize the information; this work sheds light on an easy-to-implement method to read power at the highest available sampling frequency for the device. Further, unlike tools or methods which relay on reading “window” power, such as MICSMC (Software Management Controller) [14], this work yields true, instantaneous power measurements based on the connectors that supply power.

The Xeon Phi co-processor is an accelerator with many execution modes: *native*, *offload*, and *symmetric*. This is unique to accelerators because normal operation of an accelerator is considered the *offload* execution mode; this is the mode used by GPUs. The Xeon Phi supports these other modes because of the micro-OS (running a special version of Linux) which enables the device to execute applications from the device itself; to the host, the Xeon Phi may be considered an additional node. Native execution mode allows an application to be executed only on the Xeon Phi; a user log’s onto the device and executes the application. Symmetric execution mode allows an application to be executed on the host and on the Xeon Phi, but each device is to solve a different sub-domain. Offload execution mode allows the host and accelerator to share the workload, but this execution mode requires some code changes. This is the ideal starting place for a procedure that requires some code instrumentation.

A heterogeneous cluster architecture is composed of many nodes connected by a network interconnect. Each node is composed of multiple devices with varying performance capabilities. An application executed on such an architecture must implement domain decomposition [4]; to take a problem and divide it into independent sub-problems, or sub-domains. These sub-domains are then distributed to each node, one or more sub-domain per node. However, domain decomposition requires data sharing between sub-domains to solve the total problem completely. For more simple implementations, computation of the problem and communication between sub-domains do not overlap. In this work, overlap between these two phases is not considered.

A heterogeneous cluster architecture is complex. Measuring the performance and energy consumption of such an architecture is also complex. Ideally, a measurement procedure

should have low performance impact and energy overhead; measuring an execution should not degrade the performance of the application, nor dramatically increase the required power draw. A procedure should also be easy-to-implement on other systems, and should not require dramatic code changes. In this work, such a procedure is presented to capture important data for all devices utilized in a heterogeneous cluster architecture. Important data includes bandwidth for various data transfers, work performed by the Xeon Phi accelerator, and power consumption for the various devices.

This work investigates specifically the offload execution mode [11], [9], however the procedure may be applied to native and symmetric execution modes as well with minimal changes. Some of these changes are to be introduced in this work, but have not been thoroughly tested; although this is a future work. To measure performance, hardware counters are read using the Performance API (PAPI) [5]. Host power is measured using the Running Average Power Limit (RAPL) interface [18], and Xeon Phi power is measured by reading the power file `/sys/class/micras/power` [15]. Timings are gathered during execution of an application; however additional timings are necessary beyond what is provided by default. This work will explain the additional code changes required for an application to provide accurate event timings to be used to synchronize execution flow with the power and performance samples.

The remainder of this paper is organized as follows: ?? provides details for cluster and application requirements, such as software, hardware, and code changes. ?? discusses defining the experiment and post-execution data processing involved in profiling execution output. Finally, ?? concludes.

## II. INITIAL STEPS

Before experimentation may proceed, certain software and hardware are required to accurately measure an execution. In general, the authors assume the cluster is composed of Intel Xeon processors of the Sandy-Bridge or newer micro-architecture supplied with one or more Intel Xeon Phi accelerators. This architecture configuration is assumed to be most common (among hybrid Xeon and Xeon Phi clusters), and provides the necessary hardware counters for model parameter estimations. However, it is not a requirement that the processors be of the Intel brand or the accelerator be a Xeon Phi *if* similar measurements may be obtained.

Beyond compiling the application [8] and executing in an MPI (Message Passing Interface) environment [7], the cluster architecture should have access to RAPL on the host, and a version of PAPI for both the host and native Xeon Phi; even for offload execution. Although the application will require calls to PAPI from within the offload section, PAPI itself should be natively compiled and the library accessible during compilation and execution of the application. For offload execution, a host version of PAPI is also required because offload sections may be executed on the host in the event of a conditional offload, or should “no-offload” be enabled during compilation. It is also important to note that for native Xeon

Phi hardware counters, only versions 5.3.0 and 5.3.2 currently support this functionality; more recent versions of PAPI (up to 5.4.1 as of this version) are unable to convert native hardware counter names into codes and therefore are unable to access the counter. Removing the dependency of PAPI from the parameter estimation procedure will be done by the authors in the future since PAPI provides limited support for the Xeon Phi. It is important to note that with the more recent versions of MPSS, configuring PAPI requires more than what is provided in the instructions for the PAPI 5.3.X versions. Specifically, the authors followed the instructions from version 5.4.1 [5] to use the following configurations options:

```
--with-mic
--host=x86_64-k10m-linux
--with-arch=k10m
--with-ffsll
--with-walltimer=cycle
--with-tls=__thread
--with-virtualtimer=
clock_thread_cputime_id,
```

along with all the other configuration steps as per instructions to PAPI versions 5.3.X.

### A. Code Instrumentation

This section defines the required code changes to implement offload execution in CoMD and to obtain highly accurate timings for the computation and communication phases on each device. These timings may then be cross-referenced to the power and performance measurements to define various performance metrics, and total energy consumption. Associate code changes and micro-measurement apps are provided. Each micro-measurement app only spawns a single-thread to sample and print.

1) *CoMD Overview*: CoMD is a proxy application developed as part of the Department of Energy co-design research effort [2] Extreme Materials at Extreme Scale [3] (ExMatEx) center. CoMD is a compute-intensive application where approximately 85-90% of the execution time is spent computing forces. Although two methods are available for the force computation, this work focuses only on one of them, the more complex and accurate EAM force kernel for short-range material response simulations, such as uncharged metallic materials [17]. The EAM kernel was chosen because its parallel performance generally receives less attention than the more commonly used Lennard-Jones potential, which easily yields itself to parallelism.

2) *Setup of the Offload Execution Mode*: Offloading to MIC requires the use of special pragmas defined for the Intel compilers. These pragmas specify the code sections to be processed by the Xeon Phi accelerator. Within the pragma statement, one must specify the MIC device to communicate with, the data to be transferred with the associated parameters (such as array length, data persistence, variable reassignment, etc.), offload conditional, and whether the offload event is asynchronous, among other options [8]. However, in addition to simply specifying what code sections to process on the

Xeon Phi, the arrays must be properly formatted for optimal transfer bandwidth.

It is possible, although inefficient, to transfer multi-dimensional arrays between the host and Xeon Phi. Therefore algorithm structures should conform to the structure-of-arrays data layout; CoMD is originally organized as an array-of-structures which do not transfer easily. This code change simply requires converting the multi-dimensional arrays into one-dimensional arrays. In the most recent experiments, CoMD is measured to obtain more than 3 GB/s bandwidth over the PCI bus (of 8 GB/s) for a problem size of 50 (500,000 atoms); the resulting communication time is insignificant with respect to the remaining computational requirements. This is one of many measurements to be obtained using the procedure. One final code improvement is the re-assignment of the maximum number of atoms per link cell: by default, a link cell may contain 64 atoms but has been reduced to 16 to reduce memory requirements per thread. PAPI must be instrumented into the offload sections such that memory and bandwidth may be approximated during execution. PAPI is simply started and stopped for each offload section such that the counter is always reset for the next offload; the result is printed with application output. SSE3 instructions have been enforced during compilation [12], and utilization of the 2 MB buffers available through the environment variable [6] has been implemented.

3) *Synchronization of Measuring Event Timers:* Power and performance measurements are obtained for each device individually. This approach removes unnecessary overhead because devices are not required to communicate measurement data during execution. However, this approach also requires the use of three (or more) separate timers: the algorithm timer, host timer, and accelerator timer(s). To synchronize these data files, two timings are output with each measurement or event output statement: local time in the format [HH:MM:SS], and the time from start as a decimal value. The time from start (TFS) value represents the time elapsed from the start of each measurement tool or algorithm execution. The use of the local timestamp ensures all timings are accurate to within one second, however in addition to TFS, the error in timings is reduced to a fraction of a second (within 10ms for the host, and 50ms for the Xeon Phi).

Until a more sophisticated, and automatic method is developed, direct source code manipulation is the simplest solution to start with. However, as offload execution already requires source code manipulation, the additional event timing statements are reasonable; especially for CoMD which features robust profiling output by default. Specifically, CoMD provides four specific functions which must occur within one iteration of the simulation; for other codes one or more functions may be required, but in general it is most important to quantify total simulation time, the time spent performing offload execution, and the time spent transferring data during the communication phase.

4) *Obtaining Execution Time Values:* The execution timings of interest are specifically: the time to compute on the host, communicate on the host, compute on the Xeon Phi,

and transfer data over the PCI bus. To obtain these timings, the application output must be consulted: for CoMD, the timings are excellently profiled although only the root timings are provided in entirety. For other applications, additional timings may be required to obtain host computation; this will be investigated in the future. The execution timings, which are already collected for each sub-domain, have been exposed to obtain exact timings for each sub-domain. Although this is not so much of interest in these offload-only execution experiments; the authors preliminary investigation into executions with multiple execution modes showed this information to be crucial and thus has been maintained for future investigations until an improved method has been determined.

5) *Using CPU Hardware Counters:* The host CPU micro-measurement application has been developed to continuously read the RAPL power counter for CPU Core and DRAM power; the sum is regarded as total CPU power as uncore device power is not considered. Additionally, host performance is measured using PAPI where the last-level-cache memory fill counter, and unhalted CPU cycles are measured; the hardware counter name differs slightly depending on micro-architecture. For Sandy-Bridge, “MEM\_LOAD\_UOPS\_MISC\_RETIRED:LLC\_MISS”, and “CPU\_CLK\_UNHALTED:THREAD\_P” are the native hardware counters used to approximate host memory usage and bandwidth. For Ivy-Bridge, unhalted cycles are captured using the same counter as on Sandy-Bridge, but the LLC memory counter is: “MEM\_LOAD\_UOPS\_RETIRED:L3\_MISS”. Power and performance are sampled at a rate of 10 ms; the resulting data is printed to output with the timestamp and TFS for synchronization.

6) *Using MIC Hardware Counters:* The MIC<sup>1</sup> micro-measurement application has been developed to continuously read the available power file [15]: /sys/class/micras/power which provides approximated power over two time windows, power to each connector, and voltage and power readings to the core, uncore, and DRAM devices. Unlike the host CPU definition of power, MIC power is based on the power draw measured for each connector: PCI-E, 2x3, and 2x4. The sum of each connector is the absolute power draw for the device as defined in the Xeon Phi data sheet [9]. The power file is updated only every 50ms, thus is the lowest available sample rate for the device.

For offload execution, the MIC micro-measurement app only measures power; however for native or symmetric execution, this micro-app would also measure performance with PAPI. For the Xeon Phi, the native hardware counters of interest are: “L2\_DATA\_READ\_MISS\_MEM\_FILL” and “CPU\_CLK\_UNHALTED”; these are used to obtain estimates for memory usage and bandwidth. For offload execution, these hardware counters are instead measured over the duration of each offload section and print with application

<sup>1</sup>MIC stands for “many-integrate cores” technology used in Intel Xeon Phi.

output. To obtain an estimate for vectorization intensity, a few executions (although one is really all that is needed) using the hardware counters: “VPU\_ELEMENTS\_ACTIVE” and “VPU\_INSTRUCTIONS\_EXECUTED” should be measured, where elements over instructions equates to vectorization intensity. In general, the value should be between 1 and 8 for double-precision, and 1 and 16 for single-precision [13].

### III. PROFILING EXECUTIONS

In this work, an execution is more than simply running the application; it requires properly measuring CPU and Xeon Phi power and performance, and synchronizing this output with the applications execution. A properly defined experiment must be presented, and the process of mining the raw output data is also discussed. The result of this process are measured performance metrics to describe various attributes for an application, such as the total workload for the accelerator defined in FLOPS and bandwidths for many different data transfer situations. The executions are always run with the `offload report` environment variable set to 2; this provides MIC time, CPU time (if available), and data transferred to and from the device. To distinguish offload reports between various sub-domains, it is advised that MPI is executed with the ‘-1’ option to print the sub-domain identification number.

#### A. The Experiment

The experiment should be designed such that all investigated parameters are meaningful. In this work, six meaningful parameters have been chosen: the system, number of nodes, number of Xeon Phi per node, total problem size, host frequency (no DVFS), and Xeon Phi cores used. In general, the authors are interested in determining the optimal configuration (defined by all six parameters) which is defined by a *static configuration* set (defined by: system, nodes, MICs/node, and problem size) and *configuration space* (defined by: host frequency and MIC cores). On the Borges system, two static configurations per problem size are investigated: *MIC 1* and *MIC 2*, because the system consists of a single-node. On Bolt, six static configurations per problem size are investigated: *N# MIC #*; Bolt only has three nodes with two Xeon Phi, hence one, two, and three node configurations are investigated, each with one and two Xeon Phi used. The parameters have been grouped into static configurations and configuration space because static configurations may be easily compared with one another and defined with a minimum energy; the minimum energy may be found in the configuration space, because these parameters impact execution energy and performance. Note, although the number of Xeon Phi also impacts energy, it is often desirable to compare the performance and energy for each investigated.

An experiment is composed of many executions; each may vary in configuration, but each follows the same execution process to ensure minimal measurement overhead. The process for a typical execution is as follows:

- 1) Start CPU micro-measurement app on all nodes
- 2) Start MIC micro-measurement app on all Xeon Phi

- 3) Sleep 20 seconds
- 4) Execute CoMD
- 5) Sleep 10 seconds
- 6) Stop MIC micro-measurement app on all Xeon Phi
- 7) Stop CPU micro-measurement app on all nodes
- 8) Copy MIC power output files from MIC to storage
- 9) Sleep 60 seconds.

Ample idle time is provided before execution begins to ensure a sufficient number of power samples may be obtained for each device such that idle power may be measured. For larger clusters, the timing for step three may need to be adjusted. The command to start each MIC power measurement is issued using SSH which incurs a slight delay before power measurements may begin. Idle power measurements are based on at least 10 seconds of sample data. CoMD is then executed according to the execution configuration parameters. Upon completion, a brief idle period is provided to capture power measurements before the CPU and MIC measurement threads are halted. Finally, a rest period of one minute is provided to allow the system to cool-down. Ideally this should be longer, but a typical experiment consists of hundreds or thousands of executions. The time spent allowing the system to rest accounts for the majority of the total execution time for an experiment.

#### B. Post-Execution Profiling

Upon successful completion of the experiment, a plentiful number of output files are available for post-execution processing. This process involves synchronizing measurement output with application execution to properly quantify timings, power measurements, and performance for various phases and states involved in execution. These raw metrics are then to be used to establish estimated global parameters that define each static configuration.

1) *Obtaining Execution Time Values:* Extracting execution time is fairly simple with CoMD. There are four main functions that occur every iteration: update position, velocity, compute force, and share data between sub-domains; for EAM, there is an additional data transfer during the force computation since it is a more specific algorithm. Host execution time is defined as time to update position plus velocity plus data redistribution minus the data transfer occurring within the redistribution phase. Host communication time is the sum of both communication phases (within the redistribution and force phase), but is more accurately defined as two comm timings: halo exchange and reduce. This is preferred because it is more interesting with respect to optimization to separate the point-to-point data transfers and reduce function timings. Xeon Phi computation time is based on the sum of offload report MIC time for all offloads throughout the simulation. PCI transfer time is based on the offload report as well; however is the difference between the sum of CPU time and MIC time over all offloads during the simulation. If CPU time is undefined (reports 0.0000 seconds), PCI time may be approximated as the difference between total simulation time (defined as loop in the CoMD output timings), and the time



to compute and communicate on host and to compute on the accelerator.

2) *Obtaining Power Consumption Values:* Extract power draw for each state, idle or active, is accomplished slightly differently for each device because idle time and duration differs for each device. For the host, the active state is defined by the host computation time; for host communication, PCI data transfer, or computation on the accelerator, the host remains idle. For the Xeon Phi, the active state is defined by the time to compute on the accelerator, and the device is otherwise idle. To synchronize power draw to execution state, the TFS for each file has to be synchronized to the TFS value from the application for the key execution phases. Host idle power is accumulated during host communication and the entire force computation because it includes accelerator computation and PCI data transfer. All other power is accumulated in host active power. For the Xeon Phi, active power is accumulated during offload execution and otherwise idle power is accumulated with the current power sample. Power is finally divided by the number of samples for each state (always greater than 100 samples).

3) *Obtaining Performance Values:* Extracting the performance metrics for each phase of execution is fairly straight forward with the required code instrumentations. For the Xeon Phi, memory usage is simply the LLC\_MISS counter multiplied by 64 bytes per cache line; bandwidth is memory usage times frequency divided by unhalted clock cycles. Because these are measured explicitly for the offload sections, these may simply be summated over all offloads during the simulation. For the host, performance samples must first be synchronized with execution and within the appropriate phase, but because only the host communication phase is of interest with respect to performance, this is the only phase in which the counters are accumulated. The host follows the same simple formula for computing memory usage and bandwidth as on the Xeon Phi. PCI memory usage is summated over each offload report within execution of the simulation by adding together the data sent to and received from the device. PCI bandwidth is estimated by the amount of data to transfer divided by transfer time.

Finally, work on the Xeon Phi may be estimated by multiplying computational throughput and computation time. Computational throughput may be calculated as the product of the number of cores, vectorization intensity, average number of operations per cycle, and operational frequency. For CoMD, vectorization intensity is measured to be 2.6; operations per cycle is estimated to be 1.15 as few fused-multiply operations are vectorized for this version of CoMD. These two values depend heavily on the implementation and application and must be measured and approximated appropriately for each application. Operations per cycle may be approximated by cross-referencing the compiler vectorization report and source code to determine which fused-multiply operations have been vectorized; all other operations count as one. Then, assuming each operation were to count only as one, take the ratio of number of vectorized to non-vectorized operations.

#### IV. CONCLUSIONS AND FUTURE WORK

This work has provided a detailed procedure through which developers may profile applications offloaded to accelerators and produce meaningful conclusions and insights. At this stage, only the mini-application CoMD has been investigated thoroughly with the procedure, but it is of the utmost concern to validate the technique on many other mini-applications. Additionally, reducing the number of executions to accurately measure the application is a high priority because this would provide larger datasets in a fraction of the time. Currently, the experiment requires several days to complete in the cluster environment because each configuration change requires a new execution and the associated system cool-down time. Finally, collecting hardware counter measurements without the aid of PAPI is also to be investigated; having to compile two separate versions of the library, and properly compile and link to them is counter-productive to the developer.

#### ACKNOWLEDGMENTS

This work was supported in part by the Air Force Office of Scientific Research under the AFOSR award FA9550-12-1-0476, by the National Science Foundation grants NSF/OCI—0941434, 0904782, 1047772, and by Ames Laboratory and Iowa State University under the contract DE-AC02-07CH11358 with the U.S. Department of Energy.

#### REFERENCES

- [1] Jee Choi, Marat Mukhan, Xing Liu, and Richard Vudue. Algorithmic time, energy, and power on candidate HPC compute building blocks. In *2014 IEEE 28th International Symposium on Parallel Distributed Processing (IPDPS)*, Arizona, USA, May 2014.
- [2] DOE. Co-design, 2013. <http://science.energy.gov/ascr/research/scidac/co-design/>.
- [3] ExMatEx. CoMD proxy application, 2012. <http://www.exmatex.org/comd.html>.
- [4] R. Hayashi and S. Horiguchi. Domain decomposition scheme for parallel molecular dynamics simulation. In *High Performance Computing on the Information Superhighway, 1997. HPC Asia '97*, pages 595–600, Apr 1997.
- [5] ICL:UT. Performance application programming interface PAPI, 2015. <http://icl.cs.utk.edu/papi/>.
- [6] Intel. How to use huge pages to improve application performance on Intel Xeon Phi coprocessor, 2012. [https://software.intel.com/sites/default/files/Large\\_pages\\_mic\\_0.pdf](https://software.intel.com/sites/default/files/Large_pages_mic_0.pdf).
- [7] Intel. Intel MPI library reference manual, 2014. [https://software.intel.com/sites/products/documentation/hpc/ics/impi/41/lin/Reference\\_Manual/index.htm?wapkw=](https://software.intel.com/sites/products/documentation/hpc/ics/impi/41/lin/Reference_Manual/index.htm?wapkw=).
- [8] Intel. Intel C++ and Fortran compilers, 2015. <https://software.intel.com/en-us/intel-compilers>.
- [9] Intel. Intel Xeon Phi coprocessor: Datasheet, 2015. <http://www.intel.com/content/www/us/en/processors/xeon/xeon-phi-coprocessor-datasheet.html>.
- [10] James Reinders Intel. An overview of programming for Intel Xeon processors and Intel Xeon Phi coprocessors, 2013. <https://software.intel.com/sites/default/files/article/330164/an-overview-of-programming-for-intel-xeon-processors-and-intel-xeon-phi-coprocessors-1.pdf>.
- [11] Kevin Davis Intel. Effective use of the Intel compiler's offload features, 2013. <https://software.intel.com/en-us/articles/effective-use-of-the-intel-compilers-offload-features>.
- [12] Martyn Corden Intel. How to compile for Intel AVX, 2012. <https://software.intel.com/en-us/articles/how-to-compile-for-intel-avx>.
- [13] Shannon Cepeda Intel. Optimization and performance tuning for Intel Xeon Phi coprocessors, part 2: Understanding and using hardware events, 2012. <https://software.intel.com/en-us/articles/>.
- [14] Taylor Kidd Intel. Intel Xeon Phi coprocessor power management configuration: Using the micsmc command-line interface, 2014. [https://software.intel.com/en-us/blogs/2014/01/31/intel-xeon-phi-coprocessor-power-m](https://software.intel.com/en-us/blogs/2014/01/31/intel-xeon-phi-coprocessor-power-management)

- [15] Intel Forums. how to measure energy consumption on the coprocessor?, 2013. <https://software.intel.com/en-us/forums/topic/488782?language=en>.
- [16] loc-nguyen Intel. Intel Xeon Phi coprocessor developer's quick start guide, 2015. <https://software.intel.com/en-us/articles/intel-xeon-phi-coprocessor-developers-quick-start-guide>.
- [17] Jamaludin Mohd-Yusof, Sriram Swaminarayan, and Timothy C. Germann. Co-design for molecular dynamics: An exascale proxy application, 2013. [http://www.lanl.gov/orgs/adts/publications/science\\_highlights\\_2013/docs/Pg88\\_89.pdf](http://www.lanl.gov/orgs/adts/publications/science_highlights_2013/docs/Pg88_89.pdf).
- [18] PAPI. Accessing the Intel RAPL registers, 2013. [http://icl.cs.utk.edu/projects/papi/wiki/PAPITopics:RAPL\\_Access](http://icl.cs.utk.edu/projects/papi/wiki/PAPITopics:RAPL_Access).