

Dynamic Slack Bus

Federico Milano, *IEEE Fellow*

Abstract—This letter proposes a general dynamic formulation of slack bus. With this aim, the angle constraint imposed by the slack bus is redefined as a set of differential equations and an energy source. The existence and role of the transient component of this source is also discussed in the letter. Based on this framework, the letter shows that the swing equations of synchronous machines can be interpreted as distributed, dynamic, multi-variable, local slack buses. Other relevant cases, including primary and secondary frequency regulation, passive loads as well as grid following and grid forming converters are discussed.

Index Terms—Slack bus, dynamic analysis, synchronous machine, frequency control, grid-following converter, grid-forming converter.

I. INTRODUCTION

The concept of slack bus, its modeling and link with secondary frequency regulation or market dispatch is a recurring topic in power system analysis. An in-depth review of the history and implementations of the slack bus model can be found in the introduction of [1]. In conventional power flow analysis, the slack bus model serves two purposes: (i) fix a reference phase angle; and (ii) provide a slack power to balance generation production, load consumption and network losses:

$$0 = \theta^o - \theta_i, \quad (1)$$

$$p_h = p_h^o + k_{g,h} \hat{\sigma}, \quad h = 1, \dots, n, \quad (2)$$

where i is the index of the i -th bus of the network; p_h is the active power injection at the h -th bus; $k_{g,h}$ is a factor that indicates the participation of the h -th generator to the system losses; and $\hat{\sigma} \in \mathbb{R}$ is the “slack” variable. The single bus formulation is obtained from (2) by imposing $k_{g,h} = 0$ for $n - 1$ generators.

The objective of this letter is to show that the conventional slack bus model for power flow analysis is a special case of a more general dynamic formulation.

II. SLACK BUS AS A SET OF DIFFERENTIAL EQUATIONS

Equation (1) is commonly interpreted as an algebraic (static) constraint. In this work, on the other hand, we interpret (1) as the equilibrium of a perfect tracking controller. In its simplest form, the dynamic form of (1) can be assumed to be a pure integrator:

$$\dot{\sigma}' = \theta^o - \theta_i. \quad (3)$$

Equations (1) and (3) are equivalent as, in steady state, $\dot{\sigma} = 0$. However, interpreting the slack as a differential equation allows further generalizing the concept of slack bus, as follows.

Equation (3) can be a non-perfect tracking controller. For example, a first-order droop control can be written as:

$$T\dot{\sigma}' = K(\theta^o - \theta_i) - H\hat{\sigma}, \quad (4)$$

For the power flow analysis, (1), (3) and (4) are equivalent, except for the fact that, if $H \neq 0$, (4) leads to $\theta_i \neq \theta^o$ in steady state. This difference is immaterial as the solution of any ac circuit represented in phasor domain is unique up to a phase angle reference.

Moreover, the dynamics of the slack variable do not need to be a first order nor a linear differential equation. As long as they depend

on θ_i , one can thus assume any set of differential equations for the slack variable(s):

$$\mathbf{T}\boldsymbol{\sigma}' = \mathbf{f}(\boldsymbol{\sigma}, \theta_i), \quad (5)$$

where $\boldsymbol{\sigma} \in \mathbb{R}^m$, $\mathbf{f} : \mathbb{R}^{m+1} \mapsto \mathbb{R}^m$ and $\mathbf{T} \in \mathbb{R}^m \times \mathbb{R}^m$. Some rows of \mathbf{T} can be null, thus leading to a set of differential-algebraic equations.

Observing (2), we note that the term $k_{g,h}\sigma$ has the units of a power. In general, this power can be composed of two terms; one term that is not null in steady-state, say $p_{h,s}$; and one transient term that vanishes in steady-state conditions, say $p_{h,t}$, as follows:

$$p_h = p_{h,s}(\boldsymbol{\sigma}) + p_{h,t}(\boldsymbol{\sigma}, \boldsymbol{\sigma}'). \quad (6)$$

where we have assumed that $p_{h,s}$ depends only on the states $\boldsymbol{\sigma}$ and $p_{h,t}$ on both the state and their first time derivative. The latter dependency is what makes $p_{h,t}$ vanish in steady-state. Equation (6) indicates that a device has slack bus capability only if it has a power source ($p_{s,h}$), as expected. On the other hand, the transient power component, which is due to some form of stored energy ($p_{t,h}$), vanishes in steady state. The examples further elaborate on this point and discuss the role of the transient component in the relevant case of the synchronous machine.

Finally, we note that there can be multiple (local) constraints on the bus voltage phase angles. One can in fact assume that each generator has its own local set of slack differential equations plus active power injection.

Combining the remarks above, we propose the following definition of device providing slack bus capability.

Definition: A set of differential-algebraic equations in the form:

$$\mathbf{T}_h \boldsymbol{\sigma}'_h = \mathbf{f}_h(\boldsymbol{\sigma}_h, \theta_h), \quad (7)$$

$$p_h = p_{s,h}(\boldsymbol{\sigma}_h) + p_{t,h}(\boldsymbol{\sigma}_h, \boldsymbol{\sigma}'_h) \quad (8)$$

has *slack bus capability* if, at equilibrium, it satisfies the condition:

$$\lim_{t \rightarrow \infty} \sigma_{k,h} \rightarrow \hat{\sigma}, \quad \exists k \in (1, \dots, m_h), \quad \forall h \in (1, \dots, n). \quad (9)$$

In (7), $\boldsymbol{\sigma}_h \in \mathbb{R}^{m_h}$, $\mathbf{f}_h : \mathbb{R}^{m_h+1} \mapsto \mathbb{R}^{m_h}$ and $\mathbf{T}_h \in \mathbb{R}^{m_h} \times \mathbb{R}^{m_h}$; p_h is the active power injected by the device into the grid; and θ_h is the bus voltage phase angle at a certain bus of the grid, generally, but not necessarily, the angle of the bus where the device is connected. In (9), $\hat{\sigma} \in \mathbb{R}$ is a common value for all devices providing slack bus capability.

Condition (9) means that, in steady state, local constraints (7) converge to the distributed slack bus model as in (2). Note, however, that the condition (1) is not required. Each device providing slack bus capability will determine its local θ_h that satisfies the steady-state condition $\mathbf{f}_h(\boldsymbol{\sigma}_h, \theta_h) = \mathbf{0}$.

Equations (7)-(8) represent a distributed, multi-variable, dynamic local slack bus model: *distributed* as there the slack variables appear in the power injection of each generator; *multi-variable* as $\boldsymbol{\sigma}_h$ is a vector or order greater than one; *dynamic* as $\boldsymbol{\sigma}'_h \neq \mathbf{0}$ in general; and *local* as each generator determines the local bus voltage phase angle θ_h . For comparison, model (2) and (4) is distributed, single-variable, dynamic, network-wide slack bus. And model (1) and (2) with all $k_{g,h} = 0$ except one is a centralized, single-variable, static, network-wide slack bus. Any other “combination” is equally valid as long as (9) is satisfied. This is illustrated below through a variety of examples.

III. EXAMPLES

A. Synchronous Machines

In light of the definition above, the classical swing equation of the synchronous machine can be interpreted as a distributed, multi-variable dynamic slack bus of the kind (7)-(8). In fact, the swing equations of the machine are in the form of (7), as follows:

$$\begin{aligned} \delta'_h &= \Omega_b (\omega_h - \omega_s), \\ M_h \omega'_h &= \tau_{m,h} - \tau_{e,h}^{\max} \sin(\delta_h - \theta_h) - D_h (\omega_h - \omega_n), \end{aligned} \quad (10)$$

where $\tau_{e,h}^{\max}$ is the maximum electrical torque; ω_n is the nominal synchronous speed with, typically, $\omega_n = 1$ pu; δ_h and ω_h are the angle and the rotor speed, respectively; ω_s is the angular speed of a common reference angular speed (typically, the angular speed of the center of inertia); Ω_b is the angular frequency base in rad/s; and parameters have usual meanings [2]. Hence, in this model, $\sigma = [\delta_h, \omega_h]^T$. The power injection of the machine into the grid is in the form of (8), where the two components of the power are:

$$p_{s,h} = \tau_{m,h} \omega_h - D_h (\omega_h - \omega_n)^2, \quad (11)$$

where $\tau_{m,h}$ is assumed to be constant for the classical machine model. If $\omega_h \approx \omega_s \approx 1$ pu, then one obtains $p_{m,h} \approx \text{const.}$, hence:

$$p_{s,h} = p_{m,h}^o - D_h (\omega_h - \omega_n)^2, \quad (12)$$

and

$$p_{t,h} = -M_h \omega'_h \omega_h = -\frac{d}{dt} \left(\frac{1}{2} M_h \omega_h^2 \right). \quad (13)$$

The last expression shows that the transient power is due to the kinetic energy stored in the machine inertia. Moreover, if $\omega_h \approx 1$, $p_{t,h} \approx M_h \omega'_h$, which is the term that appears in the swing equations of the machine, namely (10). More detailed models of the synchronous machine includes more states, such as transient and sub-transient rotor fluxes but, ultimately, all models can be written in the form of (7), that is, depends on states and θ_h .

As the system converges to an equilibrium, if $D_h \neq 0$ at least for some machines, then

$$\lim_{t \rightarrow \infty} \omega_h \rightarrow \omega_s, \quad (14)$$

This satisfies the condition (9). It is relevant to observe that, if the damping is $D_h = 0$ for all machines and there is no frequency regulation, after a contingency, the system either diverges or enters into a stationary periodic motion, which does not satisfy (9). Yet, the average value of the rotor speeds of the machines still satisfies (9). We can thus define a *weak slack bus* condition as follows:

$$\lim_{t \rightarrow \infty} \langle \sigma_{k,h} \rangle \rightarrow \hat{\sigma}, \quad \exists k \in (1, \dots, m_h), \quad \forall h \in (1, \dots, n), \quad (15)$$

where $\langle \cdot \rangle$ represents the average over the period of the motion.

B. Primary Frequency Control

In this example, we consider synchronous machines with primary frequency control. In its simplest form, the model of a turbine governor can be written as:

$$T_h \tau'_{m,h} = \tau_{m,h}^o - \frac{1}{R_h} (\omega_h - \omega_n) - \tau_{m,h}, \quad (16)$$

where R_h is the droop coefficient and $p_{m,h}^o$ is the turbine power set point. Thus, (12) can be rewritten as:

$$p_{s,h} = p_{m,h}^o - (D_h + R_h^{-1}) (\omega_h - \omega_n)^2, \quad (17)$$

where $p_{m,h}^o = \tau_{m,h}^o \omega_h \approx \tau_{m,h}^o$. The transient term is:

$$\begin{aligned} p_{t,h} &= -M_h \omega'_h \omega_h - T_h \tau'_{m,h} \omega_h \\ &\approx -M_h \omega'_h - T_h \tau'_{m,h}, \end{aligned} \quad (18)$$

where, for slow dynamic of the governor, the second term is small with respect to the inertial response of the synchronous machine. The following remarks are relevant.

Remark 1: The effect of the droop frequency control is, ultimately, to modify the damping of the machine. Thus, in steady state, the expression of $p_{s,h}$ in (17) satisfies the slack bus condition (9).

Remark 2: If one turbine governor is integral, for example:

$$T_h \tau'_{m,h} = -\frac{1}{R_h} (\omega_h - \omega_n), \quad (19)$$

then, in steady state, $(\omega_h - \omega_n)^2 = 0$, which leads to $p_{s,h} = p_{m,h}^o$ for all machines except for the one with integral frequency control. For this machine, $p_{s,h}$ is whatever active power satisfies the power balance at the point of connection of the machine with the grid. This case is equivalent to the single slack bus model (1). Moreover, only one turbine governor can be integral for an interconnected grid, otherwise, the active power injections of the generators connected to the integral governors are undetermined. This conclusion is generally obtained in the context of primary frequency control (see, e.g., [2]) not as a particular model of dynamic slack bus.

C. Automatic Generation Control

It is possible to show that a perfect-tracking automatic generation control (AGC) is equivalent in steady state to a distributed slack bus model. This concept has been discussed in the literature (see, e.g., [1]), however, the derivation of this result in the framework of a generalized dynamic slack bus model is a contribution of this paper. In particular, we show, based on proposed definition, that the ensemble of an AGC coupled with turbine governors and synchronous machines constitutes a distributed, multi-variable, dynamic, network-wide slack bus model.

The simplest AGC model is an integral controller:

$$\xi' = K_o (\omega_n - \omega_s), \quad (20)$$

Its output signal is shared with the turbine governors of the synchronous machines and adjusts their power set point. Equation (16) is thus rewritten as:

$$T_h \tau'_{m,h} = \tau_{m,h}^o + r_h \xi - \frac{1}{R_h} (\omega_h - \omega_n) - \tau_{m,h}, \quad (21)$$

where, in conventional implementations, $r_h = R_h (\sum_{h=1}^n R_h)^{-1}$. As (20) is perfect tracking, in steady state, the model composed of (10), (20) and (21) leads to the following active power injection for the h -th synchronous machine:

$$p_h = p_{m,h}^o + \tilde{r}_h \xi, \quad (22)$$

where $\tilde{r}_h = r_h \omega_n$ and which has the same form as (2) — and thus satisfies (9) — with $\hat{\sigma} \equiv \xi$.

D. Passive Load

This example considers a passive load modeled as a series RLC circuit. Using the dq-axis reference frame, the load equations at bus h are:

$$\begin{aligned} \ell_h \bar{v}'_{\ell,h} &= \bar{v}_h - \bar{v}_{c,h} - (r_h + j\Omega_b \ell_h) \bar{v}_{\ell,h}, \\ c_h \bar{v}'_{c,h} &= \bar{v}_{\ell,h} - j\Omega_b c_h \bar{v}_{c,h}, \end{aligned} \quad (23)$$

where $\bar{v}_h = v_h^d + jv_h^q$, $\bar{v}_{c,h} = v_{c,h}^d + jv_{c,h}^q$, $\bar{v}_{\ell,h} = i_{\ell,h}^d + ji_{\ell,h}^q$ are the Park vectors of the voltage at the grid bus, the voltage on the capacitor and the load current, respectively; r_{hk} , $j\Omega_b \ell_{hk}$ and $j\Omega_b c_h$ are the resistance, inductive reactance and capacitive susceptance, respectively, of the load. Then, the source and transient powers are:

$$\begin{aligned} p_{s,h} &= 0, \\ p_{t,h} &= \ell_{hk} i'_{hk} i_{hk} + c_h v'_h v_h, \end{aligned} \quad (24)$$

where $p_{s,h}$ is zero as the load is a passive device and $p_{t,h}$ accounts for the energy stored in the capacitive and inductive elements. The load, as expected and as any other passive element of the grid, including transmission lines, cannot provide any steady-state slack bus capability, and its transient support runs out quickly as it due to the energy stored in its inductive and capacitive elements.

E. Grid-Following Converters

Grid-following converters (GFLs) are synchronized to the ac grid through a phase-locked loop (PLL), and include a dc circuit, an ac filter as well as inner-loop current controllers and outer-loop voltage controllers. A detailed description of typical dynamic models of GFL converters for system stability studies can be found, for example, in [3], [4]. The active power injected by the GFL into the grid is:

$$p_h = v_h^d i_h^d + v_h^q i_h^q, \quad (25)$$

where the current dq-axis components, namely (i_h^d, i_h^q) , are controlled in order to impose a reference dc and ac voltage; and the converter voltage dq-axis components (v_h^d, v_h^q) are linked to the grid voltage (v_h, θ_h) , as follows:

$$\begin{aligned} v_h^d &= v_h \cos(\theta_h - \hat{\theta}_h), \\ v_h^q &= v_h \sin(\theta_h - \hat{\theta}_h), \end{aligned} \quad (26)$$

where $\hat{\theta}_h$ is the angle estimated through the PLL, a simple implementation of which is:

$$\begin{aligned} \zeta_h' &= \theta_h - \hat{\theta}_h, \\ -k_h^p \zeta_h' &= k_h^i \zeta_h - \Delta \hat{\omega}_h, \\ \hat{\theta}_h' &= \Omega_b \Delta \hat{\omega}_h, \end{aligned} \quad (27)$$

Then, the power injected into the grid can be decomposed into the following source and transient active power expressions:

$$\begin{aligned} p_{s,h} &= p_{dc} - g_{dc} v_{dc}^2 - r_f i_h^2, \\ p_{t,h} &= c_{dc} v_{dc}' v_{dc} + \ell_f i_h' i_h + c_f v_h' v_h, \end{aligned} \quad (28)$$

where r_f , ℓ_f , c_f are the resistance, inductance and capacitance (expressed in pu) of the ac filter of the converter; g_{dc} is an equivalent conductance that accounts for the losses of the converter; c_{dc} is the condenser utilized to filter the ripple on the converter dc voltage; v_h and i_h are the ac voltage and current, respectively; $p_{dc} = v_{dc} i_{dc}$ is the dc power injected into the converter. From (28), one obtains that the GFL can provide slack bus capability in steady-state only if the dc side includes a controlled energy source. For example, if the dc current of the energy source is regulated through a droop frequency controller, one has:

$$T_{dc} i_{dc}' = i_{dc}^o - \frac{1}{R_{dc}} (\omega_h - \omega_n) - i_{dc}, \quad (29)$$

which leads to rewrite (28) as:

$$\begin{aligned} p_{s,h} &= v_{dc} i_{dc}^o - \frac{v_{dc}}{R_{dc}} (\omega_h - \omega_n) - g_{dc} v_{dc}^2 - r_f i_h^2, \\ p_{t,h} &= T_{dc} i_{dc}' i_{dc} + c_{dc} v_{dc}' v_{dc} + \ell_f i_h' i_h + c_f v_h' v_h. \end{aligned} \quad (30)$$

In steady state, the first equation of (30) resembles the distributed slack model (2). Moreover, similarly to the case of the passive load, the transient power $p_{t,h}$ is due to the energy stored in the dc and ac filters, and it decays in the order of milliseconds in case of a disturbance.

F. Grid-Forming Converters

Grid-forming converters (GFM) can be formulated as a set of equations similar to (10)-(13) [5]. The main difference with GFLs, is how the converter voltage is linked to the grid voltage, as follows:

$$\begin{aligned} v_h^d &= v_h \cos(\alpha_h - \hat{\theta}_h), \\ v_h^q &= v_h \sin(\alpha_h - \hat{\theta}_h), \end{aligned} \quad (31)$$

where the variable α_h is utilized in the active power control of the GFM:

$$D_\alpha \alpha_h' = p_h^{\text{ref}} - p_h - H_\alpha \alpha_h, \quad (32)$$

from where one can deduce that the source and transient powers of the GFM (omitting for simplicity the terms due to dc and ac filters and losses which are similar to the ones shown for the GFL) are:

$$\begin{aligned} p_{s,h} &= p_{dc} - p_{\text{losses}} - H_\alpha \alpha_h, \\ p_{t,h} &= D_\alpha \alpha_h', \end{aligned} \quad (33)$$

where $v_{dc} i_{dc} - p_{\text{losses}} = p_h^{\text{ref}}$ in steady state, thus resembling the case of a distributed slack (2). In some configurations, the dynamics of the GFM are implemented in such a way that the converter behaves as a virtual synchronous machine [6], leading to:

$$\begin{aligned} \alpha_h' &= \tilde{\omega}_h, \\ M_\alpha \tilde{\omega}_h' &= p_h^{\text{ref}} - p_h - D_\alpha \tilde{\omega}_h - H_\alpha \alpha_h, \end{aligned} \quad (34)$$

and

$$\begin{aligned} p_{s,h} &= p_{dc} - p_{\text{losses}} - H_\alpha \alpha_h - D_\alpha \tilde{\omega}_h, \\ p_{t,h} &= M_\alpha \tilde{\omega}_h', \end{aligned} \quad (35)$$

which closely resemble (12) and (13) of synchronous machines.

IV. CONCLUSIONS

The letter shows that the well-known distributed slack bus model can be interpreted as the steady-state version of a set of differential-algebraic equations. The dynamic version includes a transient component which has a role in the *weak* version of the proposed definition. A variety of examples applies the proposed framework to a variety of devices, including passive loads and electronic power converters with both grid-following and grid-forming controls. Future work will elaborate on the proposed framework and study whether it is possible to set up devices with dynamic slack bus capability where the slack variables do not converge, in steady-state, to the system frequency.

REFERENCES

- [1] S. Dhople, Y. C. Chen, A. Al-Digs, and A. D. Domínguez-García, "Reexamining the distributed slack bus," *IEEE Trans. on Power Systems*, vol. 35, no. 6, pp. 4870–4879, 2020.
- [2] F. Milano, *Power System Modelling and Scripting*. London, UK: Springer, 2010.
- [3] F. Milano and Á. Ortega, *Converter-Interfaced Energy Storage Systems*. Cambridge University Press, 2019.
- [4] D. Pal, B. K. Panigrahi, B. Johnson, D. Venkatramanan, and S. Dhople, "Large-signal stability analysis of three-phase grid-following inverters," *IEEE Trans. on Energy Conversion*, pp. 1–15, 2023.
- [5] R. Rosso, X. Wang, M. Liserre, X. Lu, and S. Engelken, "Grid-forming converters: Control approaches, grid-synchronization, and future trends—a review," *IEEE Open Journal of Industry Applications*, vol. 2, pp. 93–109, 2021.
- [6] O. Mo, S. D'Arco, and J. A. Suul, "Evaluation of virtual synchronous machines with dynamic or quasi-stationary machine models," *IEEE Trans. on Industrial Electronics*, vol. 64, no. 7, pp. 5952–5962, 2017.