

# A novel methodology for antenna design and optimization: *Variable $Z_0$* (ver. 2)

## Richard A. Formato

Registered Patent Attorney & Consulting Engineer  
Cataldo & Fisher, LLC, 400 TradeCenter, Suite 5900  
Woburn, MA 01801 USA  
rf2@ieee.org, rformato@cataldofisher.com

**Abstract** — This paper describes “Variable  $Z_0$ ,” a novel and proprietary approach to antenna design and optimization. The new methodology is illustrated by applying it to the design of a resistively-loaded bowtie antenna and two broadband Yagi-Uda arrays. *Variable  $Z_0$*  is applicable to any antenna design or optimization methodology. Using it will result in generally better antenna designs across any user-specified set of performance objectives.

**Keywords** — Variable  $Z_0$ ,  $Z_0$ , characteristic impedance, feed system, antenna, antenna design, antenna optimization, design objectives, performance objectives, bandwidth, impedance bandwidth, broadband, ultra wideband, UWB, resistive loading, impedance loading, bowtie, Yagi, Yagi-Uda, Central Force Optimization, CFO, numerical optimization, optimization algorithm, metaheuristic

## 1. Introduction

This paper describes what the author believes to be a novel and proprietary antenna design methodology called “Variable  $Z_0$ ,”  $Z_0$  being the antenna feed system characteristic impedance. *Design* refers to the process of specifying a complete set of parameters that define an antenna meeting specific performance objectives. *Optimization* refers to specifying a complete set of parameters that define the antenna that *best* meets specific performance objectives. While *Variable  $Z_0$*  may be particularly useful for improving impedance bandwidth (IBW), the methodology can be used to meet any performance objectives, even ones that do not consider IBW at all.

Traditional antenna design and optimization methods, processes, or procedures (“methodology”) view  $Z_0$  as a *fixed* design *parameter* with a constant value specified at the start of the methodology.  $Z_0$  therefore is not a *variable* quantity whose value is determined *by* the methodology. This distinction is quite important, because traditional methodology excludes from the outset all designs that could provide better performance by using some other value of  $Z_0$ . *Variable  $Z_0$*  improves on traditional methodologies by treating  $Z_0$  as another design *variable* in the set of variable antenna parameters to be determined by the methodology. *Variable  $Z_0$*  is applied to the design of a numerically optimized ultra wideband (UWB) bowtie antenna and to two broadband Yagi-Uda arrays to illustrate its use.

## 2. $Z_0$ as a design variable

IBW is defined as the frequency band or bands within which  $Z_m$ , the antenna input impedance, is matched within specified limits to the feed system characteristic impedance,  $Z_0$ . The required degree of matching can be specified in terms of the antenna’s actual input impedance (resistance,  $R_m$ , and reactance,  $X_m$ ) as a function of frequency, or, as is more often the case, in terms of a maximum voltage standing wave ratio (VSWR). IBW typically is specified as  $VSWR // Z_0 \leq 2:1$  ( $//$  denoting “relative to”), which is equivalent to a return loss (scattering parameter  $S_{11}$ ) approximately less than  $-10$  dB. Other

VSWR thresholds can be used instead, and frequently are. Zehforoosh *et al.* [1] describes the design of an UWB microstrip antenna and provides a good summary of  $Z_0$ 's significance as a design parameter in the context of IBW. As is usual in the traditional methodology,  $Z_0$  in [1] is a fixed parameter, not a variable quantity as it is in *Variable  $Z_0$* .

While *Variable  $Z_0$*  methodology is useful in any antenna design, its widest range of applicability likely will be in improving IBW, which consequently is emphasized in this paper. The literature is replete with examples of various design and optimization approaches to improving IBW. Hoorfar's review of Evolutionary Programming (EP) in electromagnetic optimization [2] provides several antenna design examples involving IBW, all of which employ fixed  $Z_0$ . An optimized dipole array design using fixed  $Z_0$  is described in [3]. An extensive study of the impact of various antenna parameters on down-link performance appears in [4], but  $Z_0$  is not one of those parameters. Boryssenko [5] presents an extensive discussion of methodologies for designing wideband antennas, yet  $Z_0$  is not included as a design *variable*. The multiband and UWB printed bowties described in [6] and [7], respectively, both utilize fixed  $Z_0$  as a design parameter. Other UWB bowtie configurations (slot [8], UWB balun-fed [9], and dual-band slot [10]) are all designed using constant values for  $Z_0$ . Of course, the traditional practice of specifying  $Z_0$  as a fixed parameter is not restricted to bowties. It is the approach used in all antenna design and optimization methodologies, as, for example, in [11] (broad-band array optimization) and [12] (Particle Swarm Optimized Vivaldi antenna). The state-of-the-art, which fixes  $Z_0$ 's value, limits achievable IBW (as well as meeting other performance objectives) because better results are obtainable when  $Z_0$  is considered to be a design *variable* whose value is determined *by* the design or optimization process, instead of being a user-supplied constant at the outset of that process.

### 3. Design example: resistively loaded broadband bowtie

As discussed above, the bowtie antenna has been studied extensively, and it provides a simple structure to illustrate how better IBW can be achieved using *Variable  $Z_0$*  instead of traditional methodology. Its structure is shown schematically in Fig. 1. The antenna comprises two symmetrical wire triangles connected by a feed wire. The perfectly electrically conducting (PEC) wire has diameter  $2a$ , and the arm and feed wire lengths are  $L_{arm}$  and  $L_{feed}$ , respectively. The bowtie's flare angle (vertex angle) is  $2\alpha$ . The antenna is impedance-loaded with four symmetrically placed loading resistors of equal-value,  $R_{load}$ , that increase IBW at the expense of radiation efficiency (see [13] for a discussion of impedance loading). The resistors are inserted in series with the antenna wire a distance  $L_{load}$  from the vertex. Excitation is provided by an RF (radio frequency) source at the center of the feed wire.

The bowtie structure was modeled in free space with the Numerical Electromagnetics Code Ver 4.1D (NEC4, double precision) [14,15], the "modeling engine." NEC4 is a widely used Method of Moments (MoM) modeling code for wire structures developed at Lawrence Livermore National Laboratory. The RF source is located at the origin of NEC's standard right-handed spherical polar coordinate system with the antenna the Y-Z plane and the feed wire along the Y-axis. For readers interested in NEC MoM modeling who do not have access to NEC4, freeware versions of NEC2 are available [16] (source code and executables). While NEC4 is particularly useful for wire structures like the bowtie, any suitable modeling engine, numerical, analytical or hybrid, can be used instead. The engine must be capable of accurately calculating all performance parameters that are used in evaluating how good a particular antenna design is.




Fig. 1. Schematic diagram of the resistively loaded bowtie antenna.

#### 4. Bowtie design variables

There are five bowtie design *variables*:  $L_{arm}$ ,  $\alpha$ ,  $L_{load}$ ,  $R_{load}$ , and, importantly and differently from traditional methodology,  $Z_0$ . Each one of these quantities is allowed to vary in the design or optimization process. Their values are determined by meeting specific performance goals or by achieving the best performance using a designer-specified “fitness” or “objective” function that measures how well a particular set of values meets the desired performance goals. The key idea in *Variable*  $Z_0$  is that the value of  $Z_0$  be allowed to change during the design or optimization methodology because different values result in different antenna performance. It is likely that specific performance objectives can be met with multiple values of  $Z_0$ , especially in the design setting. Even in the optimization setting there may be multiple values for a “best” design corresponding to multiple global optima, or that result from using a stochastic optimization algorithm or one that has converged to a local optimum.

Note that the wire radius  $a$  and the feed wire length  $L_{feed}$  are *not* included in the design variable list because these quantities are *fixed parameters*. As in the traditional design methodology, their values are assigned at the beginning of the design or optimization process, and they do not change as a result of that process.  $Z_0$  is treated that way in traditional methodology, that is,  $Z_0$  is assigned a value that does not change and is not determined by the methodology. Of course, neither  $a$  nor  $L_{feed}$  need be fixed. They could be allowed to vary with their values determined by how well the performance goals are met, because different values of  $a$  or  $L_{feed}$  might improve performance. However, in the bowtie design discussed here these quantities are held constant as examples of the fixed design parameters used in traditional methodology.

#### 5. Optimization methodology

Any methodology can be used to design an antenna using *Variable*  $Z_0$  (it is applicable regardless of the methodology). For the bowtie design example, CFO (Central Force Optimization) [17] was used. But any number of other commonly employed algorithms, such as Particle Swarm (PSO) [18], Ant Colony (ACO) [19], Group Search Optimizer (GSO) [20], or Differential Evolution (DE) [21], could be used instead. This “product by process” approach applies to any methodology, deterministic ones like CFO; stochastic metaheuristics like PSO, ACO, GSO or DE; analytic approaches such as extended Wu-King impedance loading [13]; or even “seat of the pants” optimization based on experience, intuition, or a “best guess.” The specific optimization methodology is irrelevant to the novelty of treating  $Z_0$  as a design

variable instead of a fixed parameter. Thus, *Variable*  $Z_0$  can be used advantageously with *any* design or optimization methodology.

The bowtie fitness function (to be maximized by CFO) is defined as

$$F(Z_0, R_{load}, L_{load}, L_{arm}, \alpha) = \frac{5 \cdot \min(G_{max}) + \min(\varepsilon)}{|\max(R_{in}) - Z_0| \cdot \{\max(VSWR // Z_0) - \min(VSWR // Z_0)\} \cdot \{\max(X_{in}) - \min(X_{in})\}}$$

$\varepsilon$  is the bowtie's radiation efficiency,  $G_{max}$  its maximum gain, and  $Z_{in} = R_{in} + jX_{in}$  ( $j = \sqrt{-1}$ ) its input impedance, all as functions of frequency. The first term in the denominator drives the input resistance toward  $Z_0$  (assumed purely resistive), while the second and third terms, respectively, minimize the VSWR and input reactance variability with frequency. A particular bowtie's fitness increases with increasing radiation efficiency and minimum maximum gain. It decreases with increasing mismatch between  $Z_0$  and  $R_{in}$  and increasing variability in VSWR and input reactance. The coefficient 5 in the gain term was determined empirically. Of course, the antenna designer is free to specify any desired fitness function, with different fitnesses creating different decision space landscapes resulting in different antenna designs.

A parameter-free CFO implementation was used as described in [22-24] (only the fitness function is supplied as input to the algorithm; Appendix I contains a complete source code listing). Because there are five design variables, the decision space is 5-dimensional ( $N_d = 5$ ) with the following hardwired

parameters:  $N_t = 250$ ,  $N_\gamma = 11$ ,  $\max\left(\frac{N_p}{N_d}\right) = 8$ ,  $F_{rep}^{init} = 0.5$ ,  $\Delta F_{rep} = 0.1$ ,  $F_{rep}^{min} = 0.05$ ,  $\alpha = 1$ ,  $\beta = 1$ ,  $G = 2$ ,  $\Delta t = 0.5$ . Decision space adaptation was applied every 20<sup>th</sup> time step with an early termination criterion of fitness saturation for 25 consecutive steps (variation  $\leq 10^{-6}$ ). The best fitness returned by CFO was  $1.5806 \times 10^{-4}$  (probe #1) with  $\frac{N_p}{N_d} = 2$  and  $\gamma = 1$  at step 35.

The decision space was defined as follows:  $0.01 \leq L_{arm} \leq 0.08$  m,  $10^\circ \leq \alpha \leq 80^\circ$  (bowtie variables);  $1 \leq \left\lfloor \frac{L_{load}}{L_{arm}} \right\rfloor \leq 9$ ,  $1 \leq R_{load} \leq 1000 \Omega$  (loading variables);  $50 \leq Z_0 \leq 1000 \Omega$  (*variable* feed system characteristic impedance). The *fixed* design parameters were  $L_{feed} = 0.02$  m and wire radius  $a = 0.0005$  m (note all dimensions in meters). These values, which are specified by the antenna designer, were determined based on experience.

The bowtie's performance was computed every 100MHz across the band  $800 \leq f_{mhz} \leq 12,000$  ( $f_{mhz}$  being the frequency in megahertz) and the resulting data used to compute the fitness function. The NEC-4 model employed 9 segments in each of the six wires forming the bowtie triangles, and three segments in the feed wire. Gain was computed every 5 degrees from  $0 \leq \theta \leq 90^\circ$  at  $\phi = 0^\circ$  (see [14,15] for coordinate system details). Note that the range for  $L_{load}$  is specified as an integer ratio to  $L_{arm}$  because NEC loads a wire by segment *number* ("LD" cards), not by coordinate. The distance  $L_{arm}$  consequently must be converted to an integer for use in NEC4.

## 5. Bowtie results

Design values for the *Variable*  $Z_0$  CFO-optimized loaded bowtie appear in Fig. 2. Its computed performance from 800 to 12,000 MHz is summarized in Fig. 3. Post-processing extended the frequency range from 200 to 15,000 MHz with data computed every 15 MHz (Appendices II and III contain the computed data). Figures 8 and 11-15 plot the results, and Fig. 16 shows the NEC4 input file. Fig. 17 shows the antenna geometry as visualized using 4nec2 [16(i)] (rectangles are loading resistors). In order to compare *Variable*  $Z_0$  to the traditional methodology, another CFO run was made holding  $Z_0$  constant. The same run parameters and decision space boundaries were employed, except  $50 \leq Z_0 \leq 50 \Omega$  to fix its value. Results of the comparison run appear in Figs. 4 and 5.

As a preliminary matter, the NEC4 model must be validated using the *unloaded* antenna's average free space power gain test (AGT) as discussed at [15, Part I, p. 101]. Radiation patterns were computed from 200 to 15,000 MHz at  $5^\circ$  and  $10^\circ$  increments, respectively, for  $0 \leq \theta \leq 90^\circ$  and  $0 \leq \phi \leq 180^\circ$  with power gain averaged over  $\pi$  steradians. The AGT plot for the *Variable*  $Z_0$  bowtie appears in Fig. 6, and in Fig. 7 for the fixed  $Z_0$  design.

The average power gain for the *Variable*  $Z_0$  bowtie is between about 1.05 and 1.1 over most of the band with a peak near 1.18. Values within 20% of unity usually are considered adequate for model validation, so that in this case there is confidence in the bowtie data throughout the entire frequency range. By comparison, the average gain for the fixed  $Z_0 = 50 \Omega$  design shows a sharp increase above 1.2 for frequencies beyond about 14,000 MHz, so that confidence in those data is considerably less.

The primary objective of this design example is minimizing VSWR, which is plotted for the optimized *Variable*  $Z_0$  antenna in Fig. 8. The bowtie structure computed by CFO was modeled with and without resistive loading and its VSWR computed relative to the optimum CFO-computed feed system  $Z_0$  of  $715 \Omega$ . Interestingly, this value for  $Z_0$ , which was determined as a result of its being *variable* in

$L_{arm}$	0.051 m
$\alpha$	$39.4^\circ$
$\left[ \frac{L_{load}}{L_{arm}} \right]$	6
$L_{load}$	0.03117 m
$R_{load}$	$166.93 \Omega$
$Z_0$	$715 \Omega$

Fig. 2. *Variable*- $Z_0$  CFO-optimized bowtie.

<i>Parameter</i>	<i>Minimum</i>	<i>Maximum</i>
VSWR// $715 \Omega$	1.06	6.43
$R_{in}$	$111.51 \Omega$	$729.32 \Omega$
$X_{in}$	$-286 \Omega$	$335.73 \Omega$
$\mathcal{E}$	24.25 %	98.88 %
$G_{max}$	$-3.34$ dBi	4.71 dBi

Fig. 3. *Variable*- $Z_0$  bowtie performance 800-12,000 MHz.

$L_{arm}$	0.08 m
$\alpha$	30°
$\left[ \frac{L_{load}}{L_{arm}} \right]$	9
$L_{load}$	0.07555
$R_{load}$	1000 $\Omega$
$Z_0$	50 $\Omega$ <i>fixed</i>

Fig. 4. CFO-optimized fixed  $Z_0 = 50 \Omega$  bowtie.

the optimization process, is unusual and quite far from the “standard” values that are much lower (mostly  $\sim 50 \Omega$ ). Of course, impedance-matching the optimized value of  $Z_0$  to a “standard” value, say,  $50 \Omega$ , requires a sufficiently broadband matching network, for example, a broadband transformer, lumped or distributed matching network, tapered transmission line, and so on, with some matching devices being better than others depending on the frequency range.

Fig. 9 plots the fixed  $Z_0$  bowtie’s VSWR, which is much higher than it is for the *Variable*  $Z_0$  antenna across the entire band. At no point is  $VSWR \leq 2:1$ , and for the most part it is  $> 5:1$ . Since IBW is the primary performance measure in this case, this example shows how the *Variable*  $Z_0$  methodology can lead to much better antenna designs because  $Z_0$  then is determined *by* the design or optimization process instead of being assigned a value that cannot change.

<i>Parameter</i>	<i>Minimum</i>	<i>Maximum</i>
VSWR // 50 $\Omega$	2.67	13.58
$R_{in}$	119.38 $\Omega$	676.71 $\Omega$
$X_{in}$	-285.46 $\Omega$	294.05 $\Omega$
$\mathcal{E}$	43.76 %	91.85 %
$G_{max}$	-1.37 dBi	5.14 dBi

Fig. 5. Fixed  $Z_0 = 50 \Omega$  bowtie performance 800-12,000 MHz.

Figure 10 summarizes the *Variable*  $Z_0$  bowtie’s IBW using the commonly employed threshold  $VSWR // Z_0 \leq 2:1$ . The antenna has several low-VSWR bands, two of which would be considered UWB because the fractional bandwidth is greater than 25% of the band’s center frequency,  $f_c$ . The loading resistance has the desired effect of increasing IBW, but it does so at the expense of radiation efficiency as shown in Figure 11. At low frequencies  $\mathcal{E}$  is quite low, and it decreases very quickly with decreasing frequency. But near 3000 MHz  $\mathcal{E}$  exhibits a sharp increase, with very reasonable values at higher frequencies. The unloaded PEC bowtie’s efficiency is 100 % and consequently is not plotted.

Figs. 12 and 13, respectively, plot the *Variable*  $Z_0$  antenna’s input resistance and reactance. As expected, the effect of adding resistive loading is to reduce fluctuations in these variables. Figures 14 and 15 plot the maximum and minimum gains, respectively. As expected, adding resistive loading generally

reduces maximum gain as expected, but, interestingly, it actually increases minimum gain in certain frequency ranges.




Fig.6. Variable- $Z_0$  bowtie NEC4 AGT plot ( $Z_0 = 715 \Omega$ ).




Fig.7. Fixed- $Z_0$  bowtie NEC4 AGT plot ( $Z_0 = 50 \Omega$ ).




Fig.8. Variable- $Z_0$  bowtie VSWR ( $Z_0 = 715\ \Omega$ ).




Fig.9. Fixed- $Z_0$  bowtie VSWR ( $Z_0 = 50\ \Omega$ ).



<i>Resistively Loaded</i>			<i>No Loading</i>		
Band Limits (MHz)	Width (MHz)	% of $f_c$	Band Limits (MHz)	Width (MHz)	% of $f_c$
1655-1865	210	11.9%	1685-2030	345	18.6%
3185-5210	2025	48.2%	3185-3860	675	18.9%
6365-8345	1980	26.9%	4460-5375	915	18.6%
11420-11675	255	2.21%	6260-7025	765	11.52%
-	-	-	7955-8555	600	7.27%
-	-	-	9395-9740	345	3.6%
-	-	-	11510-11765	255	2.19%

Fig.10. Variable- $Z_0$  bowtie VSWR//715  $\Omega \leq 2:1$  bands ( $f_c$ =band center).




Fig.11. Variable- $Z_0$  Resistively loaded bowtie radiation efficiency.




Fig.12. Variable- $Z_0$  bowtie input resistance.




Fig. 13. Variable- $Z_0$  bowtie input reactance.




Fig. 14. Variable- $Z_0$  bowtie maximum power gain.




Fig. 15. Variable- $Z_0$  bowtie minimum power gain.

```

CM File: BESTBOWTIE.NEC
CM R-LOADED BOWTIE IN FREE SPACE WITH
CM Zo AS AN OPTIMIZATION PARAMETER.
CM Antenna in Y-Z plane.
CM Run ID: 07022011_221747
CM Fitness function:
CM [Min(Eff)+5*Min(Gmax)]/[|Zo-MaxRin|*(MaxVSWR-MinVSWR)*(MaxXin-MinXin)]
CM Arm Length = .051 meters
CM Bowtie HALF Angle = 39.4 degrees
CM Zo = 715 ohms
CM Rload = 166.93 ohms
CM Loaded Seg # = 6/9
CM File ID 07032011225840
CM Nd = 5, p = 1, j = 35
CE
GW1,3,0.,-.01,0.,0.,.01,0.,.0005
GW2,9,0.,.01,0.,0.,.049,.032,.0005
GW3,9,0.,.01,0.,0.,.049,-.032,.0005
GW4,9,0.,.049,.032,0.,.049,-.032,.0005
GW5,9,0.,-.01,0.,0.,-.049,.032,.0005
GW6,9,0.,-.01,0.,0.,-.049,-.032,.0005
GW7,9,0.,-.049,.032,0.,-.049,-.032,.0005
GE
LD0,2,6,6,166.93,0.,0.
LD0,3,6,6,166.93,0.,0.
LD0,5,6,6,166.93,0.,0.
LD0,6,6,6,166.93,0.,0.
FR 0,1001,0,0,200.,15.
EX 0,1,2,1,1,0.
RP 0,19,1,1001,0.,0.,5.,0.,100000.
EN

```

Fig. 16. Variable- $Z_0$  bowtie NEC4 input file.




Fig. 17. Variable- $Z_0$  bowtie 4nec2 geometry display.

## 6. Design example: broadband Yagi-Uda arrays

The second *Variable  $Z_0$*  design example is two 6-element Yagi-Uda (“Yagi”) arrays. A Yagi comprises a single center-fed dipole driven element (DE), one or more reflectors (REF) on one side of DE (usually only one), and a group of directors on the other side (often many). DE is excited by the RF source, and all other elements are parasitic. Fig. 18 shows the array geometry as visualized by 4nec2 for Yagi design #1 (red circle is the RF source). All elements are parallel to the y-axis with the reflector on the axis. If the element radius is fixed (usually the same value for all elements), there are 11 geometric design variables, the 5 element spacings and their 6 lengths. Of course, in this case there is a twelfth design

variable, viz.,  $Z_0$ . Fixing the element radius is an example of the traditional methodology in which certain design parameters are fixed at the outset, so that their values are not determined by the methodology. Fig. 19 shows the NEC4 input file for this antenna.




Fig. 18. 4nec2 geometry display for Variable- $Z_0$  6-element Yagi design #1.

```

CM File: YAGI.NEC
CM YAGI ARRAY IN FREE SPACE
CM Band center frequency, Fc = 299.8 MHz
CM Run ID: 07102011_205004
CM Fitness function:
CM Gfwd(L)/5-2*VSWR(L)+Gfwd(M)-4*VSWR(M)+Gfwd(U)-2*VSWR(U)/5
CM where L,M,U are lower/mid/upper frequencies
CM Zo=65.75 ohms
CM File ID 07122011125139
CM Nd= 13, p= 20, j= 160
CE
GW1,9,0.,-.234,0.,0.,.234,0.,.00635
GW2,9,.343,-.228,0.,.343,.228,0.,.00635
GW3,9,.54,-.19,0.,.54,.19,0.,.00635
GW4,9,.827,-.186,0.,.827,.186,0.,.00635
GW5,9,1.137,-.184,0.,1.137,.184,0.,.00635
GW6,9,1.41,-.189,0.,1.41,.189,0.,.00635
GE
FR 0,1501,0,0,200.,.1
EX 0,2,5,1,1,0.
RP 0,19,19,1001,0.,0.,5.,10.,100000.
EN

```

Fig. 19. Variable- $Z_0$  Yagi design #1 NEC4 input file.

The antenna was CFO-optimized against the following fitness function (to be maximized):

$$F(Z_0, L_i, S_j) = c_1 \cdot G_{fwd}(f_L) - c_2 \cdot VSWR(f_L) + c_3 \cdot G_{fwd}(f_C) - c_4 \cdot VSWR(f_C) + c_5 \cdot G_{fwd}(f_U) - c_6 \cdot VSWR(f_U)$$

$L_i$ ,  $i = 1, \dots, 6$  and  $S_j$ ,  $j = 1, \dots, 5$  are the element lengths and spacings, respectively. The constants  $c_i$  are empirically determined weighting coefficients;  $G_{fwd}(f)$  the Yagi's forward directivity (along the +X-

axis,  $\theta = 90^\circ, \phi = 0^\circ$ ); and  $f_L, f_C,$  and  $f_U,$  respectively, the lower, center, and upper frequencies defining the band within which the Yagi is optimized.

The same CFO parameters that were used for the loaded bowtie were used for the two Yagi designs, but with  $\max\left(\frac{N_p}{N_d}\right) = 6$  for both antennas, and with  $N_i = 250, N_i = 200$  for the first and second designs, respectively. Note that, although the Yagi problem contains 12 design *variables*, as a matter of programming convenience in dealing with array dimensions, CFO treats the problem as 13-D. The Yagi element REF is assigned a fixed “spacing” of zero because it is placed on the Y-axis, and this is the 13<sup>th</sup> “variable” (see the source code listing in Appendix I for details). For Yagi design #1, CFO’s best fitness was 14.62534041 (CFO probe #20) with  $\frac{N_p}{N_d} = 4$  and  $\gamma = 0.6$  at step 160, while for design #2 it was 0.93193733 (probe #28) with  $\frac{N_p}{N_d} = 4$  and  $\gamma = 0.2$  at step 168.

The decision space was  $0.2 \leq L_i \leq 0.6\lambda, 0.1 \leq S_j \leq 0.5\lambda,$  where  $\lambda$  is the wavelength corresponding to the band center frequency  $f_C.$  The *variable* feed system impedance was bounded by  $5 \leq Z_0 \leq 600 \Omega.$  The first Yagi was optimized over the band 275-325 MHz and the second over 250-350 MHz (in both cases  $\lambda \approx 1\text{m} @ f_C$ ). In post processing, performance was computed from 200-350 MHz every 0.1 MHz. All array elements have the same radius  $0.00635\lambda$  (0.5-inch diameter elements at 299.8 MHz). In the NEC4 model, lengths were rounded to three decimal places (except radius) and  $Z_0$  to two. The fitness weighting coefficients are tabulated in Fig. 20.

Design #	$c_1$	$c_2$	$c_3$	$c_4$	$c_5$	$c_6$
1	0.2	2	1	4	1	0.4
2	0.2	4	1	8	1	0.8

Fig. 20. Variable- $Z_0$  Yagi fitness coefficients.

Fig. 21 plots the evolution of CFO’s best fitness for design #1, while Fig. 22 shows the convergence of CFO’s probes onto the maximum ( $D_{avg}$  is the average distance between the probe with the best fitness and all other probes). The best probe number as a function of time step appears in Fig. 23. These results are typical of CFO’s behavior, both on antenna problems and on established benchmark functions (see, for example, [25-27]).

The optimum feed system impedance computed by CFO was  $Z_0 = 65.75 \Omega$  for design #1 and  $Z_0 = 89.88 \Omega$  for design #2. Although Yagi arrays are generally considered “low” impedance antennas (typically  $Z_{in} \approx 10 - 30 \Omega$ ), the optimized feed system  $Z_0$ ’s are relatively high. These values, however, are more readily matched to the “standard” values of  $50 - 75 \Omega,$  which is a fortuitous outcome. The optimized array geometry is tabulated in Fig. 24. The spacings have been added to specify each element’s position ( $X -$  coordinate, “boom dist”) along the Yagi’s boom ( $+ X -$  axis).




Fig. 21. Variable- $Z_0$  CFO fitness evolution for Yagi design #1.




Fig. 22. Variable- $Z_0$  CFO  $D_{avg}$  evolution for Yagi design #1.




Fig. 23. Variable- $Z_0$  CFO best probe evolution for Yagi design #1.

element #	design #1 ( $Z_0 = 65.75 \Omega$ )		design #2 ( $Z_0 = 89.88 \Omega$ )	
	length ( $\lambda$ )	boom dist ( $\lambda$ )	length ( $\lambda$ )	boom dist ( $\lambda$ )
1(REF)	0.468	0	0.564	0
2 (DE)	0.456	0.343	0.500	0.305
3	0.380	0.540	0.370	0.434
4	0.372	0.827	0.360	0.715
5	0.368	1.137	0.364	0.921
6	0.378	1.410	0.344	1.238

Fig. 24. Geometry of Variable- $Z_0$  CFO-optimized Yagi arrays.

VSWR curves for the Variable  $Z_0$  optimized Yagis appear in Fig. 25 (note,  $0.994 \leq \text{AGT} \leq 0.998$  not plotted). For design #1,  $\text{VSWR} // 65.75\Omega \leq 2:1$  from 273.5 MHz to 319.6 MHz and from 329.3 MHz to 333.8 MHz with a peak of 2.2:1 between these bands at 324.8 MHz. As a practical matter, the 2:1 VSWR IBW can be reasonably considered to be 273.5-333.8 MHz (60.3 MHz) centered on 303.65 MHz, resulting in an IBW of 19.86%. This bandwidth is quite large for a Yagi, which usually is thought of as “narrowband” structure (typically, IBW of a few percent).

The performance of design # 2 is even better. Its VSWR is less than 2:1 from 249.7 to 322.7 MHz (73 MHz) centered at 286.2 MHz for an IBW of 25.5%, which is quite remarkable because this erstwhile “narrowband” device actually exhibits **UWB** performance without any impedance loading or other measures to increase bandwidth. Of course, for these two designs, matching the optimized feed system impedances of  $Z_0 = 65.75 \Omega$  and  $Z_0 = 89.88 \Omega$  to the usual  $50 \Omega$  requires 1.32:1 and 1.8:1 broadband transformers, respectively (or other suitable matching device).

These interesting results highlight another consideration in antenna design, the effect of different fitness functions on the resulting antenna. Any change in the objective function, however slight, changes the decision space landscape, and, consequently, the “optimum” antenna in that new landscape. The



question is, How to specify an objective function that actually meets specific performance objectives?, a conundrum not easily answered. The best way to address it is with a *deterministic* optimizer instead of a *stochastic* one. Deterministic algorithms like CFO return the same result for every run with the same setup parameters, while stochastic metaheuristics, ACO or PSO, for example, yield different results with every run because they rely on variables whose values are unknowable in advance of their being calculated from a probability distribution.

The only way the antenna designer can know that changing the fitness function actually produced a better antenna, instead of being the result of an optimizer's inherent stochasticity, is by using a deterministic algorithm. If this run's Yagi is better than the last, is it because of those new coefficients, or, instead, luck of the draw? There simply is no way to know. The flip side is that a genuinely better objective function might produce a worse antenna if it is used with a stochastic optimizer.

Deterministic metaheuristics such as CFO are much better suited to real world problems like designing antennas, an issue discussed at greater length in [25] by way of an example (resistively loaded monopole). In the Yagi designs considered here, changing the fitness coefficients slightly produced significantly different antennas. Yet another set of coefficients will yield yet another optimal design, and a different fitness function altogether will result in possibly quite different antennas. In this regard, the *Variable  $Z_0$*  methodology is advantageous because it provides additional flexibility in meeting specific performance goals by creating a decision landscape with one more degree of freedom, a landscape that should be searched deterministically.




Fig. 25. *Variable- $Z_0$  CFO-optimized Yagi VSWR// $Z_0$ .*

Figs. 26-28, respectively, plot the two Yagis'  $G_{fwd}$ ,  $R_{in}$ , and  $X_{in}$ . The gain for design #1 increases monotonically from 8.29 dBi at 273.5MHz to 11.96 dBi at 333.8 MHz with a band-center gain of 9.73 dBi at 303.15 MHz. The corresponding values for design #2 are 7.66 dBi at 249.7 MHz, 9.5 dBi at 322.7 MHz, and 7.39 dBi at 286.2 MHz; and the gain is flatter than for design #1. These figures are quite good for a Yagi array with such large IBW. For example, the "A3" wideband Yagi design reported in [28] has  $VSWR//50\ \Omega \leq 2:1$  from 262.5-309.8 MHz centered at 286.15 MHz (IBW 16.53%) with a maximum

in-band  $G_{fwd}$  of 10.24 dBi as computed by NEC4. This antenna was optimized using the traditional approach of *fixing*  $Z_0$  at  $50 \Omega$  with a deterministic optimizer (DCLS). While the *Variable*  $Z_0$  Yagis and the DCLS-optimized array cannot be compared “head-to-head” because different optimization objectives were used, their performances can be compared as being representative of the state-of-the-art for broadband array design. This comparison clearly shows that the *Variable*  $Z_0$  approach can produce better antennas.

Turning to the input impedance,  $R_{in}$  is moderate across the band for both Yagis, but large fluctuations begin to appear at the high end.  $X_{in}$  also is moderate and increases monotonically across the band, almost linearly. Each Yagi exhibits a single resonance, design #1 at 301.05 MHz and design #2 at 274.7 MHz.




Fig. 26. *Variable- $Z_0$*  CFO-optimized Yagi  $G_{fwd}$ .

## 7. Conclusion

This paper describes *Variable*  $Z_0$ , which, to the author’s knowledge, is a novel and proprietary methodology for antenna design and optimization. As an example, *Variable*  $Z_0$  is applied to designing a CFO-optimized resistively-loaded bowtie antenna and two broadband Yagi-Uda arrays, both with good results. The resulting bowtie exhibits UWB properties in two bands useful for UWB systems, and one of the Yagis is UWB without any broadbanding mechanism such as impedance-loading. The performance of the *Variable*  $Z_0$  Yagis compares very favorably to another state-of-the-art deterministically optimized array.




Fig. 27. Variable- $Z_0$  CFO-optimized Yagi  $R_{in}$ .




Fig. 28. Variable- $Z_0$  CFO-optimized Yagi  $X_{in}$ .

## References

1. Zehforoosh, Y., Ghobadi, C., and Nourinia, J., "Antenna Design for Ultra Wideband Application Using a New Multilayer Structure," *PIERS Online*, vol. 2, no. 6, 2006, pp. 544-549.
2. Hoorfar, A., "Evolutionary Programming in Electromagnetic Optimization: A Review," *IEEE Transactions on Antennas and Propagation*, vol. 55, no. 3, March 2007, pp. 523-537.
3. Hashemi, S. M., Nayyeri, V., Soleimani, M., and Mallahzadeh, A-R., "Designing a Compact-Optimized Planar Dipole Array Antenna," *IEEE Antennas and Wireless Propagation Letters*, Vol. 10, 2011, pp. 243-246.
4. Yilmaz, O. N. C., Hamalainen, S., and Hamalainen, J., "Analysis of Antenna Parameter Optimization Space for 3 GPP LTE," *IEEE 70<sup>th</sup> Vehicular Technology Conference Fall (VTC 2009-Fall)*, 2009, pp. 1-5 (doi: 10.1109/VETECE.2009.5379077)
5. Boryssenko, A. O., "Taxonomical and Heuristic Studies on UWB Antenna Design Strategies," *High Frequency Electronics Magazine*, August 2009, pp. 38-48.
6. Tawk, Y., Kabalan, K. Y., El-Hajj, A., Christodoulou, C. G., and Costantine, J., "A Simple Multiband Printed Bowtie Antenna," *IEEE Antennas and Wireless Propagation Letters*, Vol. 7, 2008, pp. 557-560.
7. Kiminami, K., Hirata, A., and Shiozawa, T., "Double-Sided Printed Bow-Tie Antenna for UWB Communications," *IEEE Antennas and Wireless Propagation Letters*, Vol. 3, 2004, pp. 152-153.
8. Chen, Y.-L., Ruan, C.-L., and Peng, L., "A Novel Ultra-Wideband Bow-Tie Slot Antenna in Wireless Communication Systems," *Progress in Electromagnetics Research Letters*, Vol. 1, 101-108, 2008.
9. Kim, Y.-G., Woo, D.-S., Kim, K. W., and Cho, Y.-K., "Design of Bow-Tie-Type UWB Antennas Using an Ultra-wideband Balun," *IEEE 2007 Antennas and Propagation Society International Symposium*, pp. 1989-1992, (doi: 10.1109/APS.2007.4395913)
10. Li, C. M., and Ye, L. H., "Improved Dual Band-Notched UWB Slot Antenna with Controllable Notched Bandwidths," *Progress in Electromagnetics Research*, vol. 115, 477-493, 2011.
11. Li, J.-F., Sun, B.-H., and Liu, Q.-Z., "PSO-Based Fast Optimization Algorithm for Broadband Array Antenna by Using the Cubic Spline Interpolation," *Progress in Electromagnetics Research Letters*, Vol. 4, 173-181, 2008.
12. Jolani, F., Dadashzadeh, G., Naser-Moghadasi, M., and Dadgarpour, A., "Design and Optimization of Compact Balanced Antipodal Vivaldi Antenna," *Progress in Electromagnetic Research C*, Vol. 9, 183-192, 2009.
13. Formato, R. A., "New Techniques for Increasing Antenna Bandwidth with Impedance Loading," *Progress in Electromagnetics Research B*, Vol. 29, 269-288, 2011.
14. Burke, G. J., and Poggio, A. J., "Numerical Electromagnetics Code (NEC) – Method of Moments," Parts I, II and III, January 1981, UCID-19934, Lawrence Livermore National Laboratory, Livermore, California, USA
15. Burke, G. J., "Numerical Electromagnetics Code – NEC-4, Method of Moments, Part I: User's Manual and Part II: Program Description – Theory," January 1992, UCRL-MA-109338, Lawrence Livermore National Laboratory, Livermore, California, USA  
(<https://ipo.llnl.gov/technology/software/softwaretitles/nec.php>).
16. (i) "4nec2" antenna modeling freeware by Arie Voors, available online at <http://home.ict.nl/~arivoors/>. (ii) Unofficial Numerical Electromagnetic Code (NEC) Archives, online at <http://www.si-list.net/swindex.html>
17. Formato, R. A., "Central Force Optimization: A New Metaheuristic with Applications in Applied Electromagnetics," *Prog. Electromagnetics Research*, vol. PIER 77, pp. 425-491, 2007:  
<http://www.jpier.org/pier/pier.php?paper=07082403>  
(doi:10.2528/PIER07082403).
18. Kennedy, J., and Eberhart, R., "Particle Swarm Optimization," *Proc. IEEE Conf. On Neural Networks*, 4 (Nov/Dec), 1942-1948, 1995.
19. Dorigo, M., Maniezzo, V., and Coloni, A., "Positive feedback as a search strategy," Dipartimento di Elettronica, Politecnico di Milano, Italy, Tech. Rep. 91-016, 1991: [http://iridia.ulb.ac.be/~mdorigo/pub\\_x\\_subj.html](http://iridia.ulb.ac.be/~mdorigo/pub_x_subj.html)
20. He, S., Wu, Q. H., Saunders, J. R., "Group Search Optimizer: An Optimization Algorithm Inspired by Animal Searching Behavior," *IEEE Trans. Evol. Computation*, vol. 13, no. 5, pp. 973-990, Oct. 2009.
21. A. Chowdhury, A. Ghosh, R. Giri, and S. Das, "Optimization of Antenna Configuration with a Fitness-adaptive Differential Evolution Algorithm," *Progress In Electromagnetics Research B*, Vol. 26, 291-319, 2010.

22. Formato, R. A., "Parameter-Free Deterministic Global Search with Simplified Central Force Optimization," in **Advanced Intelligent Computing Theories and Applications (ICIC2010)**, Lecture Notes in Computer Science (D.-S. Huang, Z. Zhao, V. Bevilacqua and J. C. Figueroa, Eds.), LNCS 6215, pp. 309–318, Springer-Verlag Berlin Heidelberg, 2010.
23. Formato, R. A., "Improved CFO Algorithm for Antenna Optimization," *Prog. Electromagnetics Research B*, pp. 405-425, 2010. <http://www.jpier.org/pierb/pier.php?paper=09112309> (doi:10.2528/PIERB09112309).
24. Formato, R. A., "Central Force Optimization with Variable Initial Probes and Adaptive Decision Space," *Applied Mathematics and Computation*, Vol. 217, 2011, pp. 8866-8872.
25. Formato, R. A., "Issues in Antenna Optimization – A Monopole Case Study," March, 2011. <http://arXiv.org/abs/1103.5629>.
26. Formato, R. A., "Central Force Optimization Applied to the PBM Suite of Antenna Benchmarks," Feb., 2010. <http://arXiv.org/abs/1003.0221>.
27. Formato, R. A., "Comparative Results: Group Search Optimizer and Central Force Optimization," Feb., 2010. <http://arXiv.org/abs/1002.2798>.
28. Lisboa, A. C., Vieira, D. A. G., Vasconcelos, J. A., Saldanha, R. R., and Takahashi, R. H. C., "Monotonically Improving Yagi-Uda Conflicting Specifications Using the Dominating Cone Line Search Method," *IEEE Trans. Magnetics*, vol. 45, no. 3, March 2009, pp. 1494-1497.

*14 July 2011*  
*Brewster, Massachusetts*

© 2011 Richard A. Formato  
*All rights reserved worldwide.*

# Appendix I

```
'Program 'CFO_R_ONLY_LOADED_BOWTIE_YAGI_07-10-2011.BAS'
'Compiled with Power Basic/Windows Compiler 9.04.0122 (www.PowerBasic.com).

'CFO-OPTIMIZED R-LOADED (1 RESISTOR/ARM) BOWTIE IN FREE SPACE AND
'FS YAGI-UDA ARRAY BOTH WITH Zo AS AN OPTIMIZATION <<<VARIABLE>>>.

'LAST MOD 07-10-2011 ~2049 HRS EDT

'***** YAGI FITNESS FUNCTION *****
'THE USER CAN USE THE FOLLOWING FITNESS FUNCTION:
' F=[A*FwdGain(Db1)-B*|Zo-Max(Rin)|-
' C*Max|Xin|-D*(MaxVSWR-MinVSWR)]/(A+B+C+D)
'WHERE THE COEFFICIENTS A, B, and C are USER-SPECIFIED IN THE FILE
'YagiCoeff.TXT. THIS FILE MUST CONTAIN FOUR LINES WITH A, B, C,
'AND D, RESPECTIVELY, ON ONE LINE EACH. IF THE FILE DOES NOT
'EXIST, A DEFAULT FILE IS CREATED WITH A=20, B=2, C=3, D=4.
'OR, SOME OTHER FITNESS MAY BE HARDWIRED IN THE YAGI FUNCTION.
'CHECK THE SOURCE LISTING TO SEE WHICH IS BEING USED.

'***** YAGI CFO SETUP PARAMETERS *****
'THE TEXT FILE YAGI_CFO.CFG CONTAINS THREE CFO SETUP PARAMETERS:
' NT& (# time steps)
' NumGammas(# gamma values)
' MaxProbesPerDimension% (max # probes/dim on probe lines)
'EACH ONE MUST BE ENTERED AS A NUMBER ON A SEPARATE LINE. IF THE
'FILE YAGI_CFO.CFG DOES NOT EXIST, A DEFAULT VERSION IS CREATED.
'THIS APPLIES ONLY TO THE YAGI MODEL. OTHER BUILT-IN BENCHMARK
'FUNCTIONS USE THE HARDWIRED INTERNAL VALUES FOR THESE PARAMETERS.

'***** IMPORTANT MODELING NOTE *****
'THE YAGI ELEMENT SEGMENT LENGTH IN NEC CAN BE VARIABLE OR FIXED.
'IF FIXED, THEN THE NUMBER OF SEGMENTS VARIES FROM ONE ELEMENT TO
'THE NEXT, BUT ALL SEGMENTS ARE PERFECTLY ALIGNED, WHICH, AS A
'GENERAL RULE IS RECOMMENDED IN THE NEC MODELING GUIDELINES. BUT
'EXPERIENCE SUGGESTS THAT THIS IS NOT NECESSARILY THE BEST
'APPROACH UNDER ALL CIRCUMSTANCES, SO VARIABLE LENGTH SEGMENTS
'ARE ALLOWED AS WELL. SEGMENTATION MUST BE VALIDATED USING THE
'NEC-RECOMMENDED AGT TEST. THE SETUP FILE 'YagiSeg.TXT' CONTAINS
'TWO LINES. THE FIRST IS EITHER THE WORD 'VARIABLE' (NO QUOTES)
'OR THE WORD 'FIXED' WHICH DETERMINES WHETHER VARIABLE LENGTH OR
'FIXED LENGTH SEGMENTS ARE USED. THE NEXT LINE IS THE SEGMENT
'LENGTH IN WAVELENGTHS (RANGE 0.02-0.2). THIS FILE WILL BE
'CREATED IF IT DOES NOT EXIST USING VARIABLE SEGMENT LENGTH AS
'THE DEFAULT WITH 9 SEGMENTS PER ARRAY ELEMENT. NOTE THAT IF
'FIXED SEGMENT LENGTH IS USED, EACH ELEMENT'S PHYSICAL LENGTH
'IS ADJUSTED TO BE AN INTEGER NUMBER OF SEGMENTS IN ORDER TO
'ALIGN EVERY SEGMENT.

'***** BOWTIE FITNESS FUNCTION *****
'THE HARDWIRED BOWTIE FITNESS FUNCTION IS:
'F=[Min(EFF)+5*Min(Gmax)]*{|Zo-Max(Rin)|}^{|Max(VSWR)-Min(VSWR)}*
' |Max(Xin)-Min(Xin)|}

'***** BOWTIE CFO SETUP PARAMETERS *****
'THE TEXT FILE BOWTIE_CFO.CFG CONTAINS THREE CFO SETUP PARAMETERS:
' NT& (# time steps)
' NumGammas(# gamma values)
' MaxProbesPerDimension% (max # probes/dim on probe lines)
'EACH ONE MUST BE ENTERED AS A NUMBER ON A SEPARATE LINE. IF THE
'FILE BOWTIE_CFO.CFG DOES NOT EXIST, A DEFAULT VERSION IS CREATED.
'THIS APPLIES ONLY TO THE BOWTIE MODEL. OTHER BUILT-IN BENCHMARK
'FUNCTIONS USE THE HARDWIRED INTERNAL VALUES FOR THESE PARAMETERS.

'=====
'NOTE: ALL PBM FUNCTIONS HAVE WIRE RADIUS SET TO 0.00001 LAMBDA
'=====

'THIS PROGRAM IMPLEMENTS A SIMPLE VERSION OF "CENTRAL
'FORCE OPTIMIZATION." IT IS DISTRIBUTED FREE OF CHARGE
'TO INCREASE AWARENESS OF CFO AND TO ENCOURAGE EXPERI-
'MENTATION WITH THE ALGORITHM.

'CFO IS A MULTIDIMENSIONAL SEARCH AND OPTIMIZATION
'ALGORITHM THAT LOCATES THE GLOBAL MAXIMA OF A FUNCTION.
'UNLIKE MOST OTHER ALGORITHMS, CFO IS COMPLETELY DETERMIN-
'ISTIC SO THAT EVERY RUN WITH THE SAME SETUP PRODUCES
'THE SAME RESULTS.

'(c) 2006-2011 Richard A. Formato

'ALL RIGHTS RESERVED WORLDWIDE

'THIS PROGRAM IS FREWARE. IT MAY BE COPIED AND
'DISTRIBUTED WITHOUT LIMITATION AS LONG AS THIS
'COPYRIGHT NOTICE AND THE GNUPLOT AND REFERENCE
'INFORMATION BELOW ARE INCLUDED WITHOUT MODIFICATION,
'AND AS LONG AS NO FEE OR COMPENSATION IS CHARGED.
'INCLUDING "TIE-IN" OR "BUNDLING" FEES CHARGED FOR
'OTHER PRODUCTS.

'=====
'THIS PROGRAM REQUIRES wgnuplot.exe TO DISPLAY PLOTS.
'Gnuplot is a copyrighted freeware plotting program
'available at http://www.gnuplot.info/index.html.

'IT ALSO REQUIRES A VERSION OF THE Numerical Electromagnetics
'Code (NEC) in order to run the PBM benchmarks, Bowtie and Yagi
'antenna models. If this file is not present, a runtime error
'occurs. Remove the code that checks for the NEC EXE if there
'is no interest in the these functions.

'=====
'CFO REFERENCES (author: Richard A. Formato unless otherwise noted)

'"A Novel Methodology for Antenna Design and Optimization: Variable Zo," July 2011, http://arxiv.org/abs/1107.1437.

'"Central Force Optimization with Variable Initial Probes and Adaptive Decision Space," Applied Mathematics and Computation,
'vol. 217, 2011, pp. 8866-8872, 2011.

'"New Techniques for Increasing Antenna Bandwidth with Impedance Loading," Progress In Electromagnetics Research B, vol. 29, pp. 269-288, 2011,
'http://www.jpier.org/pierb/pier.php?paper=11021904.

'"Parameter-Free Deterministic Global Search with Simplified Central Force Optimization," in Advanced Intelligent Computing Theories and
'Applications (ICIC2010), Lecture Notes in Computer Science (D.-S. Huang, Z. Zhao, V. Bevilacqua and J. C. Figueroa, Eds.), LNCS 6215, pp. 309-318,
'Springer-Verlag Berlin Heidelberg, 2010 [book chapter].

'"Antenna Benchmark Performance and Array Synthesis using Central Force Optimization," IET (U.K.) Microwaves, Antennas & Propagation vol. 4, no. 5,
'pp. 583-592, 2010. (doi: 10.1049/iet-map.2009.0147). [with G. M. Qubati and N. I. Dib].

'"Improved CFO Algorithm for Antenna Optimization," Prog. Electromagnetics Research B, pp. 405-425, 2010
'http://www.jpier.org/pierb/pier.php?paper=09112309 (doi:10.2528/PIERB09112309).
```

"Central Force Optimization and NEOS - First Cousins?," Journal of Multiple-Valued Logic and Soft Computing, vol. 16, pp. 547-565, 2010.

"Convergence Analysis and Performance of the Extended Artificial Physics Optimization Algorithm," Applied Mathematics and Computation (in press) [with L. Xie and J. Zeng].

"Central Force Optimization with Variable Initial Probes and Adaptive Decision Space," Applied Mathematics and Computation, July 2011.

"High-Performance Indoor VHF-UHF Antennas: Technology Update Report," National Association of Broadcasters (NAB), FASTROAD (Flexible Advanced Services For Television and Radio On All Devices), Technology Advocacy Program, 15 May 2010 [with M. W. Cross and E. Merulla] <http://www.nabfastroad.org/NABHighPerformanceIndoorTVAntennaRpt.pdf>

"Central Force Optimisation: a New Gradient-Like Metaheuristic for Multidimensional Search and Optimisation," Int. J. Bio-Inspired Computation, vol. 1, no. 4, pp. 217-238, 2009. (doi: 10.1504/IJBIC.2009.024721).

"Central Force Optimization: A New Deterministic Gradient-Like Optimization Metaheuristic," OPSEARCH, Journal of the Operations Research Society of India, vol. 46, no. 1, pp. 25-51, 2009. (doi: 10.1007/s12597-009-0003-4).

"Central Force Optimization: A New Computational Framework for Multidimensional Search and Optimization," in Nature Inspired Cooperative Strategies for Optimization (NICSO 2007), Studies in Computational Intelligence 129 (N. Krasnogor, G. Nicosia, M. Pavone, and D. Pelta, Eds.), vol. 129, Springer-Verlag, Heidelberg, 2008 [book chapter].

"Central Force Optimization: A New Metaheuristic with Applications in Applied Electromagnetics," Prog. Electromagnetics Research, vol. PIER 77, pp. 425-491, 2007: <http://www.jpier.org/pier/pier.php?paper=07082403> (doi:10.2528/PIER07082403).

"Are Near Earth Objects the Key to Optimization Theory?," Dec., 2009. <http://arxiv.org/abs/0912.1394>.

"Pseudorandomness in Central Force Optimization," Jan., 2010. <http://arxiv.org/abs/1001.0317>.

"Central Force Optimization Applied to the PBM Suite of Antenna Benchmarks," Feb., 2010, <http://arxiv.org/abs/1003.0221>.

"On the Utility of Directional Information for Repositioning Errant Probes in Central Force Optimization," May, 2010, <http://arxiv.org/abs/1005.5490>.

"Issues in Antenna Optimization - A Monopole Case Study," Mar., 2011. <http://arxiv.org/abs/1103.5629>.

"Central Force Optimization with Variable Initial Probes and Adaptive Decision Space," Applied Mathematics and Computation, vol. 217, 2011, pp. 8866-8872.

```

=====
#COMPILE EXE
#DIM ALL
#USEMACROS = 1
#include "win32API.inc"
DEFEXT A-Z
'----- EQUATES -----
%IDC_FRAME1 = 101
%IDC_FRAME2 = 102
%IDC_Function_Number1 = 121
%IDC_Function_Number2 = 122
%IDC_Function_Number3 = 123
%IDC_Function_Number4 = 124
%IDC_Function_Number5 = 125
%IDC_Function_Number6 = 126
%IDC_Function_Number7 = 127
%IDC_Function_Number8 = 128
%IDC_Function_Number9 = 129
%IDC_Function_Number10 = 130
%IDC_Function_Number11 = 131
%IDC_Function_Number12 = 132
%IDC_Function_Number13 = 133
%IDC_Function_Number14 = 134
%IDC_Function_Number15 = 135
%IDC_Function_Number16 = 136
%IDC_Function_Number17 = 137
%IDC_Function_Number18 = 138
%IDC_Function_Number19 = 139
%IDC_Function_Number20 = 140
%IDC_Function_Number21 = 141
%IDC_Function_Number22 = 142
%IDC_Function_Number23 = 143
%IDC_Function_Number24 = 144
%IDC_Function_Number25 = 145
%IDC_Function_Number26 = 146
%IDC_Function_Number27 = 147
%IDC_Function_Number28 = 148
%IDC_Function_Number29 = 149
%IDC_Function_Number30 = 150
%IDC_Function_Number31 = 151
%IDC_Function_Number32 = 152
%IDC_Function_Number33 = 153
%IDC_Function_Number34 = 154
%IDC_Function_Number35 = 155
%IDC_Function_Number36 = 156
%IDC_Function_Number37 = 157
%IDC_Function_Number38 = 158
%IDC_Function_Number39 = 159
%IDC_Function_Number40 = 160
%IDC_Function_Number41 = 161
%IDC_Function_Number42 = 162
%IDC_Function_Number43 = 163
%IDC_Function_Number44 = 164
%IDC_Function_Number45 = 165
%IDC_Function_Number46 = 166
%IDC_Function_Number47 = 167
%IDC_Function_Number48 = 168
%IDC_Function_Number49 = 169
%IDC_Function_Number50 = 170
'----- GLOBAL CONSTANTS & SYMBOLS -----
GLOBAL YagiSegmentLength$, YagiCoefficients$
GLOBAL NumYagiElements% 'added 05/12/2011 instead of passing in function call
GLOBAL YAGIsecsPerRun, YagiSegmentLengthWln, YagiFitnessCoefficients() AS EXT
GLOBAL BowtieSegmentLength$, BowtieCoefficients$
GLOBAL NumBowtieElements% 'added 05/12/2011 instead of passing in function call
GLOBAL BOWTIEsecsPerRun, BowtieSegmentLengthWln, BowtieFitnessCoefficients() AS EXT
GLOBAL XiOffset() AS EXT 'offset array for Rosenbrock F6 function
GLOBAL XiMin(), XiMax(), DiagLength, StartingXiMin(), StartingXiMax() AS EXT 'decision space boundaries, length of diagonal
GLOBAL Aij() AS EXT 'array for Shekel's Foxholes function
GLOBAL EulerConst, Pi, Pi2, Pi4, TwoPi, FourPi, e, Root2 AS EXT 'mathematical constants
GLOBAL Alphabet$, Digits$, RunID$ 'upper/lower case alphabet, digits 0-9 & Run ID

```

```

GLOBAL Quote$, SpecialCharacters$ 'quotation mark & special symbols
GLOBAL Mu0, Eps0, c, eta0 AS EXT 'E&M constants
GLOBAL Rad2Deg, Deg2Rad, Feet2Meters, Meters2Feet, Inches2Meters, Meters2Inches AS EXT 'conversion factors
GLOBAL Miles2Meters, Meters2Miles, NautMi2Meters, Meters2NautMi AS EXT 'conversion factors
GLOBAL Screenwidth&, ScreenHeight& 'screen width & height
GLOBAL xoffset&, yoffset& 'offsets for probe plot windows
GLOBAL FunctionNumber%
GLOBAL AddNoiseToPBM2$

```

```

'----- TEST FUNCTION DECLARATIONS -----

```

```

DECLARE FUNCTION F1(R(),Nd%,p%,j&) 'F1 (n-D)
DECLARE FUNCTION F2(R(),Nd%,p%,j&) 'F2(n-D)
DECLARE FUNCTION F3(R(),Nd%,p%,j&) 'F3 (n-D)
DECLARE FUNCTION F4(R(),Nd%,p%,j&) 'F4 (n-D)
DECLARE FUNCTION F5(R(),Nd%,p%,j&) 'F5 (n-D)
DECLARE FUNCTION F6(R(),Nd%,p%,j&) 'F6 (n-D)
DECLARE FUNCTION F7(R(),Nd%,p%,j&) 'F7 (n-D)
DECLARE FUNCTION F8(R(),Nd%,p%,j&) 'F8 (n-D)
DECLARE FUNCTION F9(R(),Nd%,p%,j&) 'F9 (n-D)
DECLARE FUNCTION F10(R(),Nd%,p%,j&) 'F10 (n-D)
DECLARE FUNCTION F11(R(),Nd%,p%,j&) 'F11 (n-D)
DECLARE FUNCTION F12(R(),Nd%,p%,j&) 'F12 (n-D)
DECLARE FUNCTION u(Xi,a,k,m) 'Auxiliary function for F12 & F13
DECLARE FUNCTION F13(R(),Nd%,p%,j&) 'F13 (n-D)
DECLARE FUNCTION F14(R(),Nd%,p%,j&) 'F14 (n-D)
DECLARE FUNCTION F15(R(),Nd%,p%,j&) 'F15 (n-D)
DECLARE FUNCTION F16(R(),Nd%,p%,j&) 'F16 (n-D)
DECLARE FUNCTION F17(R(),Nd%,p%,j&) 'F17 (n-D)
DECLARE FUNCTION F18(R(),Nd%,p%,j&) 'F18 (n-D)
DECLARE FUNCTION F19(R(),Nd%,p%,j&) 'F19 (n-D)
DECLARE FUNCTION F20(R(),Nd%,p%,j&) 'F20 (n-D)
DECLARE FUNCTION F21(R(),Nd%,p%,j&) 'F21 (n-D)
DECLARE FUNCTION F22(R(),Nd%,p%,j&) 'F22 (n-D)
DECLARE FUNCTION F23(R(),Nd%,p%,j&) 'F23 (n-D)
DECLARE FUNCTION F24(R(),Nd%,p%,j&) 'F24 (n-D)
DECLARE FUNCTION F25(R(),Nd%,p%,j&) 'F25 (n-D)
DECLARE FUNCTION F26(R(),Nd%,p%,j&) 'F26 (n-D)
DECLARE FUNCTION F27(R(),Nd%,p%,j&) 'F27 (n-D)
DECLARE FUNCTION ParrottF4(R(),Nd%,p%,j&) 'Parrott F4 (1-D)
DECLARE FUNCTION SGO(R(),Nd%,p%,j&) 'SGO Function (2-D)
DECLARE FUNCTION GoldsteinPrice(R(),Nd%,p%,j&) 'Goldstein-Price Function (2-D)
DECLARE FUNCTION StepFunction(R(),Nd%,p%,j&) 'Step Function (n-D)
DECLARE FUNCTION Schwefel1226(R(),Nd%,p%,j&) 'Schwefel Prob. 2.26 (n-D)
DECLARE FUNCTION Colville(R(),Nd%,p%,j&) 'Colville Function (4-D)
DECLARE FUNCTION Griewank(R(),Nd%,p%,j&) 'Griewank (n-D)
DECLARE FUNCTION Himmelblau(R(),Nd%,p%,j&) 'Himmelblau (2-D)
DECLARE FUNCTION Rosenbrock(R(),Nd%,p%,j&) 'Rosenbrock (n-D)
DECLARE FUNCTION Sphere(R(),Nd%,p%,j&) 'Sphere (n-D)
DECLARE FUNCTION HimmelblauNLO(R(),Nd%,p%,j&) 'Himmelblau NLO (5-D)
DECLARE FUNCTION Tripod(R(),Nd%,p%,j&) 'Tripod (2-D)
DECLARE FUNCTION Sign(X) 'Auxiliary function for Tripod
DECLARE FUNCTION RosenbrockF6(R(),Nd%,p%,j&) 'Rosenbrock F6 (10-D)
DECLARE FUNCTION CompressionSpring(R(),Nd%,p%,j&) 'Compression Spring (3-D)
DECLARE FUNCTION GearTrain(R(),Nd%,p%,j&) 'Gear Train (4-D)
DECLARE FUNCTION PBM_1(R(),Nd%,p%,j&) 'PBM Benchmark #1
DECLARE FUNCTION PBM_2(R(),Nd%,p%,j&) 'PBM Benchmark #2
DECLARE FUNCTION PBM_3(R(),Nd%,p%,j&) 'PBM Benchmark #3
DECLARE FUNCTION PBM_4(R(),Nd%,p%,j&) 'PBM Benchmark #4
DECLARE FUNCTION PBM_5(R(),Nd%,p%,j&) 'PBM Benchmark #5
DECLARE FUNCTION BOWTIE(R(),Nd%,p%,j&) 'FREE-SPACE RLC-LOADED BOWTIE
DECLARE FUNCTION YAGI_ARRAY(R(),Nd%,p%,j&) 'FREE-SPACE YAGI ARRAY

```

```

'----- SUB DECLARATIONS -----

```

```

DECLARE SUB SieveOfEratosthenes(N&&,Primes&&(),NumPrimes&&)
DECLARE SUB IPD_Halton(Np%,Nd%,Nt&,R(),Gamma)
DECLARE SUB ReplaceCommentCard(NECFile$)
DECLARE SUB CopyBestMatrices(Np%,Nd%,Nt&,R(),M(),Rbest(),Mbest())

```



```

DECLARE SUB CheckNECFiles(NECFileError$)
DECLARE SUB GetTestFunctionNumber(FunctionName$)
DECLARE SUB FillArrayIj
DECLARE SUB Plot3DbestProbeTrajectories(NumTrajectories%,M(),R(),Np%,Nd%,LastStep&,FunctionName$)
DECLARE SUB Plot2DbestProbeTrajectories(NumTrajectories%,M(),R(),Np%,Nd%,LastStep&,FunctionName$)
DECLARE SUB Plot2DIndividualProbeTrajectories(NumTrajectories%,M(),R(),Np%,Nd%,LastStep&,FunctionName$)
DECLARE SUB Show2Dprobes(R(),Np%,Nt&,j&,Frep,BestFitness,BestProbeNumber%,BestTimeStep&,FunctionName$,RepositionFactor$,Gamma)
DECLARE SUB Show3Dprobes(R(),Np%,Nd%,Nt&,j&,Frep,BestFitness,BestProbeNumber%,BestTimeStep&,FunctionName$,RepositionFactor$,Gamma)
DECLARE SUB StatusWindow(FunctionName$,StatusWindowHandle???)
DECLARE PlotResults(FunctionName$,Nd%,Np%,BestFitnessOverall,BestNpNd%,BestGamma,Neval&&,Rbest(),Mbest(),BestProbeNumberOverall,BestTimeStepOverall,LastStepBestRun&,Alpha,Beta) SUB
DECLARE DisplayRunParameters(FunctionName$,Nd%,Np%,Nt&,G,DeltaT,Alpha,Beta,Frep,R(),A(),M(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,RunCFO$,ShrinkDSS$,CheckForEarlyTerminations$) SUB
DECLARE SUB GetBestFitness(M(),Np%,StepNumber&,BestFitness,BestProbeNumber%,BestTimeStep&)
DECLARE Tabulate1DprobeCoordinates(Max1DprobesPlotted&,Nd%,Np%,LastStep&,G,DeltaT,Alpha,Beta,Frep,R(),M(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,Gamma) SUB
DECLARE GetPlotAnnotation(PlotAnnotation$,Nd%,Np%,Nt&,G,DeltaT,Alpha,Beta,Frep,M(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,Gamma) SUB
DECLARE ChangeRunParameters(NumProbesPerDimension%,Np%,Nd%,Nt&,G,Alpha,Beta,DeltaT,Frep,PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$) SUB
DECLARE SUB CLEANUP
DECLARE Plot1DprobePositions(Max1DprobesPlotted&,Nd%,Np%,LastStep&,G,DeltaT,Alpha,Beta,Frep,R(),M(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,Gamma) SUB
DECLARE SUB DisplayMmatrix(Np%,Nt&,M())
DECLARE SUB DisplayMbestMatrix(Np%,Nt&,Mbest())
DECLARE SUB DisplayMmatrixThisTimeStep(Np%,j&,M())
DECLARE SUB DisplayAmatrix(Np%,Nd%,Nt&,A())
DECLARE SUB DisplayAmatrixThisTimeStep(Np%,Nd%,j&,A())
DECLARE SUB DisplayRmatrix(Np%,Nd%,Nt&,R())
DECLARE SUB DisplayRmatrixThisTimeStep(Np%,Nd%,j&,R(),Gamma)
DECLARE SUB DisplayXiMinMax(Nd%,XiMin(),XiMax())
DECLARE SUB DisplayRunParameters2(FunctionName$,Nd%,Np%,Nt&,G,DeltaT,Alpha,Beta,Frep,PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$)
DECLARE PlotBestProbeVsTimeStep(Nd%,Np%,LastStep&,G,DeltaT,Alpha,Beta,Frep,M(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,Gamma) SUB
DECLARE PlotBestFitnessEvolution(Nd%,Np%,LastStep&,G,DeltaT,Alpha,Beta,Frep,M(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,Gamma) SUB
DECLARE PlotAverageDistance(Nd%,Np%,LastStep&,G,DeltaT,Alpha,Beta,Frep,M(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,R(),DiagLength,Gamma) SUB
DECLARE SUB Plot2Dfunction(FunctionName$,R())
DECLARE SUB Plot1Dfunction(FunctionName$,R())
DECLARE GetFunctionRunParameters(FunctionName$,Nd%,Np%,Nt&,G,DeltaT,Alpha,Beta,Frep,R(),A(),M(),DiagLength,PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$) SUB
DECLARE SUB InitialProbeDistribution(Np%,Nd%,Nt&,R(),PlaceInitialProbes$,Gamma)
DECLARE SUB RetrieveErrantProbes(Np%,Nd%,j&,R(),Frep)
DECLARE SUB Retrieveerrantprobes2(Np%,Nd%,j&,R(),A(),Frep)
DECLARE SUB CFO(FunctionName$,Nd%,Nt&,R(),A(),M(),DiagLength,BestFitnessOverall,BestNpNd%,BestGamma,Neval&&,Rbest(),Mbest(),BestProbeNumberOverall,BestTimeStepOverall,LastStepBestRun&,Alpha,Beta) 'Self-contained CFO routine -> NO USER-SPECIFIED PARAMETERS
DECLARE SUB IPD(Np%,Nd%,Nt&,R(),Gamma)
DECLARE SUB ResetDecisionSpaceBoundaries(Nd%)
DECLARE SUB ThreeDplot(PlotFileName$,PlotTitle$,Annotation$,xCoords$,yCoords$,zCoords$, _
XaxisLabel$,YaxisLabel$,ZaxisLabel$,zMin$,zMax$,GnuPlotEXES$,A$)
DECLARE SUB ThreeDplot2(PlotFileName$,PlotTitle$,Annotation$,xCoords$,yCoords$,zCoords$, _
XaxisLabel$,YaxisLabel$,ZaxisLabel$,zMin$,zMax$,GnuPlotEXES$,A$,xStart$,xStop$,yStart$,yStop$)
DECLARE SUB ThreeDplot3(PlotFileName$,PlotTitle$,Annotation$,xCoords$,yCoords$,zCoords$, _
XaxisLabel$,YaxisLabel$,ZaxisLabel$,zMin$,zMax$,GnuPlotEXES$,xStart$,xStop$,yStart$,yStop$)
DECLARE SUB TwoDplot(PlotFileName$,PlotTitle$,xCoords$,yCoords$,XaxisLabel$,YaxisLabel$, _
LogXaxis$,LogYaxis$,xMin$,xMax$,yMin$,yMax$,xTics$,yTics$,GnuPlotEXES$,Linetype$,Annotation$)
DECLARE SUB TwoDplot2curves(PlotFileName1$,PlotFileName2$,PlotTitle$,Annotation$,xCoords$,yCoords$,XaxisLabel$,YaxisLabel$, _
LogXaxis$,LogYaxis$,xMin$,xMax$,yMin$,yMax$,xTics$,yTics$,GnuPlotEXES$,Linetype$)
DECLARE SUB TwoDplot3curves(NumCurves%,PlotFileName1$,PlotFileName2$,PlotFileName3$,PlotTitle$,Annotation$,xCoords$,yCoords$,XaxisLabel$,YaxisLabel$, _
LogXaxis$,LogYaxis$,xMin$,xMax$,yMin$,yMax$,xTics$,yTics$,GnuPlotEXES$)
DECLARE SUB CreateGnuPlotINIfile(PlotWindowULC_X%,PlotWindowULC_Y%,PlotWindowwidth%,PlotWindowheight%)
DECLARE SUB Delay(NumSecs)
DECLARE SUB MathematicalConstants
DECLARE SUB AlphabetAndDigits
DECLARE SUB SpecialSymbols
DECLARE SUB EMconstants
DECLARE SUB ConversionFactors
DECLARE SUB ShowConstants

```

```

DECLARE
GetNECdata(NECOutputFile$, NumFreqs$, NumRadPattAngles$, Zo, FrequencyMHZ(), RadEfficiencyPCT(), MaxGainDBI(), MinGainDBI(), RinOhms(), XinOhms(), VSWR(), ForwardGainDBI(), FileStatus$, FileIDs) SUB
DECLARE SUB ComplexMultiply(ReA, ImA, ReB, ImB, ReC, ImC)
DECLARE SUB ComplexDivide(ReA, ImA, ReB, ImB, ReC, ImC)
'----- FUNCTION DECLARATIONS -----
DECLARE FUNCTION DecimalToVanDerCorputBaseN(Nd%, Nbase%)
DECLARE FUNCTION Probeweight2(Nd%, Np%, R(), M(), p%, j&)
DECLARE FUNCTION Probeweight(Nd%, R(), p%, j&) 'computes a 'weighting factor' based on probe's position (greater weight if closer to decision space boundary)
DECLARE FUNCTION SlopeRatio(M(), Np%, StepNumber&)
DECLARE CALLBACK FUNCTION DlgProc
DECLARE FUNCTION HasFITNESSsaturated$(Nsteps&, j&, Np%, Nd%, M(), R(), DiagLength)
DECLARE FUNCTION HasDAVGsaturated$(Nsteps&, j&, Np%, Nd%, M(), R(), DiagLength)
DECLARE FUNCTION OscillationIndavg$(j&, Np%, Nd%, M(), R(), DiagLength)
DECLARE FUNCTION DavgThisStep(j&, Np%, Nd%, M(), R(), DiagLength)
DECLARE FUNCTION NoSpaces$(X, NumDigits%)
DECLARE FUNCTION FormatFP$(X, Ndigits%)
DECLARE FUNCTION FormatInteger$(M%)
DECLARE FUNCTION TerminateNowForSaturation$(j&, Nd%, Np%, Nt&, G, DeltaT, Alpha, Beta, R(), A(), M())
DECLARE FUNCTION MagVector(V(), N%)
DECLARE FUNCTION UniformDeviate(u&&)
DECLARE FUNCTION RandomNum(a, b)
DECLARE FUNCTION GaussianDeviate(Mu, Sigma)
DECLARE FUNCTION UnitStep(X)
DECLARE FUNCTION Fibonacci&&(N%)
DECLARE FUNCTION ObjectiveFunction(R(), Nd%, p%, j&, FunctionName$)
DECLARE FUNCTION UnitStep(X)
DECLARE FUNCTION FP2String2$(X!)
DECLARE FUNCTION FP2String$(X)
DECLARE FUNCTION Int2String$(X%)
DECLARE FUNCTION StandingWaveRatio(Zo, ReZ, ImZ)
'=====
'----- MAIN PROGRAM -----
FUNCTION PBMAIN () AS LONG
' ----- CFO Parameters -----
LOCAL Nd%, Np%, Nt&
LOCAL G, DeltaT, Alpha, Beta, Freq AS EXT
LOCAL PlaceInitialProbes$, InitialAcceleration$, RepositionFactors$
LOCAL R(), A(), M(), Rbest(), Mbest() AS EXT 'position, acceleration & fitness matrices
LOCAL FunctionName$ 'name of objective function
' ----- Miscellaneous Setup Parameters -----
LOCAL N%, O%, P%, i%, YN&, Neval&&, NevalTotal&&, BestNpNd%, NumTrajectories%, MaxIDprobesPlotted%, LastStepBestRun&, Pass%
LOCAL A$, RunCFO$, CFOversion$, NECFileError$, RunStart$, RunStop$
LOCAL BestGamma, BestFitnessThisRun, BestFitnessOverall, StartTime, StopTime, OptimumFitness AS EXT
LOCAL BestProbeNum%, BestTimeStep&, BestProbeNumberOverall%, BestTimeStepOverall&, StatusWindowHandle???
' ----- Global Constants -----
REDIM Aij(1 TO 2, 1 TO 25) '(GLOBAL array for Shekel's Foxholes function)
CALL FillArrayAij
CALL MathematicalConstants 'NOTE: Calling order is important!!
CALL AlphabetAndDigits 'NOTE: GLOBAL VARIABLE RunID$ IS SET HERE
CALL SpecialSymbols
CALL EMconstants
CALL ConversionFactors ' : CALL ShowConstants 'to verify constants have been set
BOWTIEsecsPerRun = 3##
' ----- General Setup -----
CFOversion$ = "CFO Ver. 06-25-2011"
RANDOMIZE TIMER 'seed random number generator with program start time
DESKTOP GET SIZE TO ScreenWidth&, ScreenHeight& 'get screen size (global variables)
IF DIR$("wgnuplot.exe") = "" THEN
MSGBOX("WARNING! 'wgnuplot.exe' not found. Run terminated.") : EXIT FUNCTION
END IF
IF DIR$("Fitness") <> "" THEN KILL "Fitness"
IF DIR$("Davg") <> "" THEN KILL "Davg"
IF DIR$("Best Probe") <> "" THEN KILL "Best Probe"
'----- CFO RUN PARAMETERS -----
CALL GetTestFunctionNumber(FunctionName$) : exit function 'DEBUG

```

```

CALL
GetFunctionRunParameters(FunctionName$,Nd%,Np%,Nt&,g,deltaT,Alpha,Beta,Frep,R(),AO,MO,DiagLength,PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$)
'NOTE: Parameters returned but not used in this version!!

REDIM R(1 TO Np%, 1 TO Nd%, 0 TO Nt&), A(1 TO Np%, 1 TO Nd%, 0 TO Nt&), M(1 TO Np%, 0 TO Nt&) 'position, acceleration & fitness matrices
REDIM Rbest(1 TO Np%, 1 TO Nd%, 0 TO Nt&), Mbest(1 TO Np%, 0 TO Nt&) 'overall best position & fitness matrices
'
----- PLOT 1D and 2D FUNCTIONS ON-SCREEN FOR VISUALIZATION -----
IF Nd% = 2 AND INSTR(FunctionName$,"PBM_") > 0 THEN
    CALL CheckNECFiles(NECFileError$)
    IF NECFileError$ = "YES" THEN
        EXIT FUNCTION
    ELSE
        MSGBOX("Begin computing plot of function "+FunctionName$+"? May take a while - be patient...")
    END IF
END IF

SELECT CASE Nd%
CASE 1 : CALL Plot1dfunction(FunctionName$,R()) : REDIM R(1 TO Np%, 1 TO Nd%, 0 TO Nt&) 'erases coordinate data in R()used to plot function
CASE 2 : CALL Plot2dfunction(FunctionName$,R()) : REDIM R(1 TO Np%, 1 TO Nd%, 0 TO Nt&) 'ditto
END SELECT
'
----- RUN CFO -----
YN& = MSGBOX("RUN CFO ON FUNCTION " + FunctionName$ + "?" + CHR$(13) + CHR$(13) + "Get some coffee & sit back...",%MB_YESNO,"CONFIRM RUN") : IF YN& = %IDYES THEN RunCFO$ = "YES"

IF RunCFO$ = "YES" THEN
    StartTime = TIMER : RunStart$ = "Started at "+TIME$+"", "+DATE$

    ----- BOWTIE -----
    IF FunctionName$ = "BOWTIE" THEN
        N% = FREEFILE : OPEN "Runtime_BOWTIE.DAT" FOR OUTPUT AS #N% : PRINT #N%, RunStart$ : CLOSE #N%

        IF DIR$("BOWTIE_CFO.CFG") = "" THEN
            N% = FREEFILE
            OPEN "BOWTIE_CFO.CFG" FOR OUTPUT AS #N%
            PRINT #N%, "150" : PRINT #N%, "11" : PRINT #N%, "4" 'CFO parameters Nt&, NumGammas%, MaxProbesPerDimension%, respectively
            CLOSE #N%
        END IF
    END IF

    ----- YAGI -----
    IF FunctionName$ = "YAGI" THEN
        N% = FREEFILE : OPEN "Runtime_YAGI.DAT" FOR OUTPUT AS #N% : PRINT #N%, RunStart$ : CLOSE #N%

        IF DIR$("YAGI_CFO.CFG") = "" THEN
            N% = FREEFILE
            OPEN "YAGI_CFO.CFG" FOR OUTPUT AS #N%
            PRINT #N%, "150" : PRINT #N%, "11" : PRINT #N%, "4" 'CFO parameters Nt&, NumGammas%, MaxProbesPerDimension%, respectively
            CLOSE #N%
        END IF
    END IF

    CALL
    CFO(FunctionName$,Nd%,Nt&,R(),AO,MO,DiagLength,BestFitnessOverall,BestNpNd%,BestGamma,Neval&&,Rbest(),Mbest(),BestProbeNumberOverall%,BestTimeStepOverall%&,LastStepBestRun&,Alpha,Beta)

    StopTime = TIMER : RunStop$ = "Ended at "+TIME$+"", "+DATE$
    Np% = BestNpNd%*Nd%

    ----- Add Best Run Results to CFO Setup Parameter File -----
    N% = FREEFILE
    OPEN "CFO_"+RunID$+".PAR" FOR APPEND AS #N%
    PRINT #N%, ""
    PRINT #N%, "Best Run Data:"
    PRINT #N%, "-----"
    PRINT #N%, "Fitness      = "+STR$(ROUND(BestFitnessOverall,8))
    PRINT #N%, "Np/Nd          = "+STR$(BestNpNd%)
    PRINT #N%, "Nd             = "+STR$(Nd%)
    PRINT #N%, "Np             = "+STR$(Np%)
    PRINT #N%, "Gamma          = "+STR$(BestGamma)
    PRINT #N%, "Probe #        = "+STR$(BestProbeNumberOverall%)
    PRINT #N%, "Time Step      = "+STR$(BestTimeStepOverall%)
    PRINT #N%, "Last Step      = "+STR$(LastStepBestRun%)
    CLOSE #N%

    CALL
    PlotResults(FunctionName$,Nd%,Np%,BestFitnessOverall,BestNpNd%,BestGamma,Neval&&,Rbest(),Mbest(),BestProbeNumberOverall%,BestTimeStepOverall%&,LastStepBestRun&,Alpha,Beta)

    ----- BOWTIE -----
    IF FunctionName$ = "BOWTIE" THEN
        N% = FREEFILE
        OPEN "Runtime_BOWTIE.DAT" FOR APPEND AS #N%
        PRINT #N%, RunStart$
        PRINT #N%, RunStop$
        PRINT #N%, "Runtime = "+STR$(ROUND((StopTime-StartTime)/3600#2))+" hrs"
        PRINT #N%, "Note: runtime will be incorrect if start/stop times transition midnight..."
        PRINT #N%, FunctionName$+" , Total Function Evaluations = "+STR$(Neval&&)
        PRINT #N%, "Avg Time/Run = "+STR$(ROUND((StopTime-StartTime)/Neval&&,6))
        CLOSE #N%

        IF DIR$("BestBOWTIE.NEC") <> "" THEN KILL "BestBOWTIE.NEC"
        IF DIR$("BestBOWTIE.OUT") <> "" THEN KILL "BestBOWTIE.OUT"
        OptimumFitness = BOWTIE(Rbest(),Nd%,BestProbeNumberOverall%,BestTimeStepOverall%)
        CALL ReplaceCommentCard("BOWTIE.NEC")
        NAME "BOWTIE.NEC" AS "BestBOWTIE.NEC"
        CALL ReplaceCommentCard("BOWTIE.OUT")
        NAME "BOWTIE.OUT" AS "BestBOWTIE.OUT"

        O% = FREEFILE
        OPEN "BestBOWTIE.NEC" FOR APPEND AS #O%
        PRINT #O%, "RLC-LOADED BOWTIE"
        PRINT #O%, "" : PRINT #O%, "OPTIMUM FITNESS = "+STR$(ROUND(OptimumFitness,3))+" @ Fo = 299.8 MHz, "+DATE$+" , "+TIME$
        PRINT #O%, "" : PRINT #O%, "USINGS('Best Gamma: ##.###      BestNp/Nd: ###      Nt: #####      Neval: #####      LastStep:
        #####",BestGamma,BestNpNd,Nt&,Neval&&,LastStepBestRun%)
        PRINT #O%, ""
        PRINT #O%, RunStart$
        PRINT #O%, RunStop$
        CLOSE #O%

        P% = FREEFILE
        OPEN "BestBOWTIE.OUT" FOR APPEND AS #P%
        PRINT #P%, "RLC-LOADED BOWTIE"
        PRINT #P%, "" : PRINT #P%, "OPTIMUM FITNESS = "+STR$(ROUND(OptimumFitness,3))+" @ Fo = 299.8 MHz, "+DATE$+" , "+TIME$

```



```

END SELECT

'----- BOWTIE -----
IF FunctionName$ = "BOWTIE" THEN
  M% = FREEFILE
  OPEN "BOWTIE_CFO.CFG" FOR INPUT AS #M%
  INPUT #M%, Nt& : INPUT #M%, NumGammas% : INPUT #M%, MaxProbesPerDimension%
  CLOSE #M%
  IF Nt& < 5 OR Nt& > 500 THEN Nt& = 150
  IF NumGammas% < 2 OR NumGammas% > 31 THEN NumGammas% = 11
  IF MaxProbesPerDimension% < 2 OR MaxProbesPerDimension% > 10 THEN MaxProbesPerDimension% = 6
END IF

'----- YAGI ARRAY -----
IF FunctionName$ = "YAGI" THEN
  M% = FREEFILE
  OPEN "YAGI_CFO.CFG" FOR INPUT AS #M%
  INPUT #M%, Nt& : INPUT #M%, NumGammas% : INPUT #M%, MaxProbesPerDimension%
  CLOSE #M%
  IF Nt& < 5 OR Nt& > 500 THEN Nt& = 150
  IF NumGammas% < 2 OR NumGammas% > 31 THEN NumGammas% = 11
  IF MaxProbesPerDimension% < 2 OR MaxProbesPerDimension% > 10 THEN MaxProbesPerDimension% = 6
END IF

'-----
LastStep& = Nt&

'IF FunctionName$ = "BOWTIE" THEN
  MaxProbesPerDimension% = 6 'to reduce runtime for LOADED BOWTIE
  MSGBOX("Approximate runtime: "+STR$(ROUND(BOWTIEsecsPerRun*NumGammas*Nd%*MaxProbesPerDimension%*Nt&/40##,1))+ minutes")
'END IF

'----- Save Setup Parameters for This Run -----
M% = FREEFILE
OPEN "CFO_"+RunID$+".PAR" FOR OUTPUT AS #M%
PRINT #M%,"CFO RUN PARAMETERS, Run ID: "+RunID$
PRINT #M%,"-----"+STRING$(LEN(RunID$),"-")
PRINT #M%,"Alpha = "+STR$(Alpha)
PRINT #M%,"Beta = "+STR$(Beta)
PRINT #M%,"Nt = "+STR$(Nt&)
PRINT #M%,"Initial Frep = "+STR$(FrepInit)
PRINT #M%,"Delta Frep = "+STR$(DeltaFrep)
PRINT #M%,"Min Frep = "+STR$(MinFrep)
PRINT #M%,"# Gammas = "+STR$(NumGammas%)
PRINT #M%,"Nt = "+STR$(Nt&)
PRINT #M%,"Max Probes/Dim = "+STR$(MaxProbesPerDimension%)
CLOSE #M%

'----- Np/Nd LOOP -----
BestFitnessOverall = -1E4200 'very large negative number...
FOR NumProbesPerDimension% = 2 TO MaxProbesPerDimension% STEP 2
  FOR NumProbesPerDimension% = 4 TO MaxProbesPerDimension% STEP 2 'original code
    Np% = NumProbesPerDimension%*Nd%
    '----- GAMMA LOOP -----
    FOR GammaNumber% = 1 TO NumGammas%
      Gamma = (GammaNumber%-1)/(NumGammas%-1)
      REDIM R(1 TO Np%, 1 TO Nd%, 0 TO Nt&), A(1 TO Np%, 1 TO Nd%, 0 TO Nt&), M(1 TO Np%, 0 TO Nt&) 're-initializes Position Vector/Acceleration/Fitness matrices to zero
      'STEP (A1) ----- Compute Initial Probe Distribution (Step 0)-----
      CALL IPD(Np%,Nd%,Nt&,R(),Gamma) 'Probe Line IPD intersecting on diagonal at a point determined by Gamma
      'STEP (A2) ----- Compute Initial Fitness Matrix (Step 0) -----
      FOR p% = 1 TO Np% : M(p%,0) = ObjectiveFunction(R(),Nd%,p%,0,FunctionName$) : INCR Neval&& : NEXT p%
      'STEP (A3) ----- Set Initial Probe Accelerations to ZERO (Step 0)-----
      FOR p% = 1 TO Np% : FOR i% = 1 TO Nd% : A(p%,i%,0) = 0## : NEXT i% : NEXT p%
      'STEP (A4) ----- Initialize Frep -----
      Frep = FrepInit '0.5##
      '===== LOOP ON TIME STEPS STARTING AT STEP #1 =====
      BestFitnessThisRun = M(1,0)
      FOR j& = 1 TO Nt&
        'STEP (B) ----- Compute Probe Position Vectors for this Time Step -----
        FOR p% = 1 TO Np% : FOR i% = 1 TO Nd% : R(p%,i%,j&) = R(p%,i%,j&-1) + A(p%,i%,j&-1) : NEXT i% : NEXT p% 'note: factor of 1/2 combined with G=2 to produce unity coefficient
        'STEP (C) ----- Retrieve Errant Probes -----
        CALL RetrieveErrantProbes(Np%,Nd%,j&,R(),Frep)
        CALL RetrieveErrantProbes2(Np%,Nd%,j&,R(),A(),Frep) 'added 04-01-10
        'STEP (D) ----- Compute Fitness Matrix for Current Probe Distribution -----
        FOR p% = 1 TO Np% : M(p%,j&) = ObjectiveFunction(R(),Nd%,p%,j&,FunctionName$) : INCR Neval&& : NEXT p%
        'STEP (E) ----- Compute Accelerations Based on Current Probe Distribution & Fitnesses -----
        FOR p% = 1 TO Np%
          FOR i% = 1 TO Nd%
            A(p%,i%,j&) = 0
            FOR k% = 1 TO Np%
              IF k% <> p% THEN
                SumSQ = 0## : FOR L% = 1 TO Nd% : SumSQ = SumSQ + (R(k%,L%,j&)-R(p%,L%,j&))^2 : NEXT L% 'dummy index
                IF SumSQ <> 0## THEN 'to avoid zero denominator (added 03-20-10) [NOTE THAT POWER BASIC DOES NOT FAULT ON DIVIDE-BY-ZERO...]
                  Denom = SQR(SumSQ) : Numerator = UnitStep((M(k%,j&)-M(p%,j&)))*(M(k%,j&)-M(p%,j&))
                  A(p%,i%,j&) = A(p%,i%,j&) + (R(k%,i%,j&)-R(p%,i%,j&))*Numerator^Alpha/Denom^Beta 'ORIGINAL VERSION WITH VARIABLE Alpha & Beta
                END IF 'added 03-20-10
              END IF
            END FOR
          END FOR
        END FOR
      END FOR
    END FOR
  END FOR
END SELECT

```

```

        END IF
        NEXT k% 'dummy index
        NEXT i% 'coord (dimension) #
        NEXT p% 'probe #
' ----- Get Best Fitness & Corresponding Probe # and Time Step -----
CALL GetBestFitness(M),Np%,j%,BestFitness,BestProbeNumber%,BestTimeStep%)
IF BestFitness >= BestFitnessThisRun THEN
    BestFitnessThisRun = BestFitness : BestProbeNumberThisRun% = BestProbeNumber% : BestTimeStepThisRun% = BestTimeStep%
END IF
' ---- Increment Frep ----
Frep = Frep + DeltaFrep
IF Frep > 1## THEN Frep = MinFrep 'keep Frep in range [0.05,1]
' ----- Starting at Step #20 Shrink Decision Space Around Best Probe Every 20th Step -----
' IF j% MOD 10 = 0 AND j% >= 20 THEN
' IF j% MOD 20 = 0 AND j% >= 20 THEN
    FOR i% = 1 TO Nd% : XiMin(i%) = XiMin(i%)+(R(BestProbeNumber%,i%,BestTimeStep%)-XiMin(i%))/2## : XiMax(i%) = XiMax(i%)-(XiMax(i%)-
R(BestProbeNumber%,i%,BestTimeStep%))/2## : NEXT i% 'shrink DS by 0.5
    CALL RetrieveErrantProbes(Np%,Nd%,j%,R(),Frep) 'TO RETRIEVE PROBES LYING OUTSIDE SHRUNKEN DS 'ADDED 02-07-2010
    CALL RetrieveErrantProbes2(Np%,Nd%,j%,R(),A(),Frep) 'added 04-01-10
END IF
'STEP (F) ----- Check for Early Run Termination -----
IF HasFITNESSsaturated$(25,j%,Np%,Nd%,M(),R(),DiagLength) = "YES" THEN
    LastStep% = j%
    EXIT FOR
END IF
NEXT j% 'END TIME STEP LOOP
'----- Best Overall Fitness & Corresponding Parameters -----
IF BestFitnessThisRun >= BestFitnessOverall THEN
    BestFitnessOverall = BestFitnessThisRun : BestProbeNumberOverall% = BestProbeNumberThisRun% : BestTimeStepOverall% = BestTimeStepThisRun%
    BestNpNd% = NumProbesPerDimension% : BestGamma = Gamma : LastStepBestRun% = LastStep%
    CALL CopyBestMatrices(Np%,Nd%,Nt%,R(),M(),Rbest(),Mbest())
END IF
'STEP (G) ----- Reset Decision Space Boundaries to Initial Values -----
CALL ResetDecisionSpaceBoundaries(Nd%)
NEXT GammaNumber% 'END GAMMA LOOP
NEXT NumProbesPerDimension% 'END Np/Nd LOOP
END SUB 'CFO()
'=====
SUB IPD_Halton(Np%,Nd%,Nt%,R(),Gamma) 'added 06-29-2011
LOCAL DeltaXi, De1X1, De1X2, Di AS EXT
LOCAL NumProbesPerDimension%, p%, i%, k%, NumX1points%, NumX2points%, x1pointNum%, x2pointNum%
    IF Nd% > 1 THEN
        NumProbesPerDimension% = Np%*Nd% 'even #
    ELSE
        NumProbesPerDimension% = Np%
    END IF
    FOR i% = 1 TO Nd%
        FOR p% = 1 TO Np%
            R(p%,i%,0) = XiMin(i%) + Gamma*(XiMax(i%)-XiMin(i%))
        NEXT Np%
    NEXT i%
    FOR i% = 1 TO Nd% 'place probes probe line-by-probe line (i% is dimension number)
        DeltaXi = (XiMax(i%)-XiMin(i%))/(NumProbesPerDimension%-1)
        FOR k% = 1 TO NumProbesPerDimension%
            p% = k% + NumProbesPerDimension%*(i%-1) 'probe #
            R(p%,i%,0) = XiMin(i%) + (k%-1)*DeltaXi
        NEXT k%
    NEXT i%
END SUB 'IPD_Halton()
'-----
FUNCTION DecimalToVanDerCorputBaseN(N&&,Nbase%)
'Returns the decimal value of the VDC base Nbase% 'radical inverse function' to create a Low Discrepancy sequence of decimal values.
'Maps integer argument into a quasirandom real number on the interval [0,1).
'Refs: (1) "Improved Particle Swarm Optimization with Low-Discrepancy Sequences,"
Pant, Thangaraj, Grosan & Abraham, 2008 IEEE Congress on Evolutionary Computation (CEC2008), p. 3011.
(2) "Quasirandom Ramblings," Computing Science column in American Scientist Magazine, July-August 2011, p. 282.

```

(www.american scientist.org)

'CHECK VALUES FOR BASE 2

Integer(N&&)	Base 2 Representation	Digits Reversed	VDC Decimal Value
0	0	0	0.0
2	10	01	0.25
3	11	11	0.75
4	100	001	0.125
6	110	011	0.375
7	111	111	0.875
15	1111	1111	0.9375
120	1111000	0001111	0.1171875
121	1111001	1001111	0.6171875
532	1000010100	0010100001	0.1572265625

'CHECK VALUES FOR BASE 3

Integer(N&&)	Base 3 Representation	Digits Reversed	VDC Decimal Value
0	0	0	0.0
2	2	2	0.666...
3	10	01	0.111...
7	21	12	0.555...
120	11110	01111	0.164609053497942
532	201201	102102	0.422496570544719

'CHECK VALUES FOR BASE 5

Integer(N&&)	Base 5 Representation	Digits Reversed	VDC Decimal Value
0	0	0	0.0
1	1	1	0.2
2	2	2	0.4
3	3	3	0.6
4	4	4	0.8
5	10	01	0.04
7	12	21	0.44
17	32	23	0.52
121	441	144	0.392
532	4112	2114	0.4544

LOCAL S AS EXT, R AS EXT, I&&, D&&

S = 0##

IF N&& > 2^63-2 THEN  
MSGBOX("WARNING! VDC arg > 2^63-2. Zero returned.") : GOTO ExitVDC  
END IF

I&& = N&& : R = 1##/Nbase%

DO WHILE I&& <> 0 : D&& = I&& MOD Nbase% : S = S + D&&^R : I&& = (I&&-D&&)/Nbase% : R = R/Nbase% : LOOP

ExitVDC:

DecimalToVanDerCorputBaseN = S

END FUNCTION

'-----

SUB SieveOfEratosthenes(N&&,Primes&&(),NumPrimes&&)

'Returns primes between 2 and N&& and their number.

'NOTE: There are 303 primes between 2 and 2000. Accuracy of this routine has been checked against table of the first 1000 primes (# primes up to N&&=7919).

'Ref: Caldwell, C., "The Prime Pages," Univ. Tennessee at Martin, <http://primes.utm.edu>

LOCAL i&&, istart&&, p&&, j&&, TempArray&&()

REDIM TempArray&&(1 TO N&&)

TempArray&&(1) = 0 : FOR i&& = 2 TO N&& : TempArray&&(i&&) = 1 : NEXT i&&

p&& = 2 : WHILE p&&^2 <= N&& : j&& = p&&^2 : WHILE j&& <= N&& : TempArray&&(j&&) = 0 : j&& = j&& + p&& : WEND : p&& = p&& + 1 : WEND 'inserts 0 or 1 depending on whether or not # is a prime

NumPrimes&& = 0

FOR i&& = 1 TO N&& 'converts the 1's into their corresponding prime numbers & retrieves # primes between 2 and N&&  
IF TempArray&&(i&&) = 1 THEN INCR NumPrimes&&  
TempArray&&(i&&) = i&&^TempArray&&(i&&)  
NEXT i&&

REDIM Primes&&(1 TO NumPrimes&&)

istart&& = 1  
FOR j&& = 1 TO NumPrimes&&  
FOR i&& = istart&& TO N&&  
IF TempArray&&(i&&) <> 0 THEN  
Primes&&(j&&) = TempArray&&(i&&) : istart&& = i&&+1 : EXIT FOR  
END IF  
NEXT i&&  
NEXT j&&

END SUB 'SieveOfEratosthenes()

'-----

SUB IPD(Np%,Nd%,Nt%,R(),Gamma)

LOCAL DeltaXi, De1X1, De1X2, Di AS EXT

LOCAL NumProbesPerDimension%, p%, i%, k%, NumX1points%, NumX2points%, x1pointNum%, x2pointNum%

IF Nd% > 1 THEN

NumProbesPerDimension% = Np%\Nd% 'even #

ELSE

NumProbesPerDimension% = Np%

END IF

FOR i% = 1 TO Nd%

FOR p% = 1 TO Np%

R(p%,i%,0) = XiMin(i%) + Gamma\*(XiMax(i%)-XiMin(i%))

NEXT p%

NEXT i%

FOR i% = 1 TO Nd% 'place probes probe line-by-probe line (i% is dimension number)

```

DeltaXi = (XiMax(i%) - XiMin(i%)) / (NumProbesPerDimension% - 1)
FOR k% = 1 TO NumProbesPerDimension%
  p% = k% + NumProbesPerDimension% * (i% - 1) 'probe #
  R(p%, i%, 0) = XiMin(i%) + (k% - 1) * DeltaXi
NEXT k%
NEXT i%
END SUB 'IPD()
'-----
FUNCTION HasFITNESSsaturated$(Nsteps&, j&, Np%, Nd%, MC), R(), DiagLength)
LOCAL A$, B$
LOCAL k&, p%
LOCAL BestFitness, SumOfBestFitnesses, BestFitnessStepJ, FitnessSatTOL AS EXT
A$ = "NO" : B$ = "j=" + STR$(j&) + CHR$(13)
FitnessSatTOL = 0.000001## 'tolerance for FITNESS saturation
IF j& < Nsteps& + 10 THEN GOTO ExitHasFITNESSsaturated 'execute at least 10 steps after averaging interval before performing this check
SumOfBestFitnesses = 0##
FOR k& = j& - Nsteps& + 1 TO j& 'GET BEST FITNESSES STEP-BY-STEP FOR Nsteps& INCLUDING THIS STEP j& AND COMPUTE AVERAGE VALUE.
  BestFitness = M(k&, 1) 'ORIG CODE 03-23-2010: THIS IS A MISTAKE!
  BestFitness = -1E4200 'THIS LINE CORRECTED 03-23-2010 PER DISCUSSION WITH ROB GREEN.
  'INITIALIZE BEST FITNESS AT k&-th TIME STEP TO AN EXTREMELY LARGE NEGATIVE NUMBER.
  FOR p% = 1 TO Np% 'PROBE-BY-PROBE GET MAXIMUM FITNESS
    IF M(p%, k&) >= BestFitness THEN BestFitness = M(p%, k&)
  NEXT p%
  IF k& = j& THEN BestFitnessStepJ = BestFitness 'IF AT THE END OF AVERAGING INTERVAL, SAVE BEST FITNESS FOR CURRENT TIME STEP j&
  SumOfBestFitnesses = SumOfBestFitnesses + BestFitness
  B$ = B$ + "k=" + STR$(k&) + " BestFit=" + STR$(BestFitness) + " SumFit=" + STR$(SumOfBestFitnesses) + CHR$(13)
NEXT k&
IF ABS(SumOfBestFitnesses / Nsteps& - BestFitnessStepJ) <= FitnessSatTOL THEN A$ = "YES" 'saturation if (avg value - last value) are within TOL
ExitHasFITNESSsaturated:
HasFITNESSsaturated$ = A$
END FUNCTION 'HasFITNESSsaturated$()
'-----
SUB RetrieveErrantprobes2(Np%, Nd%, j&, R(), A(), Frep) 'added 04-01-10
LOCAL ErrantProbe$
LOCAL p%, i%, k%
LOCAL Xi k, dMax, Eta(), EtaStar, SumSQ, MagAj1 AS EXT
REDIM Eta(1 TO Nd%, 1 TO 2) 'Eta(i%, k%)
FOR p% = 1 TO Np%
  ErrantProbe$ = "NO" 'presume each probe is inside DS
  FOR i% = 1 TO Nd% 'check to see if probe p lies outside DS (any coordinate exceeding a boundary)
    IF (R(p%, i%, j&) > XiMax(i%) OR R(p%, i%, j&) < XiMin(i%)) AND A(p%, i%, j& - 1) <> 0## THEN 'probe lies outside DS
      ErrantProbe$ = "YES" : EXIT FOR
    END IF
  NEXT i%
  IF ErrantProbe$ = "YES" THEN 'reposition probe p inside DS with acceleration direction preserved
    FOR i% = 1 TO Nd% 'compute array of Eta values
      FOR k% = 1 TO 2
        SELECT CASE k%
          CASE 1 : Xi k = XiMin(i%)
          CASE 2 : Xi k = XiMax(i%)
        END SELECT
        Eta(i%, k%) = (Xi k - R(p%, i%, j& - 1)) / A(p%, i%, j& - 1)
      NEXT k%
    NEXT i%
    EtaStar = 1E4200 'very large positive number
    FOR i% = 1 TO Nd% 'get min Eta value > 0
      FOR k% = 1 TO 2
        IF Eta(i%, k%) <= EtaStar AND Eta(i%, k%) >= 0## THEN EtaStar = Eta(i%, k%)
      NEXT k%
    NEXT i%
    SumSQ = 0## : FOR i% = 1 TO Nd% : SumSQ = SumSQ + A(p%, i%, j& - 1) ^ 2 : NEXT i% : MagAj1 = SQR(SumSQ) 'magnitude of acceleration vector A(probe #p)
    dMax = EtaStar * MagAj1 'distance to nearest boundary plane from position of probe p% at step j&-1
    FOR i% = 1 TO Nd% 'change probe p's i-th coordinate in proportion to the ratio of position vector lengths at steps j& and j&-1
      R(p%, i%, j&) = R(p%, i%, j& - 1) + Frep * dMax * A(p%, i%, j& - 1) / MagAj1 'preserves acceleration directional information by scaling dMax by Frep, which
      is arbitrary but precisely known
    NEXT i%
  END IF
NEXT p%

```



```

        END IF 'ErrantProbe$ = "YES"
    NEXT p%
END SUB 'Retrieveerrantprobes2()
'-----
SUB RetrieveErrantProbes(Np%,Nd%,j&,R(),Frep)
LOCAL p%, i%
FOR p% = 1 TO Np%
    FOR i% = 1 TO Nd%
        IF R(p%,i%,j&) < XiMin(i%) THEN R(p%,i%,j&) = MAX(XiMin(i%) + Frep*(R(p%,i%,j&-1)-XiMin(i%)),XiMin(i%)) 'CHANGED 02-07-10
        IF R(p%,i%,j&) > XiMax(i%) THEN R(p%,i%,j&) = MIN(XiMax(i%) - Frep*(XiMax(i%)-R(p%,i%,j&-1)),XiMax(i%))
    NEXT i%
NEXT p%
END SUB 'RetrieveErrantProbes()
'-----
SUB ResetDecisionSpaceBoundaries(Nd%)
LOCAL i%
FOR i% = 1 TO Nd% : XiMin(i%) = StartingXiMin(i%) : XiMax(i%) = StartingXiMax(i%) : NEXT i%
END SUB
'-----
SUB CopyBestMatrices(Np%,Nd%,Nt&,R(),M(),Rbest(),Mbest())
LOCAL p%, i%, j&
REDIM Rbest(1 TO Np%, 1 TO Nd%, 0 TO Nt&), Mbest(1 TO Np%, 0 TO Nt&) 're-initializes Best Position Vector/Fitness matrices to zero
FOR p% = 1 TO Np%
    FOR i% = 1 TO Nd%
        FOR j& = 0 TO Nt&
            Rbest(p%,i%,j&) = R(p%,i%,j&) : Mbest(p%,j&) = M(p%,j&)
        NEXT j&
    NEXT i%
NEXT p%
END SUB
'-----
'FORGET THIS IDEA !!!!
FUNCTION Probeweight(Nd%,R(),p%,j&) 'computes a 'weighting factor' based on probe's position (greater weight if closer to decision space boundary)
LOCAL MinDistCoordinate%, i% 'Dimension number. Remember, XiMin(), XiMax() & DiagLength are GLOBAL.
LOCAL MinDistance, dStar, MaxWeight AS EXT
MinDistance = DiagLength 'largest dimension of decision space
FOR i% = 1 TO Nd% 'compute distance to closest boundary
    IF ABS(R(p%,i%,j&)-XiMin(i%)) <= MinDistance THEN
        MinDistance = ABS(R(p%,i%,j&)-XiMin(i%)) : MinDistCoordinate% = i%
    END IF
    IF ABS(XiMax(i%)-R(p%,i%,j&)) <= MinDistance THEN
        MinDistance = ABS(XiMax(i%)-R(p%,i%,j&)) : MinDistCoordinate% = i%
    END IF
NEXT i%
dStar = MinDistance/(XiMax(MinDistCoordinate%)-XiMin(MinDistCoordinate%)) 'normalized minimum distance, [0-1]
MaxWeight = 2##
' Probeweight = 1## + 2##*MaxWeight*abs(dStar-0.5##)
Probeweight = 1## + 4##*MaxWeight*(dStar-0.5##)^2
END FUNCTION 'Probeweight
'-----
'FORGET THIS IDEA !!!!
FUNCTION Probeweight2(Nd%,Np%,R(),M(),p%,j&) 'computes a 'weighting factor' based on probe's position (greater weight if closer to decision space boundary)
LOCAL MinDistCoordinate%, ProbeNum%, BestProbeThisStep%, i% 'Dimension number. Remember, XiMin(), XiMax() & DiagLength are GLOBAL.
LOCAL Distance, SumSQ, dStar, MaxWeight, BestFitnessThisStep AS EXT
BestFitnessThisStep = M(1,j&)
FOR ProbeNum% = 1 TO Np% 'get number of best probe this step
    IF M(ProbeNum%,j&) >= BestFitnessThisStep THEN
        BestFitnessThisStep = M(ProbeNum%,j&) : BestProbeThisStep% = ProbeNum%
    END IF
NEXT ProbeNum%
SumSQ = 0##
FOR i% = 1 TO Nd% 'compute distance from probe #p% to the best probe this step
    SumSQ = (R(p%,i%,j&) - R(BestProbeThisStep%,i%,j&))^2
NEXT i%
Distance = SQR(SumSQ)

```

```

dStar = Distance/DiagLength 'range [0-1]
' ----- Compute weight Factor -----
Maxweight = 0##
' Probeweight2 = 1## + 2##*MaxWeight*abs(dStar-0.5##)
' Probeweight2 = 1## + 4##*MaxWeight*(dStar-0.5##)^2
END FUNCTION 'Probeweight2
'-----
FUNCTION SlopeRatio(M(),Np%,StepNumber&)
LOCAL p% 'probe #
LOCAL NumSteps%
LOCAL BestFitnessAtStepNumber, BestFitnessAtStepNumberMinus1, BestFitnessAtStepNumberMinus2, Z AS EXT
Z = 1## 'assumes no slope change
IF StepNumber& < 10 THEN GOTO ExitsSlopeRatio 'need at least 10 steps for this test
NumSteps% = 2
BestFitnessAtStepNumber = M(1,StepNumber&) : FOR p% = 1 TO Np% : IF M(p%,StepNumber&) >= BestFitnessAtStepNumber
THEN BestFitnessAtStepNumber = M(p%,StepNumber&) : NEXT p%
BestFitnessAtStepNumberMinus1 = M(1,StepNumber&-NumSteps%) : FOR p% = 1 TO Np% : IF M(p%,StepNumber&-NumSteps%) >= BestFitnessAtStepNumberMinus1
THEN BestFitnessAtStepNumberMinus1 = M(p%,StepNumber&-NumSteps%) : NEXT p%
BestFitnessAtStepNumberMinus2 = M(1,StepNumber&-2*NumSteps%) : FOR p% = 1 TO Np% : IF M(p%,StepNumber&-2*NumSteps%) >= BestFitnessAtStepNumberMinus2
THEN BestFitnessAtStepNumberMinus2 = M(p%,StepNumber&-2*NumSteps%) : NEXT p%
Z = (BestFitnessAtStepNumber-BestFitnessAtStepNumberMinus1)/(BestFitnessAtStepNumberMinus1-BestFitnessAtStepNumberMinus2)
ExitsSlopeRatio:
SlopeRatio = Z
END FUNCTION
'-----
SUB
PlotResults(FunctionName$,Nd%,Np%,BestFitnessOverall,BestNpNd%,BestGamma,Neval&&,Rbest(),Mbest(),BestProbeNumberOverall%,BestTimeStepOverall%,LastStepBestRun&,Alpha,Beta)
LOCAL LastStep&, BestFitnessProbeNumber%, BestFitnessTimeStep&, NumTrajectories%, MaxIDprobesPlotted%, i%
LOCAL RepositionFactor$, PlaceInitialProbes$, InitialAcceleration$, A$, B$
LOCAL G, DeltaT, Freq AS EXT
' G = 2## : DeltaT = 1## : Freq = 0.5## : RepositionFactor$ = "VARIABLE" : PlaceInitialProbes$ = "UNIFORM ON-AXIS " : InitialAcceleration$ = "FIXED"
'THESE ARE NOW HARDWIRED IN THE CFO EQUATIONS 'ORIG CODE 05/14/2011
G = 2## : DeltaT = 1## : Freq = 0.5## : RepositionFactor$ = "VARIABLE" : PlaceInitialProbes$ = "PROBE LINES" : InitialAcceleration$ = "ZERO" 'MOD
05/14/2011
B$ = "" : IF Nd% > 1 THEN B$ = "s"
A$ = FunctionName$ + CHR$(13) +
"Best Fitness = " + REMOVE$(STR$(BestFitnessOverall),ANY" ") + " returned by" + CHR$(13) +
"Probe # " + REMOVE$(STR$(BestProbeNumberOverall%),ANY" ") +
"at Time Step " + REMOVE$(STR$(BestTimeStepOverall%),ANY" ") + CHR$(13) + CHR$(13) + "P" + REMOVE$(STR$(BestProbeNumberOverall%),ANY" ") +
coordinate$ + B$ + " : " + CHR$(13)
FOR i% = 1 TO Nd% : A$ = A$ + STR$(i%)+ " "+REMOVE$(STR$(ROUND(Rbest(BestProbeNumberOverall%,i%,BestTimeStepOverall%),8)),ANY" ") +CHR$(13) : NEXT i%
MSGBOX(A$)
' ----- PLOT EVOLUTION OF BEST FITNESS, AVG DISTANCE & BEST PROBE # -----
CALL
PlotBestFitnessEvolution(Nd%,Np%,LastStepBestRun&,G,DeltaT,Alpha,Beta,Freq,Mbest(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,BestGamma)
' MSGBOX("Enter for next plot...")
CALL
PlotAverageDistance(Nd%,Np%,LastStepBestRun&,G,DeltaT,Alpha,Beta,Freq,Mbest(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,Rbest(),DiagLength,BestGamma)
' MSGBOX("Enter for next plot...")
CALL
PlotBestProbeVsTimeStep(Nd%,Np%,LastStepBestRun&,G,DeltaT,Alpha,Beta,Freq,Mbest(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,BestGamma)
' ----- PLOT TRAJECTORIES OF BEST PROBES FOR 2/3-D FUNCTIONS -----
IF Nd% = 2 THEN
NumTrajectories% = 10 : CALL Plot2DbestProbeTrajectories(NumTrajectories%,Mbest(),Rbest(),Np%,Nd%,LastStepBestRun&,FunctionName$)
NumTrajectories% = 16 : CALL Plot2DindividualProbeTrajectories(NumTrajectories%,Mbest(),Rbest(),Np%,Nd%,LastStepBestRun&,FunctionName$)
END IF
IF Nd% = 3 THEN
NumTrajectories% = 4 : CALL Plot3DbestProbeTrajectories(NumTrajectories%,Mbest(),Rbest(),Np%,Nd%,LastStepBestRun&,FunctionName$)
END IF
' ----- For 1-D Objective Functions, Tabulate Probe Coordinates & if Np% <= MaxIDprobesPlotted% Plot Evolution of Probe Positions -----
IF Nd% = 1 THEN
MaxIDprobesPlotted% = 15
CALL
TabulateIDprobeCoordinates(MaxIDprobesPlotted%,Nd%,Np%,LastStepBestRun&,G,DeltaT,Alpha,Beta,Freq,Rbest(),Mbest(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,BestGamma)
IF Np% <= MaxIDprobesPlotted% THEN _
CALL
PlotIDprobePositions(MaxIDprobesPlotted%,Nd%,Np%,LastStepBestRun&,G,DeltaT,Alpha,Beta,Freq,Rbest(),Mbest(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,BestGamma)
CALL CLEANUP 'delete probe coordinate plot files, if any
END IF

```

```

END SUB 'PlotResults()
'=====
SUB CheckNECFiles(NECfileError$)
LOCAL N%
NECfileError$ = "NO"
'----- NEC Files Required for PBM Antenna Benchmarks -----
IF DIR$( "n4l_2k1.exe" ) = "" THEN
    MSGBOX("WARNING! 'n4l_2k1.exe' not found. Run terminated.") : NECfileError$ = "YES" : EXIT SUB
END IF
'----- These Files are Required for NEC-4.1, Some for NEC-2 -----
N% = FREEFILE : OPEN "ENDERR.DAT" FOR OUTPUT AS #N% : PRINT #N%, "NO" : CLOSE #N%
N% = FREEFILE : OPEN "FILE_MSG.DAT" FOR OUTPUT AS #N% : PRINT #N%, "NO" : CLOSE #N%
N% = FREEFILE : OPEN "NHSCALE.DAT" FOR OUTPUT AS #N% : PRINT #N%, "0.00001" : CLOSE #N%
END SUB
'-----
SUB GetBestFitness(M(),Np%,StepNumber&,BestFitness,BestProbeNumber%,BestTimeStep&)
LOCAL p%, i&, A$
BestFitness = M(1,0)
FOR i& = 0 TO StepNumber&
    FOR p% = 1 TO Np%
        IF M(p%,i&) >= BestFitness THEN
            BestFitness = M(p%,i&) : BestProbeNumber% = p% : BestTimeStep& = i&
        END IF
    NEXT p%
NEXT i&
END SUB
'===== FUNCTION DEFINITIONS =====
FUNCTION ObjectiveFunction(R(),Nd%,p%,j&,FunctionName$) 'Objective function to be MAXIMIZED is defined here
SELECT CASE FunctionName$
CASE "ParrottF4" : ObjectiveFunction = ParrottF4(R(),Nd%,p%,j&) 'Parrott F4 (1-D)
CASE "SGO" : ObjectiveFunction = SGO(R(),Nd%,p%,j&) 'SGO Function (2-D)
CASE "GP" : ObjectiveFunction = GoldsteinPrice(R(),Nd%,p%,j&) 'Goldstein-Price Function (2-D)
CASE "STEP" : ObjectiveFunction = StepFunction(R(),Nd%,p%,j&) 'Step Function (n-D)
CASE "SCHWEFEL226" : ObjectiveFunction = Schwefel226(R(),Nd%,p%,j&) 'Schwefel Prob. 2.26 (n-D)
CASE "COLVILLE" : ObjectiveFunction = Colville(R(),Nd%,p%,j&) 'Colville Function (4-D)
CASE "GRIEWANK" : ObjectiveFunction = Griewank(R(),Nd%,p%,j&) 'Griewank Function (n-D)
CASE "HIMMELBLAU" : ObjectiveFunction = Himmelblau(R(),Nd%,p%,j&) 'Himmelblau Function (2-D)
CASE "ROSENBROCK" : ObjectiveFunction = Rosenbrock(R(),Nd%,p%,j&) 'Rosenbrock Function (n-D)
CASE "SPHERE" : ObjectiveFunction = Sphere(R(),Nd%,p%,j&) 'Sphere Function (n-D)
CASE "HIMMELBLAUNLO" : ObjectiveFunction = HIMMELBLAUNLO(R(),Nd%,p%,j&) 'Himmelblau NLO (5-D)
CASE "TRIPOD" : ObjectiveFunction = Tripod(R(),Nd%,p%,j&) 'Tripod (2-D)
CASE "ROSENBROCKF6" : ObjectiveFunction = RosenbrockF6(R(),Nd%,p%,j&) 'RosenbrockF6 (10-D)
CASE "COMPRESSIONSPRING" : ObjectiveFunction = CompressionSpring(R(),Nd%,p%,j&) 'Compression Spring (3-D)
CASE "GEARTRAIN" : ObjectiveFunction = GearTrain(R(),Nd%,p%,j&) 'Gear Train (4-D)
'----- GSO Paper Benchmark Functions -----
CASE "F1" : ObjectiveFunction = F1(R(),Nd%,p%,j&) 'F1 (n-D)
CASE "F2" : ObjectiveFunction = F2(R(),Nd%,p%,j&) 'F2 (n-D)
CASE "F3" : ObjectiveFunction = F3(R(),Nd%,p%,j&) 'F3 (n-D)
CASE "F4" : ObjectiveFunction = F4(R(),Nd%,p%,j&) 'F4 (n-D)
CASE "F5" : ObjectiveFunction = F5(R(),Nd%,p%,j&) 'F5 (n-D)
CASE "F6" : ObjectiveFunction = F6(R(),Nd%,p%,j&) 'F6 (n-D)
CASE "F7" : ObjectiveFunction = F7(R(),Nd%,p%,j&) 'F7 (n-D)
CASE "F8" : ObjectiveFunction = F8(R(),Nd%,p%,j&) 'F8 (n-D)
CASE "F9" : ObjectiveFunction = F9(R(),Nd%,p%,j&) 'F9 (n-D)
CASE "F10" : ObjectiveFunction = F10(R(),Nd%,p%,j&) 'F10 (n-D)
CASE "F11" : ObjectiveFunction = F11(R(),Nd%,p%,j&) 'F11 (n-D)
CASE "F12" : ObjectiveFunction = F12(R(),Nd%,p%,j&) 'F12 (n-D)
CASE "F13" : ObjectiveFunction = F13(R(),Nd%,p%,j&) 'F13 (n-D)
CASE "F14" : ObjectiveFunction = F14(R(),Nd%,p%,j&) 'F14 (2-D)
CASE "F15" : ObjectiveFunction = F15(R(),Nd%,p%,j&) 'F15 (4-D)
CASE "F16" : ObjectiveFunction = F16(R(),Nd%,p%,j&) 'F16 (2-D)
CASE "F17" : ObjectiveFunction = F17(R(),Nd%,p%,j&) 'F17 (2-D)
CASE "F18" : ObjectiveFunction = F18(R(),Nd%,p%,j&) 'F18 (2-D)
CASE "F19" : ObjectiveFunction = F19(R(),Nd%,p%,j&) 'F19 (3-D)
CASE "F20" : ObjectiveFunction = F20(R(),Nd%,p%,j&) 'F20 (6-D)
CASE "F21" : ObjectiveFunction = F21(R(),Nd%,p%,j&) 'F21 (4-D)
CASE "F22" : ObjectiveFunction = F22(R(),Nd%,p%,j&) 'F22 (4-D)
CASE "F23" : ObjectiveFunction = F23(R(),Nd%,p%,j&) 'F23 (4-D)
'----- PBM Antenna Benchmarks -----
CASE "PBM_1" : ObjectiveFunction = PBM_1(R(),Nd%,p%,j&) 'PBM_1 (2-D)
CASE "PBM_2" : ObjectiveFunction = PBM_2(R(),Nd%,p%,j&) 'PBM_2 (2-D)
CASE "PBM_3" : ObjectiveFunction = PBM_3(R(),Nd%,p%,j&) 'PBM_3 (2-D)
CASE "PBM_4" : ObjectiveFunction = PBM_4(R(),Nd%,p%,j&) 'PBM_4 (2-D)
CASE "PBM_5" : ObjectiveFunction = PBM_5(R(),Nd%,p%,j&) 'PBM_5 (2-D)
'----- LOADED BOWTIE IN FREE SPACE -----
CASE "BOWTIE" : ObjectiveFunction = BOWTIE(R(),Nd%,p%,j&) 'FREE SPACE LOADED BOWTIE
'----- YAGI ARRAY IN FREE SPACE -----
CASE "YAGI" : ObjectiveFunction = YAGI_ARRAY(R(),Nd%,p%,j&) 'FREE SPACE YAGI ARRAY

```

```

END SELECT
END FUNCTION 'ObjectiveFunction()
'-----
SUB GetFunctionRunParameters(FunctionName$,Nd%,Np%,Nt&,G,DeltaT,Alpha,Beta,Frep,R(),A(),M(),_
DiagLength,PlaceInitialProbes$,InitialAccelerations,RepositionFactors$)
LOCAL i%, NumProbesPerDimension%, NN%, NumCollinearElements%
LOCAL AS$
SELECT CASE FunctionName$
CASE "ParrottF4"
Nd% = 1 : Np% = 3
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : XiMin(1) = 0## : XiMax(1) = 1##
NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
CASE "SGO"
Nd% = 2 : Np% = 8
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -50## : XiMax(i%) = 50## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "GP"
Nd% = 2 : Np% = 8
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -100## : XiMax(i%) = 100## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "STEP"
Nd% = 2 : Np% = 8
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -100## : XiMax(i%) = 100## : NEXT i%
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : XiMin(1) = 72## : XiMax(1) = 78## : XiMin(2) = 27## : XiMax(2) = 33## 'use this to plot STEP detail
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "SCHWEFEL_226"
Nd% = 30 : Np% = 120
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -500## : XiMax(i%) = 500## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "COLVILLE"
Nd% = 4 : Np% = 16
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -10## : XiMax(i%) = 10## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "GRIEWANK"
Nd% = 2 : Np% = 8
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -600## : XiMax(i%) = 600## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "HIMMELBLAU"
Nd% = 2 : Np% = 8
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -6## : XiMax(i%) = 6## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "ROSENBROCK" '(n-D)
Nd% = 2 : Np% = 8
: NEXT i%
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -2## : XiMax(i%) = 2## : NEXT i% : XiMin(i%) = -6## : XiMax(i%) = 6##
NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
CASE "SPHERE" '(n-D)
Nd% = 2 : Np% = 8
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -100## : XiMax(i%) = 100## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "HIMMELBLAUNLO" '(5-D)
Nd% = 5 : Np% = 20
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%)
XiMin(1) = 78## : XiMax(1) = 102##
XiMin(2) = 33## : XiMax(2) = 45##
XiMin(3) = 27## : XiMax(3) = 45##
XiMin(4) = 27## : XiMax(4) = 45##
XiMin(5) = 27## : XiMax(5) = 45##
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "TRIPOD" '(2-D)
Nd% = 2 : Np% = 8
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -100## : XiMax(i%) = 100## : NEXT i%

```

```

NEXT i%      REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
CASE "ROSENBROCKF6" '(10-D)
Nd% = 10
Np% = 40
REDIM XiOffset(1 TO Nd%)
'
'      XiOffset(1) = 81.0232##
'      XiOffset(2) = -48.3950##
'      XiOffset(3) = 19.2316##
'      XiOffset(4) = -2.5231##
'      XiOffset(5) = 70.4338##
'      XiOffset(6) = 47.1774##
'      XiOffset(7) = -7.8358##
'      XiOffset(8) = -86.6693##
'      XiOffset(9) = 57.8532##
'      XiOffset(10) = 0##
'
'      XiOffset(1) = 80##
'      XiOffset(2) = -50##
'      XiOffset(3) = 20##
'      XiOffset(4) = -3##
'      XiOffset(5) = 70##
'      XiOffset(6) = 47##
'      XiOffset(7) = -8##
'      XiOffset(8) = -87##
'      XiOffset(9) = 58##
'      XiOffset(10) = 0##
'
'      XiOffset(1) = 5##
'      XiOffset(2) = -25##
'      XiOffset(3) = 5##
'      XiOffset(4) = -15##
'      XiOffset(5) = 5##
'      XiOffset(6) = -25##
'      XiOffset(7) = 25##
'      XiOffset(8) = -5##
'      XiOffset(9) = 5##
'      XiOffset(10) = -15##
'
'      XiOffset(1) = 0##
'      XiOffset(2) = 81.0232##
'      XiOffset(3) = -48.3950##
'      XiOffset(4) = 19.2316##
'      XiOffset(5) = -2.5231##
'      XiOffset(6) = 70.4338##
'      XiOffset(7) = 47.1774##
'      XiOffset(8) = -7.8358##
'      XiOffset(9) = -86.6693##
'      XiOffset(10) = 57.8532##
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -100## : XiMax(i%) = 100## : NEXT i%
NEXT i%      REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
CASE "COMPRESSIONSPRING" '(3-D)
Nd% = 3 : Np% = 12
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%)
XiMin(1) = 1##      : XiMax(1) = 70## 'integer values only!!
XiMin(2) = 0.6##   : XiMax(2) = 3##
XiMin(3) = 0.207## : XiMax(3) = 0.5##
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "GEARTRAIN" '(4-D)
Nd% = 4 : Np% = 16
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = 12# : XiMax(i%) = 60## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "F1" '(n-D)
Nd% = 30 : Np% = 60
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -100## : XiMax(i%) = 100## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "F2" '(n-D)
Nd% = 30 : Np% = 60
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -10## : XiMax(i%) = 10## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "F3" '(n-D)
Nd% = 30 : Np% = 60
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -100## : XiMax(i%) = 100## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "F4" '(n-D)
Nd% = 30 : Np% = 60
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -100## : XiMax(i%) = 100## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "F5" '(n-D)
Nd% = 30 : Np% = 60
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = -30## : XiMax(i%) = 30## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%
CASE "F6" '(n-D) STEP
Nd% = 30 : Np% = 60

```



```

Nd% = 6 : Np% = 24
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = 0## : XiMax(i%) = 1## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%

CASE "F21" '(4-D) Shekel's Family m=5
Nd% = 4 : Np% = 16
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = 0## : XiMax(i%) = 10## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%

CASE "F22" '(4-D) Shekel's Family m=7
Nd% = 4 : Np% = 16
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = 0## : XiMax(i%) = 10## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%

CASE "F23" '(4-D) Shekel's Family m=10
Nd% = 4 : Np% = 16
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = 0## : XiMax(i%) = 10## : NEXT i%
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%

CASE "PBM_1" '2-D
Nd% = 2
NumProbesPerDimension% = 2 '4 '20
Np% = NumProbesPerDimension%*Nd%

Nt& = 100
G = 2##
Alpha = 2##
Beta = 2##
DeltaT = 1##
Frep = 0.5##

PlaceInitialProbes$ = "UNIFORM ON-AXIS"
InitialAcceleration$ = "ZERO"
RepositionFactor$ = "VARIABLE" "'FIXED"

Np% = NumProbesPerDimension%*Nd%
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%)

XiMin(1) = 0.5## : XiMax(1) = 3## 'dipole length, L, in Wavelengths
XiMin(2) = 0## : XiMax(2) = Pi2 'polar angle, Theta, in Radians
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%

NN% = FREEFILE : OPEN "INFILE.DAT" FOR OUTPUT AS #NN% : PRINT #NN%,"PBM1.NEC" : PRINT #NN%,"PBM1.OUT" : CLOSE #NN% 'NEC Input/Output Files

CASE "PBM_2" '2-D
AddNoiseToPBM2$ = "NO" "'YES" "'NO" "'YES"

Nd% = 2
NumProbesPerDimension% = 4 '20
Np% = NumProbesPerDimension%*Nd%

Nt& = 100
G = 2##
Alpha = 2##
Beta = 2##
DeltaT = 1##
Frep = 0.5##

PlaceInitialProbes$ = "UNIFORM ON-AXIS"
InitialAcceleration$ = "ZERO"
RepositionFactor$ = "VARIABLE" "'FIXED"

Np% = NumProbesPerDimension%*Nd%
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%)

XiMin(1) = 5## : XiMax(1) = 15## 'dipole separation, D, in Wavelengths
XiMin(2) = 0## : XiMax(2) = Pi 'polar angle, Theta, in Radians
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%

NN% = FREEFILE : OPEN "INFILE.DAT" FOR OUTPUT AS #NN% : PRINT #NN%,"PBM2.NEC" : PRINT #NN%,"PBM2.OUT" : CLOSE #NN%

CASE "PBM_3" '2-D
Nd% = 2
NumProbesPerDimension% = 4 '20
Np% = NumProbesPerDimension%*Nd%

Nt& = 100
G = 2##
Alpha = 2##
Beta = 2##
DeltaT = 1##
Frep = 0.5##

PlaceInitialProbes$ = "UNIFORM ON-AXIS"
InitialAcceleration$ = "ZERO"
RepositionFactor$ = "VARIABLE" "'FIXED"

Np% = NumProbesPerDimension%*Nd%
REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%)

XiMin(1) = 0## : XiMax(1) = 4## 'Phase Parameter, Beta (0-4)
XiMin(2) = 0## : XiMax(2) = Pi 'polar angle, Theta, in Radians
REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%

NN% = FREEFILE : OPEN "INFILE.DAT" FOR OUTPUT AS #NN% : PRINT #NN%,"PBM3.NEC" : PRINT #NN%,"PBM3.OUT" : CLOSE #NN%

CASE "PBM_4" '2-D
Nd% = 2
NumProbesPerDimension% = 4 '6 '2 '4 '20
Np% = NumProbesPerDimension%*Nd%

```

```

Nt&      = 100
G        = 2##
Alpha    = 2##
Beta     = 2##
DeltaT   = 1##
Frep     = 0.5##

PlaceInitialProbes$ = "UNIFORM ON-AXIS"
InitialAcceleration$ = "ZERO"
RepositionFactor$   = "VARIABLE" "'FIXED"

Np% = NumProbesPerDimension%*Nd%

REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%)

XiMin(1) = 0.5## : XiMax(1) = 1.5## 'ARM LENGTH (NOT Total Length), wavelengths (0.5-1.5)
XiMin(2) = Pi/18## : XiMax(2) = Pi/2## 'Inner angle, Alpha, in Radians (Pi/18-Pi/2)

REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%

NN% = FREEFILE : OPEN "INFILE.DAT" FOR OUTPUT AS #NN% : PRINT #NN%, "PBM4.NEC" : PRINT #NN%, "PBM4.OUT" : CLOSE #NN%

CASE "PBM_5"

NumCollinearElements% = 6 '30 'EVEN or ODD: 6,7,10,13,16,24 used by PBM

Nd% = NumCollinearElements% - 1
Np% = NumProbesPerDimension%*Nd%

Nt&      = 100
G        = 2##
Alpha    = 2##
Beta     = 2##
DeltaT   = 1##
Frep     = 0.5##

PlaceInitialProbes$ = "UNIFORM ON-AXIS"
InitialAcceleration$ = "ZERO"
RepositionFactor$   = "VARIABLE" "'FIXED"

Nd% = NumCollinearElements% - 1
Np% = NumProbesPerDimension%*Nd%

REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : XiMin(i%) = 0.5## : XiMax(i%) = 1.5## : NEXT i%

REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%) : FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) :
NEXT i%

NN% = FREEFILE : OPEN "INFILE.DAT" FOR OUTPUT AS #NN% : PRINT #NN%, "PBM5.NEC" : PRINT #NN%, "PBM5.OUT" : CLOSE #NN%

===== END PBM BENCHMARKS =====

CASE "BOWTIE" 'FREE SPACE LOADED BOWTIE

----- Check for NEC Executable -----
IF DIR$("NEC41D_4K_053011.EXE") = "" THEN
  MSGBOX("WARNING! NEC4.1D executable NEC41D_4K_053011.EXE not found!"+CHR$(13)+CHR$(13)+_
    RUN TERMINATED.")+CHR$(13)+CHR$(13)
  EXIT SUB
END IF

----- Get Segmentation -----
IF DIR$("BowtieSeg.TXT") = "" THEN 'create BowtieSeg.TXT if it doesn't exist
  NN% = FREEFILE : OPEN "BowtieSeg.TXT" FOR OUTPUT AS NN% : PRINT #NN%, "Variable" : PRINT #NN%, "0.05" : CLOSE #NN%
END IF
NN% = FREEFILE : OPEN "BowtieSeg.TXT" FOR INPUT AS NN% : INPUT #NN%, BowtieSegmentLengthwVln : CLOSE #NN%
IF INSTR(UCASE$(BowtieSegmentLength$), "V") > 0 THEN BowtieSegmentLength$ = "VARIABLE"
IF INSTR(UCASE$(BowtieSegmentLength$), "F") > 0 THEN BowtieSegmentLength$ = "FIXED"
IF INSTR(UCASE$(BowtieSegmentLength$), "V") = 0 AND INSTR(UCASE$(BowtieSegmentLength$), "F") = 0 THEN BowtieSegmentLength$ = "VARIABLE"
IF BowtieSegmentLengthwVln < 0.02## OR BowtieSegmentLengthwVln > 0.2## THEN BowtieSegmentLengthwVln = 0.05## 'range 0.02-0.2 wavelengths

----- Get Bowtie Fitness Function Coefficients ----- NOTE: OPTIONALLY USED IN FITNESS FUNCTION (SEE BOWTIE FUNCTION FOR ACTUAL CALCULATION)
REDIM BowtieFitnessCoefficients(1 TO 3)
IF DIR$("BowtieCoeff.TXT") = "" THEN 'create BowtieCoeff.TXT if it doesn't exist
  NN% = FREEFILE : OPEN "BowtieCoeff.TXT" FOR OUTPUT AS NN% : PRINT #NN%, "40" : PRINT #NN%, "2" : PRINT #NN%, "3" : CLOSE #NN%
END IF
NN% = FREEFILE
OPEN "BowtieCoeff.TXT" FOR INPUT AS NN%
  INPUT #NN%, BowtieFitnessCoefficients(1) : INPUT #NN%, BowtieFitnessCoefficients(2) : INPUT #NN%, BowtieFitnessCoefficients(3)
CLOSE #NN%

BowtieCoefficients$ = "A="+REMOVE$(STR$(BowtieFitnessCoefficients(1)), ANY" ") +_
  " B="+REMOVE$(STR$(BowtieFitnessCoefficients(2)), ANY" ") +_
  " C="+REMOVE$(STR$(BowtieFitnessCoefficients(3)), ANY" ")

'BOWTIE DECISION SPACE BOUNDARY ARRAY:

Array Element #      Design Variable
-----
1      Bowtie atm length (wavelengths)
2      Bowtie HALF angle (degrees)
3      Loading segment number #1
4      Loading resistance #1 (ohms)
5      Zo

Nd% = 5 'FIXED DIMENSIONALITY BASED ON ABOVE DESIGN PARAMETERS

REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%)

XiMin(1) = 0.01## : XiMax(1) = 0.08## 'min/max arm length (METERS) (>~1/4-wave at 1 GHz)
XiMin(2) = 10## : XiMax(2) = 80## 'min/max HALF angle (degrees)
XiMin(3) = 1 : XiMax(3) = 9 'min/max loading segment number #1 (NOTE FIXED SEGMENTATION AT 9 SEGS !!!)
XiMin(4) = 1## : XiMax(4) = 1000## 'min/max loading resistance, R1 (ohms)
XiMin(5) = 50## : XiMax(5) = 1000## 'Zo, ohms

REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%)
FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) : NEXT i%

NN% = FREEFILE : OPEN "INFILE.DAT" FOR OUTPUT AS #NN% : PRINT #NN%, "BOWTIE.NEC" : PRINT #NN%, "BOWTIE.OUT" : CLOSE #NN%

===== END BOWTIE =====

CASE "YAGI" 'FREE SPACE YAGI ARRAY

----- Check for NEC Executable -----
IF DIR$("NEC41D_4K_053011.EXE") = "" THEN
  MSGBOX("WARNING! NEC4.1D executable NEC41D_4K_053011.EXE not found!"+CHR$(13)+CHR$(13)+_
    RUN TERMINATED.")+CHR$(13)+CHR$(13)
  EXIT SUB
END IF

----- Get Segmentation -----
IF DIR$("YagiSeg.TXT") = "" THEN 'create YagiSeg.TXT if it doesn't exist
  NN% = FREEFILE : OPEN "YagiSeg.TXT" FOR OUTPUT AS NN% : PRINT #NN%, "Variable" : PRINT #NN%, "0.05" : CLOSE #NN%

```



```

END IF
NN% = FREEFILE : OPEN "YagiSeg.TXT" FOR INPUT AS NN% : INPUT #NN%,YagiSegmentLength$ : INPUT #NN%,YagiSegmentLengthwvln : CLOSE #NN%
IF INSTR(UCASE$(YagiSegmentLength$), "V") > 0 THEN YagiSegmentLength$ = "VARIABLE"
IF INSTR(UCASE$(YagiSegmentLength$), "F") > 0 THEN YagiSegmentLength$ = "FIXED"
IF INSTR(UCASE$(YagiSegmentLength$), "V") = 0 AND INSTR(UCASE$(YagiSegmentLength$), "F") = 0 THEN YagiSegmentLength$ = "VARIABLE"
IF YagiSegmentLengthwvln < 0.02## OR YagiSegmentLengthwvln > 0.2## THEN YagiSegmentLengthwvln = 0.05## "range 0.02-0.2 wavelengths"
'
----- Get Yagi Fitness Function Coefficients -----
REDIM YagiFitnessCoefficients(1 TO 4)
IF DIR$( "YagiCoeff.TXT") = "" THEN 'create YagiCoeff.TXT if it doesn't exist
'A=20, B=2, C=3, D=4.
NN% = FREEFILE : OPEN "YagiCoeff.TXT" FOR OUTPUT AS NN% : PRINT #NN%,"20" : PRINT #NN%,"2" : PRINT #NN%,"3" : PRINT #NN%,"4" : CLOSE
#NN%
END IF
NN% = FREEFILE
OPEN "YagiCoeff.TXT" FOR INPUT AS NN%
INPUT #NN%,YagiFitnessCoefficients(1) : INPUT #NN%,YagiFitnessCoefficients(2) : INPUT #NN%,YagiFitnessCoefficients(3) : INPUT
#NN%,YagiFitnessCoefficients(4)
CLOSE #NN%

YagiCoefficients$ = "A="+REMOVE$(STR$(YagiFitnessCoefficients(1)),ANY" ") +_
" B="+REMOVE$(STR$(YagiFitnessCoefficients(2)),ANY" ") +_
" C="+REMOVE$(STR$(YagiFitnessCoefficients(3)),ANY" ") +_
" D="+REMOVE$(STR$(YagiFitnessCoefficients(4)),ANY" ")
'
----- # Array Elements -----
AS = INPUTBOX$ (" # Array Elements", "YAGI ELEMENTS", "5")
NumYagiElements% = VAL(AS)
Nd% = 2*NumYagiElements% 'spacing and length are the two optimization parameters defining each element
Nd% = Nd%+1 'INCREASE DECISION SPACE DIMENSION TO ADD Zo AS A DESIGN <<<VARIABLE>>>.
'YAGI DECISION SPACE BOUNDARY ARRAY:
'
' Array Element # Design Variable
'-----
' 1
' TO Yagi element spacing along boom from previous element, wavelengths
' NumYagiElements
' NumYagiElements+1
' TO Yagi element length, wavelengths
' 2*NumYagiElements (Nd-1)
' Nd <<<< Zo >>>>
' REDIM XiMin(1 TO Nd%), XiMax(1 TO Nd%) ' <<<<<<<< FOLLOWING BOUNDS ARE FOR ZEPP ELEMENTS !!! >>>>>>>>>
' XiMin(1) = 0## : XiMax(1) = 0## : FOR i% = 2 TO NumYagiElements% : XiMin(i%) = 0.1## : XiMax(i%) = 0.5## : NEXT i% 'min/max SPACING, wvln
' [NOTE: XiMin/max(1)=0 ALWAYS BECAUSE FIRST ELEMENT, REFLECTOR, IS AT X=0 (no spacing)]
' XiMin(NumYagiElements%+1) = 0.2## : XiMax(NumYagiElements%+1) = 0.6## 'min/max RREFLECTOR length, waves
' XiMin(NumYagiElements%+2) = 0.2## : XiMax(NumYagiElements%+2) = 0.6## 'min/max DRIVEN ELEMENT length, waves
' FOR i% = NumYagiElements% + 3 TO Nd%-1
' XiMin(i%) = 0.2## : XiMax(i%) = 0.6## 'min/max DIRECTOR lengths, waves
' NEXT i%
' XiMin(Nd%) = 5## : XiMax(i%) = 600## 'min/max values of Zo (OHMS)
' REDIM StartingXiMin(1 TO Nd%), StartingXiMax(1 TO Nd%)
' FOR i% = 1 TO Nd% : StartingXiMin(i%) = XiMin(i%) : StartingXiMax(i%) = XiMax(i%) : NEXT i%
' NN% = FREEFILE : OPEN "INFILE.DAT" FOR OUTPUT AS #NN% : PRINT #NN%,"YAGI.NEC" : PRINT #NN%,"YAGI.OUT" : CLOSE #NN%
'
' ===== END YAGI =====
'
' NOTE - DON'T FORGET TO ADD NEW TEST FUNCTIONS TO FUNCTION objectiveFunction() ABOVE !!
'
' =====
'
END SELECT
IF Nd% > 100 THEN Nt% = MIN(Nt%,200) 'to avoid array dimensioning problems
DiagLength = 0## : FOR i% = 1 TO Nd% : DiagLength = DiagLength + (XiMax(i%)-XiMin(i%))^2 : NEXT i% : DiagLength = SQR(DiagLength) 'compute length of
decision space principal diagonal
END SUB 'GetFunctionRunParameters()
'-----
FUNCTION ParrottF4(R(),Nd%,p%,j%) 'Parrott F4 (1-D)
'MAXIMUM = 1 AT -0.0796875... WITH ZERO OFFSET (SEEMS TO WORK BEST WITH JUST 3 PROBES, BUT NOT ALLOWED IN THIS VERSION...)
'References:
'Beasley, D., D. R. Bull, and R. R. Martin, "A Sequential Niche Technique for Multimodal
'Function Optimization," Evol. Comp. (MIT Press), vol. 1, no. 2, 1993, pp. 101-125
'(online at http://citeseer.1st.psu.edu/beasley93sequential.html).
'Parrott, D., and X. Li, "Locating and Tracking Multiple Dynamic Optima by a Particle Swarm
'Model Using Speciation," IEEE Trans. Evol. Computation, vol. 10, no. 4, Aug. 2006, pp. 440-458.
LOCAL Z, x, offset AS EXT
offset = 0##
x = R(p%,1,j%)
Z = EXP(-2##*LOG(2##)*((x-0.08##-offset)/0.854##)^2)*(SIN(5##*Pi*((x-offset)^0.75##-0.05##)))^6 'WARNING! This is a NATURAL LOG, NOT Log10!!!
ParrottF4 = Z
END FUNCTION 'ParrottF4()
'-----
FUNCTION SGO(R(),Nd%,p%,j%) 'SGO Function (2-D)
'MAXIMUM = ~130.8323226... @ ~(-2.8362075..., -2.8362075...) WITH ZERO OFFSET.
'Reference:
'Hsiao, Y., Chuang, C., Jiang, J., and Chien, C., "A Novel Optimization Algorithm: Space
'Gravitational Optimization," Proc. of 2005 IEEE International Conference on Systems, Man,
'and Cybernetics, 3, 2323-2328. (2005)
LOCAL x1, x2, Z, t1, t2, SGOx1offset, SGOx2offset AS EXT
SGOx1offset = 0## : SGOx2offset = 0##
' SGOx1offset = 40## : SGOx2offset = 10##

```

```

x1 = R(p%,1,j&) - SG0x1offset : x2 = R(p%,2,j&) - SG0x2offset
t1 = x1^4 - 16##*x1^2 + 0.5##*x1 : t2 = x2^4 - 16##*x2^2 + 0.5##*x2
Z = t1 + t2
SG0 = -Z
END FUNCTION 'SG0()
'-----
FUNCTION GoldsteinPrice(R(),Nd%,p%,j&) 'Goldstein-Price Function (2-D)
'MAXIMUM = -3 @ (0,-1) WITH ZERO OFFSET.
'Reference:
'Cui, Z., Zeng, J., and Sun, G. (2006) 'A Fast Particle Swarm Optimization,' Int'l. J.
'Innovative Computing, Information and Control, vol. 2, no. 6, December, pp. 1365-1380.
LOCAL Z, x1, x2, offset1, offset2, t1, t2 AS EXT
offset1 = 0## : offset2 = 0##
offset1 = 20## : offset2 = -10##
x1 = R(p%,1,j&)-offset1 : x2 = R(p%,2,j&)-offset2
t1 = 1##+(x1+x2+1##)^2*(19##-14##*x1+3##*x1^2-14##*x2+6##*x1*x2+3##*x2^2)
t2 = 30##+(2##*x1-3##*x2)^2*(18##-32##*x1+12##*x1^2+48##*x2-36##*x1*x2+27##*x2^2)
Z = t1*t2
GoldsteinPrice = -Z
END FUNCTION 'GoldsteinPrice()
'-----
FUNCTION StepFunction(R(),Nd%,p%,j&) 'Step Function (n-D)
'MAXIMUM VALUE = 0 @ [Offset]^n.
'Reference:
'Yao, X., Liu, Y., and Lin, G., "Evolutionary Programming Made Faster,"
'IEEE Trans. Evolutionary Computation, Vol. 3, No. 2, 82-102, Jul. 1999.
LOCAL Offset, Z AS EXT
LOCAL i%
Z = 0## : Offset = 0## '75.123## '0##
FOR i% = 1 TO Nd%
IF Nd% = 2 AND i% = 1 THEN Offset = 75 '75##
IF Nd% = 2 AND i% = 2 THEN Offset = 35 '30 '35##
Z = Z + INT((R(p%,i%,j&)-Offset) + 0.5##)^2
NEXT i%
StepFunction = -Z
END FUNCTION 'StepFunction()
'-----
FUNCTION Schwefel226(R(),Nd%,p%,j&) 'Schwefel Problem 2.26 (n-D)
'MAXIMUM = 12,569.5 @ [420.8687]^30 (30-D CASE).
'Reference:
'Yao, X., Liu, Y., and Lin, G., "Evolutionary Programming Made Faster,"
'IEEE Trans. Evolutionary Computation, Vol. 3, No. 2, 82-102, Jul. 1999.
LOCAL Z, Xi AS EXT
LOCAL i%
Z = 0##
FOR i% = 1 TO Nd%
Xi = R(p%,i%,j&)
Z = Z + Xi*SIN(SQR(ABS(Xi)))
NEXT i%
Schwefel226 = Z
END FUNCTION 'SCHWEFEL226()
'-----
FUNCTION Colville(R(),Nd%,p%,j&) 'Colville Function (4-D)
'MAXIMUM = 0 @ (1,1,1,1) WITH ZERO OFFSET.
'Reference:
'Doo-Hyun, and Se-Young, O., "A New Mutation Rule for Evolutionary Programming Motivated from
'Backpropagation Learning," IEEE Trans. Evolutionary Computation, Vol. 4, No. 2, pp. 188-190,
'July 2000.
LOCAL Z, x1, x2, x3, x4, offset AS EXT
offset = 0## '7.123##
x1 = R(p%,1,j&)-offset : x2 = R(p%,2,j&)-offset : x3 = R(p%,3,j&)-offset : x4 = R(p%,4,j&)-offset
Z = 100##*(x2-x1^2)^2 + (1##-x1)^2 + -
90##*(x4-x3^2)^2 + (1##-x3)^2 + -
10.1##*((x2-1##)^2 + (x4-1##)^2) + -
19.8##*(x2-1##)*(x4-1##)
Colville = -Z
END FUNCTION 'colville()
'-----

```

```

FUNCTION Griewank(R(),Nd%,p%,j&) 'Griewank (n-D)
'Max of zero at (0,...,0)
'Reference: Yao, X., Liu, Y., and Lin, G., "Evolutionary Programming Made Faster,"
'IEEE Trans. Evolutionary Computation, Vol. 3, No. 2, 82-102, Jul. 1999.

    LOCAL Offset, Sum, Prod, Z, Xi AS EXT
    LOCAL i%
    Sum = 0## : Prod = 1##
    Offset = 75.123##
    FOR i% = 1 TO Nd%
        Xi = R(p%,i%,j&) - Offset
        Sum = Sum + Xi^2
        Prod = Prod*COS(Xi/SQR(i%))
    NEXT i%
    Z = Sum/4000## - Prod + 1##
    Griewank = -Z
END FUNCTION 'Griewank()
'-----

FUNCTION Himmelblau(R(),Nd%,p%,j&) 'Himmelblau (2-D)
    LOCAL Z, x1, x2, offset AS EXT
    offset = 0##
    x1 = R(p%,1,j&)-offset : x2 = R(p%,2,j&)-offset
    Z = 200## - (x1^2 + x2 -11##)^2 - (x1+x2^2-7##)^2
    Himmelblau = Z
END FUNCTION 'Himmelblau()
'-----

FUNCTION Rosenbrock(R(),Nd%,p%,j&) 'Rosenbrock (n-D)
'MAXIMUM = 0 @ [1,...,1]^n (n-D CASE).
'Reference: Yao, X., Liu, Y., and Lin, G., "Evolutionary Programming Made Faster,"
'IEEE Trans. Evolutionary Computation, Vol. 3, No. 2, 82-102, Jul. 1999.

    LOCAL Z, Xi, Xi1 AS EXT
    LOCAL i%
    Z = 0##
    FOR i% = 1 TO Nd%-1
        Xi = R(p%,i%,j&) : Xi1 = R(p%,i%+1,j&)
        Z = Z + 100##*(Xi-Xi1)^2 + (Xi-1##)^2
    NEXT i%
    Rosenbrock = -Z
END FUNCTION 'ROSENBRCK()
'-----

FUNCTION Sphere(R(),Nd%,p%,j&) 'Sphere (n-D)
'MAXIMUM = 0 @ [0,...,0]^n (n-D CASE).
'Reference: Yao, X., Liu, Y., and Lin, G., "Evolutionary Programming Made Faster,"
'IEEE Trans. Evolutionary Computation, Vol. 3, No. 2, 82-102, Jul. 1999.

    LOCAL Z, Xi, Xi1 AS EXT
    LOCAL i%
    Z = 0##
    FOR i% = 1 TO Nd%
        Xi = R(p%,i%,j&)
        Z = Z + Xi^2
    NEXT i%
    Sphere = -Z
END FUNCTION 'SPHERE()
'-----

FUNCTION HimmelblauNLO(R(),Nd%,p%,j&) 'Himmelblau non-linear optimization (5-D)
'MAXIMUM ~ 31025.5562644972 @ (78.0,33.0,27.0709971052,45.0,44.9692425501)
'Reference: "Constrained Optimization using CODEQ," Mahamed G.H. Omran & Ayed Salman,
'Chaos, Solitons and Tractals, 42(2009), 662-668

    LOCAL Z, x1, x2, x3, x4, x5, g1, g2, g3 AS EXT
    Z = 1E4200
    x1 = R(p%,1,j&) : x2 = R(p%,2,j&) : x3 = R(p%,3,j&) : x4 = R(p%,4,j&) : x5 = R(p%,5,j&)
    g1 = 85.334407## + 0.0056858##*x2^2*x5 + 0.00026##*x1^4 - 0.0022053##*x3^2*x5
    g2 = 80.51249## + 0.0071317##*x2^2*x5 + 0.0029955##*x1^2*x2 + 0.0021813##*x3^2*x3
    g3 = 9.300961## + 0.0047026##*x3^2*x5 + 0.0012547##*x1^2*x3 + 0.0019085##*x3^2*x4
    IF g1## < 0 OR g1 > 92## OR g2 < 90## OR g2 > 110## OR g3 < 20## OR g3 > 25## THEN GOTO ExitHimmelblauNLO
    Z = 5.3578547##*x3^2*x3 + 0.8356891##*x1^2*x5 + 37.29329##*x1 - 40792.141##

```

```

ExitHimmelblauNLO:
  HimmelblauNLO = -Z
END FUNCTION 'HimmelblauNLO()
'-----
FUNCTION Tripod(R(),Nd%,p%,j&) 'Tripod (2-D)
'MAXIMUM = 0 at (0,-50)
'Reference: "Appendix: A mini-benchmark," Maurice Clerc
  LOCAL Z, x1, x2, s1, s2, t1, t2, t3 AS EXT
  x1 = R(p%,1,j&) : x2 = R(p%,2,j&)
  s1 = Sign(x1) : s2 = Sign(x2)
  t1 = (1##-s2)*(ABS(x1)+ABS(x2+50##))
  t2 = 0.5##*(1##+s2)*(1##-s1)*(1##+ABS(x1+50##)+ABS(x2-50##))
  t3 = (1##+s1)*(2##+ABS(x1-50##)+ABS(x2-50##))
  Z = 0.5##*(t1 + t2 + t3)
  Tripod = -Z
END FUNCTION 'Tripod()
'-----
FUNCTION Sign(X)
LOCAL Z AS EXT
  Z = 1## : IF X <= 0## THEN Z = -1##
  Sign = Z
END FUNCTION
'-----
FUNCTION RosenbrockF6(R(),Nd%,p%,j&) 'Rosenbrock F6 (10-D)
'WARNING !! 03-19-10 THIS FUNCTION CONTAINS ERRORS. SEE CLERC'S EMAIL!
'MAXIMUM = 394 at (0,-50)
'Reference: "Appendix: A mini-benchmark," Maurice Clerc (NOTE: Uses his notation...)
  LOCAL Z, Xi, Xi1, Zi, Zi1, Sum AS EXT
  LOCAL i%
  Sum = 0##
  FOR i% = 2 TO Nd%
    Xi = R(p%,i%,j&) : Xi1 = R(p%,i%-1,j&)
    Zi = Xi - XiOffset(i%) + 1## : Zi1 = Xi1 - XiOffset(i%-1) + 1##
    Sum = Sum + 100##*(Zi1^2-Zi)^2 + (Zi1-1##)^2
  NEXT i%
  Z = 390## + Sum
  RosenbrockF6 = -Z
END FUNCTION 'RosenbrockF6()
'-----
FUNCTION CompressionSpring(R(),Nd%,p%,j&) 'Compression Spring (3-D)
'MAXIMUM = 394 at (0,-50)
'Reference: "Appendix: A mini-benchmark," Maurice Clerc (NOTE: Uses his notation...)
LOCAL Z, x1, x2, x3, g1, g2, g3, g4, g5, Cf, Fmax, S, Lf, Lmax, SigP, SigPM, Fp, K, SigW AS EXT
Z = 1E4200
x1 = ROUND(R(p%,1,j&),0) : x2 = R(p%,2,j&) : x3 = ROUND(R(p%,3,j&),3)
Cf = 1## + 0.75##*x3/(x2-x3)+0.615##*x3/x2
Fmax = 1000## : S = 189000## : Lmax = 14## : SigPM = 6## : Fp = 300## : SigW = 1.25##
K = 11.5##*1E6*x3^4/(8##*x1*x2^3)
Lf = Fmax/K + 1.05##*(x1+2##)*x3
SigP = Fp/K
g1 = 8##*Cf*Fmax*x2/(Pi*x3^3) - S
g2 = Lf - Lmax
g3 = SigP - SigPM
g4 = SigP - Fp/K 'WARNING! 03-19-10. THIS IS SATISFIED EXACTLY (SEE CLERC'S EMAIL - TYPO IN HIS BENCHMARKS)
g5 = SigW - (Fmax-Fp)/K
IF g1 > 0## OR g2 > 0## OR g3 > 0## OR g4 > 0## OR g5 > 0## THEN GOTO ExitCompressionSpring
Z = Pi^2*x2*x3^2*(x1+1##)/4##
ExitCompressionSpring:
  CompressionSpring = -Z
END FUNCTION 'CompressionSpring
'-----
FUNCTION GearTrain(R(),Nd%,p%,j&) 'GearTrain (4-D)
'MAXIMUM = 394 at (0,-50)
'Reference: "Appendix: A mini-benchmark," Maurice Clerc (NOTE: Uses his notation...)
LOCAL Z, x1, x2, x3, x4 AS EXT

```

```

x1 = ROUND(R(p%,1,j&),0) : x2 = ROUND(R(p%,2,j&),0)
x3 = ROUND(R(p%,3,j&),0) : x4 = ROUND(R(p%,4,j&),0)
Z = (1##/6.931##-x1*x2/(x3*x4))^2
GearTrain = -Z
END FUNCTION 'GearTrain
'-----
FUNCTION F1(R(),Nd%,p%,j&) 'F1 (n-D)
'MAXIMUM = ZERO (n-D CASE).
'Reference:
LOCAL Z, Xi AS EXT
LOCAL i%
Z = 0##
FOR i% = 1 TO Nd%
    Xi = R(p%,i%,j&)
    Z = Z + Xi^2
NEXT i%
F1 = -Z
END FUNCTION 'F1
'-----
FUNCTION F2(R(),Nd%,p%,j&) 'F2 (n-D)
'MAXIMUM = ZERO (n-D CASE).
'Reference:
LOCAL Sum, prod, Z, Xi AS EXT
LOCAL i%
Z = 0## : Sum = 0## : Prod = 1##
FOR i% = 1 TO Nd%
    Xi = R(p%,i%,j&)
    Sum = Sum+ ABS(Xi)
    Prod = Prod*ABS(Xi)
NEXT i%
Z = Sum + Prod
F2 = -Z
END FUNCTION 'F2
'-----
FUNCTION F3(R(),Nd%,p%,j&) 'F3 (n-D)
'MAXIMUM = ZERO (n-D CASE).
'Reference:
LOCAL Z, Xk, Sum AS EXT
LOCAL i%, k%
Z = 0##
FOR i% = 1 TO Nd%
    Sum = 0##
    FOR k% = 1 TO i%
        Xk = R(p%,k%,j&)
        Sum = Sum + Xk
    NEXT k%
    Z = Z + Sum^2
NEXT i%
F3 = -Z
END FUNCTION 'F3
'-----
FUNCTION F4(R(),Nd%,p%,j&) 'F4 (n-D)
'MAXIMUM = ZERO (n-D CASE).
'Reference:
LOCAL Z, Xi, MaxXi AS EXT
LOCAL i%
MaxXi = -1E4200
FOR i% = 1 TO Nd%
    Xi = R(p%,i%,j&)
    IF ABS(Xi) >= MaxXi THEN MaxXi = ABS(Xi)
NEXT i%
F4 = -MaxXi
END FUNCTION 'F4
'-----

```

```

FUNCTION F5(R(),Nd%,p%,j&) 'F5 (n-D)
'MAXIMUM = ZERO (n-D CASE).
'Reference:
  LOCAL Z, Xi, XiPlus1 AS EXT
  LOCAL i%
  Z = 0##
  FOR i% = 1 TO Nd%-1
    Xi = R(p%,i%,j&)
    XiPlus1 = R(p%,i%+1,j&)
    Z = Z + (100##*(XiPlus1-Xi^2)^2+(Xi-1##)^2)
  NEXT i%
  F5 = -Z
END FUNCTION 'F5
'-----
FUNCTION F6(R(),Nd%,p%,j&) 'F6 (n-D STEP)
'MAXIMUM VALUE = 0 @ [offset]^n.
'Reference:
'Yao, X., Liu, Y., and Lin, G., "Evolutionary Programming Made Faster,"
'IEEE Trans. Evolutionary Computation, Vol. 3, No. 2, 82-102, Jul. 1999.
  LOCAL Z AS EXT
  LOCAL i%
  Z = 0##
  FOR i% = 1 TO Nd%
    Z = Z + INT(R(p%,i%,j&) + 0.5##)^2
  NEXT i%
  F6 = -Z
END FUNCTION 'F6
'-----
FUNCTION F7(R(),Nd%,p%,j&) 'F7
'MAXIMUM VALUE = 0 @ [offset]^n.
'Reference:
'Yao, X., Liu, Y., and Lin, G., "Evolutionary Programming Made Faster,"
'IEEE Trans. Evolutionary Computation, Vol. 3, No. 2, 82-102, Jul. 1999.
  LOCAL Z, Xi AS EXT
  LOCAL i%
  Z = 0##
  FOR i% = 1 TO Nd%
    Xi = R(p%,i%,j&)
    Z = Z + i%*Xi^4
  NEXT i%
  F7 = -Z - RandomNum(0##,1##)
END FUNCTION 'F7
'-----
FUNCTION F8(R(),Nd%,p%,j&) '(n-D) F8 [Schwefel Problem 2.26]
'MAXIMUM = 12,569.5 @ [420.8687]^30 (30-D CASE).
'Reference:
'Yao, X., Liu, Y., and Lin, G., "Evolutionary Programming Made Faster,"
'IEEE Trans. Evolutionary Computation, Vol. 3, No. 2, 82-102, Jul. 1999.
  LOCAL Z, Xi AS EXT
  LOCAL i%
  Z = 0##
  FOR i% = 1 TO Nd%
    Xi = R(p%,i%,j&)
    Z = Z - Xi*SIN(SQR(ABS(Xi)))
  NEXT i%
  F8 = -Z
END FUNCTION 'F8
'-----
FUNCTION F9(R(),Nd%,p%,j&) '(n-D) F9 [Rastrigin]
'MAXIMUM = ZERO (n-D CASE).
'Reference:
'Yao, X., Liu, Y., and Lin, G., "Evolutionary Programming Made Faster,"
'IEEE Trans. Evolutionary Computation, Vol. 3, No. 2, 82-102, Jul. 1999.
  LOCAL Z, Xi AS EXT
  LOCAL i%
  Z = 0##

```

```

FOR i% = 1 TO Nd%
    Xi = R(p%,i%,j&)
    Z = Z + (Xi^2 - 10##*COS(TwoPi*Xi) + 10##)^2
NEXT i%
F9 = -Z
END FUNCTION 'F9
'-----
FUNCTION F10(R(),Nd%,p%,j&) '(n-D) F10 [Ackley's Function]
'MAXIMUM = ZERO (n-D CASE).
'Reference:
'Yao, X., Liu, Y., and Lin, G., "Evolutionary Programming Made Faster,"
'IEEE Trans. Evolutionary Computation, Vol. 3, No. 2, 82-102, Jul. 1999.
LOCAL Z, Xi, Sum1, Sum2 AS EXT
LOCAL i%
Z = 0## : Sum1 = 0## : Sum2 = 0##
FOR i% = 1 TO Nd%
    Xi = R(p%,i%,j&)
    Sum1 = Sum1 + Xi^2
    Sum2 = Sum2 + COS(TwoPi*Xi)
NEXT i%
Z = -20##*EXP(-0.2##*SQR(Sum1/Nd%)) - EXP(Sum2/Nd%) + 20## + e
F10 = -Z
END FUNCTION 'F10
'-----
FUNCTION F11(R(),Nd%,p%,j&) '(n-D) F11
'MAXIMUM = ZERO (n-D CASE).
'Reference:
'Yao, X., Liu, Y., and Lin, G., "Evolutionary Programming Made Faster,"
'IEEE Trans. Evolutionary Computation, Vol. 3, No. 2, 82-102, Jul. 1999.
LOCAL Z, Xi, Sum, Prod AS EXT
LOCAL i%
Z = 0## : Sum = 0## : Prod = 1##
FOR i% = 1 TO Nd%
    Xi = R(p%,i%,j&)
    Sum = Sum + (Xi-100##)^2
    Prod = Prod*COS((Xi-100##)/SQR(i%))
NEXT i%
Z = Sum/4000## - Prod + 1##
F11 = -Z
END FUNCTION 'F11
'-----
FUNCTION u(Xi,a,k,m)
LOCAL Z AS EXT
Z = 0##
SELECT CASE Xi
CASE > a : Z = k*(Xi-a)^m
CASE < -a : Z = k*(-Xi-a)^m
END SELECT
u = Z
END FUNCTION
'-----
FUNCTION F12(R(),Nd%,p%,j&) '(n-D) F12, Penalized #1
'Ref: Yao(1999). Max=0 @ (-1,-1,...,-1), -50=<Xi=<50.
LOCAL Offset, Sum1, Sum2, Z, X1, Y1, Xn, Yn, Xi, Yi, XiPlus1, YiPlus1 AS EXT
LOCAL i%, m%, A$
X1 = R(p%,1,j&) : Y1 = 1## + (X1+1##)/4##
Xn = R(p%,Nd%,j&) : Yn = 1## + (Xn+1##)/4##
Sum1 = 0##
FOR i% = 1 TO Nd%-1
    Xi = R(p%,i%,j&) : Yi = 1## + (Xi+1##)/4##
    XiPlus1 = R(p%,i%+1,j&) : YiPlus1 = 1## + (XiPlus1+1##)/4##
    Sum1 = Sum1 + (Yi-1##)^2*(1##+10##*(SIN(Pi*YiPlus1))^2)
NEXT i%
Sum1 = Sum1 + 10##*(SIN(Pi*Y1))^2 + (Yn-1##)^2
Sum1 = Pi*Sum1/Nd%

```

```

Sum2 = 0##
FOR i% = 1 TO Nd%
  Xi = R(p%,i%,j&)
  Sum2 = Sum2 + u(Xi,10##,100##,4##)
NEXT i%
Z = Sum1 + Sum2
F12 = -Z
END FUNCTION 'F12()
'-----
FUNCTION F13(R(),Nd%,p%,j&) '(n-D) F13, Penalized #2
'Ref: Yao(1999). Max=0 @ (1,1,...,1), -50<Xi<50.
LOCAL Offset, Sum1, Sum2, Z, Xi, Xn, XiPlus1, X1 AS EXT
LOCAL i%, m%, A$
X1 = R(p%,1,j&) : Xn = R(p%,Nd%,j&)
Sum1 = 0##
FOR i% = 1 TO Nd%-1
  Xi = R(p%,i%,j&) : XiPlus1 = R(p%,i%+1,j&)
  Sum1 = Sum1 + (Xi-1##)^2*(1##+(SIN(3##*Pi*XiPlus1))^2)
NEXT i%
Sum1 = Sum1 + (SIN(Pi*3##*X1))^2 +(Xn-1##)^2*(1##+(SIN(TwoPi*Xn))^2)
Sum2 = 0##
FOR i% = 1 TO Nd%
  Xi = R(p%,i%,j&)
  Sum2 = Sum2 + u(Xi,5##,100##,4##)
NEXT i%
Z = Sum1/10## + Sum2
F13 = -Z
END FUNCTION 'F13()
'-----
SUB FillArrayAij 'needed for function F14, Shekel's Foxholes
Aij(1,1)=-32## : Aij(1,2)=-16## : Aij(1,3)=0## : Aij(1,4)=16## : Aij(1,5)=32##
Aij(1,6)=-32## : Aij(1,7)=-16## : Aij(1,8)=0## : Aij(1,9)=16## : Aij(1,10)=32##
Aij(1,11)=-32## : Aij(1,12)=-16## : Aij(1,13)=0## : Aij(1,14)=16## : Aij(1,15)=32##
Aij(1,16)=-32## : Aij(1,17)=-16## : Aij(1,18)=0## : Aij(1,19)=16## : Aij(1,20)=32##
Aij(1,21)=-32## : Aij(1,22)=-16## : Aij(1,23)=0## : Aij(1,24)=16## : Aij(1,25)=32##
Aij(2,1)=-32## : Aij(2,2)=-32## : Aij(2,3)=-32## : Aij(2,4)=-32## : Aij(2,5)=-32##
Aij(2,6)=-16## : Aij(2,7)=-16## : Aij(2,8)=-16## : Aij(2,9)=-16## : Aij(2,10)=-16##
Aij(2,11)=0## : Aij(2,12)=0## : Aij(2,13)=0## : Aij(2,14)=0## : Aij(2,15)=0##
Aij(2,16)=-16## : Aij(2,17)=-16## : Aij(2,18)=-16## : Aij(2,19)=-16## : Aij(2,20)=-16##
Aij(2,21)=32## : Aij(2,22)=32## : Aij(2,23)=32## : Aij(2,24)=32## : Aij(2,25)=32##
END SUB
'-----
FUNCTION F14(R(),Nd%,p%,j&) 'F14 (2-D) Shekel's Foxholes (INVERTED...)
LOCAL Sum1, Sum2, Z, Xi AS EXT
LOCAL i%, jj%
Sum1 = 0##
FOR jj% = 1 TO 25
  Sum2 = 0##
  FOR i% = 1 TO 2
    Xi = R(p%,i%,j&)
    Sum2 = Sum2 + (Xi-Aij(i%,jj%))^6
  NEXT i%
  Sum1 = Sum1 + 1##/(jj%+Sum2)
NEXT jj%
Z = 1##/(0.002##+Sum1)
F14 = -Z
END FUNCTION 'F14
'-----
FUNCTION F16(R(),Nd%,p%,j&) 'F16 (2-D) 6-Hump Camel-Back
LOCAL x1, x2, Z AS EXT
x1 = R(p%,1,j&) : x2 = R(p%,2,j&)
Z = 4##*x1^2 - 2.1##*x1^4 + x1^6/3## + x1*x2 - 4*x2^2 + 4*x2^4
F16 = -Z
END FUNCTION 'F16
'-----
FUNCTION F15(R(),Nd%,p%,j&) 'F15 (4-D) Kowalik's Function
'Global maximum = -0.0003075 @ (0.1928,0.1908,0.1231,0.1358)
LOCAL x1, x2, x3, x4, Num, Denom, Z, Aj(), Bj() AS EXT
LOCAL jj%

```



```

REDIM Aj(1 TO 11), Bj(1 TO 11)
Aj(1) = 0.1957## : Bj(1) = 1##/0.25##
Aj(2) = 0.1947## : Bj(2) = 1##/0.50##
Aj(3) = 0.1735## : Bj(3) = 1##/1.00##
Aj(4) = 0.1600## : Bj(4) = 1##/2.00##
Aj(5) = 0.0844## : Bj(5) = 1##/4.00##
Aj(6) = 0.0627## : Bj(6) = 1##/6.00##
Aj(7) = 0.0456## : Bj(7) = 1##/8.00##
Aj(8) = 0.0342## : Bj(8) = 1##/10.0##
Aj(9) = 0.0323## : Bj(9) = 1##/12.0##
Aj(10) = 0.0235## : Bj(10) = 1##/14.0##
Aj(11) = 0.0246## : Bj(11) = 1##/16.0##

Z = 0##

x1 = R(p%,1,j&) : x2 = R(p%,2,j&) : x3 = R(p%,3,j&) : x4 = R(p%,4,j&)
FOR jj% = 1 TO 11
  Num = x1*(Bj(jj%))^2+Bj(jj%)*x2
  Denom = Bj(jj%)^2+Bj(jj%)*x3-x4
  Z = Z + (Aj(jj%)-Num/Denom)^2
NEXT jj%
F15 = -Z
END FUNCTION 'F15
'-----
FUNCTION F17(R(),Nd%,p%,j&) 'F17, (2-D) Branin
'Global maximum = -0.398 @ (-3.142,12.275), (3.142,2.275), (9.425,2.425)
LOCAL x1, x2, Z AS EXT
x1 = R(p%,1,j&) : x2 = R(p%,2,j&)
Z = (x2-5.1##*x1^2/(4##*Pi^2)+5##*x1/Pi-6##)^2 + 10##*(1##-1##/(8##*Pi))^2*cos(x1) + 10##
F17 = -Z
END FUNCTION 'F17
'-----
FUNCTION F18(R(),Nd%,p%,j&) 'Goldstein-Price 2-D Test Function
'Global maximum = -3 @ (0,-1)
LOCAL Z, x1, x2, t1, t2 AS EXT
x1 = R(p%,1,j&) : x2 = R(p%,2,j&)
t1 = 1##+(x1+x2+1##)^2*(19##-14##*x1+3##*x1^2-14##*x2+6##*x1*x2+3##*x2^2)
t2 = 30##+(2##*x1-3##*x2)^2*(18##-32##*x1+12##*x1^2+48##*x2-36##*x1*x2+27##*x2^2)
Z = t1*t2
F18 = -Z
END FUNCTION 'F18()
'-----
FUNCTION F19(R(),Nd%,p%,j&) 'F19 (3-D) Hartman's Family #1
'Global maximum = 3.86 @ (0.114,0.556,0.852)
LOCAL xi, Z, Sum, Aji(), Cj(), Pji() AS EXT
LOCAL i%, jj%, m%
REDIM Aji(1 TO 4, 1 TO 3), Cj(1 TO 4), Pji(1 TO 4, 1 TO 3)
Aji(1,1) = 3.0## : Aji(1,2) = 10## : Aji(1,3) = 30## : Cj(1) = 1.0##
Aji(2,1) = 0.1## : Aji(2,2) = 10## : Aji(2,3) = 35## : Cj(2) = 1.2##
Aji(3,1) = 3.0## : Aji(3,2) = 10## : Aji(3,3) = 30## : Cj(3) = 3.0##
Aji(4,1) = 0.1## : Aji(4,2) = 10## : Aji(4,3) = 35## : Cj(4) = 3.2##
Pji(1,1) = 0.36890## : Pji(1,2) = 0.1170## : Pji(1,3) = 0.2673##
Pji(2,1) = 0.46990## : Pji(2,2) = 0.4387## : Pji(2,3) = 0.7470##
Pji(3,1) = 0.10910## : Pji(3,2) = 0.8732## : Pji(3,3) = 0.5547##
Pji(4,1) = 0.03815## : Pji(4,2) = 0.5743## : Pji(4,3) = 0.8828##
Z = 0##
FOR jj% = 1 TO 4
  Sum = 0##
  FOR i% = 1 TO 3
    xi = R(p%,i%,j&)
    Sum = Sum + Aji(jj%,i%)*(xi-Pji(jj%,i%))^2
  NEXT i%
  Z = Z + Cj(jj%)*EXP(-Sum)
NEXT jj%
F19 = Z
END FUNCTION 'F19
'-----
FUNCTION F20(R(),Nd%,p%,j&) 'F20 (6-D) Hartman's Family #2
'Global maximum = 3.32 @ (0.201,0.150,0.477,0.275,0.311,0.657)
LOCAL xi, Z, Sum, Aji(), Cj(), Pji() AS EXT
LOCAL i%, jj%, m%
REDIM Aji(1 TO 4, 1 TO 6), Cj(1 TO 4), Pji(1 TO 4, 1 TO 6)
Aji(1,1) = 10.0## : Aji(1,2) = 3.00## : Aji(1,3) = 17.0## : Cj(1) = 1.0##
Aji(2,1) = 0.05## : Aji(2,2) = 10.0## : Aji(2,3) = 17.0## : Cj(2) = 1.2##
Aji(3,1) = 3.00## : Aji(3,2) = 3.50## : Aji(3,3) = 1.70## : Cj(3) = 3.0##
Aji(4,1) = 17.0## : Aji(4,2) = 8.00## : Aji(4,3) = 0.05## : Cj(4) = 3.2##

```

```

Aji(1,4) = 3.5### : Aji(1,5) = 1.7### : Aji(1,6) = 8##
Aji(2,4) = 0.1### : Aji(2,5) = 8## : Aji(2,6) = 14##
Aji(3,4) = 10### : Aji(3,5) = 17### : Aji(3,6) = 8##
Aji(4,4) = 10### : Aji(4,5) = 0.1### : Aji(4,6) = 14##

Pji(1,1) = 0.13120## : Pji(1,2) = 0.1696## : Pji(1,3) = 0.5569##
Pji(2,1) = 0.23290## : Pji(2,2) = 0.4135## : Pji(2,3) = 0.8307##
Pji(3,1) = 0.23480## : Pji(3,2) = 0.1415## : Pji(3,3) = 0.3522##
Pji(4,1) = 0.40470## : Pji(4,2) = 0.8828## : Pji(4,3) = 0.8732##

Pji(1,4) = 0.01240## : Pji(1,5) = 0.8283## : Pji(1,6) = 0.5886##
Pji(2,4) = 0.37360## : Pji(2,5) = 0.1004## : Pji(2,6) = 0.9991##
Pji(3,4) = 0.28830## : Pji(3,5) = 0.3047## : Pji(3,6) = 0.6650##
Pji(4,4) = 0.57430## : Pji(4,5) = 0.1091## : Pji(4,6) = 0.0381##

Z = 0##

FOR jj% = 1 TO 4
  Sum = 0##
  FOR i% = 1 TO 6
    Xi = R(p%,i%,j%)
    Sum = Sum + Aji(jj%,i%)*(Xi-Pji(jj%,i%))^2
  NEXT i%
  Z = Z + Cj(jj%)*EXP(-Sum)
NEXT jj%
F20 = Z
END FUNCTION 'F20
'-----
FUNCTION F21(R(),Nd%,p%,j%) 'F21 (4-D) Shekel's Family m=5
'Global maximum = 10
LOCAL Xi, Z, Sum, Aji(), Cj() AS EXT
LOCAL i%, jj%, m%
m% = 5 : REDIM Aji(1 TO m%, 1 TO 4), Cj(1 TO m%)
Aji(1,1) = 4## : Aji(1,2) = 4## : Aji(1,3) = 4## : Aji(1,4) = 4## : Cj(1) = 0.1##
Aji(2,1) = 1## : Aji(2,2) = 1## : Aji(2,3) = 1## : Aji(2,4) = 1## : Cj(2) = 0.2##
Aji(3,1) = 8## : Aji(3,2) = 8## : Aji(3,3) = 8## : Aji(3,4) = 8## : Cj(3) = 0.2##
Aji(4,1) = 6## : Aji(4,2) = 6## : Aji(4,3) = 6## : Aji(4,4) = 6## : Cj(4) = 0.4##
Aji(5,1) = 3## : Aji(5,2) = 7## : Aji(5,3) = 3## : Aji(5,4) = 7## : Cj(5) = 0.4##
Z = 0##
FOR jj% = 1 TO m% 'NOTE: Index jj% is used to avoid same variable name as j%
  Sum = 0##
  FOR i% = 1 TO 4 'shekel's family is 4-D only
    Xi = R(p%,i%,j%)
    Sum = Sum + (Xi-Aji(jj%,i%))^2
  NEXT i%
  Z = Z + 1##/(Sum + Cj(jj%))
NEXT jj%
F21 = Z
END FUNCTION 'F21
'-----
FUNCTION F22(R(),Nd%,p%,j%) 'F22 (4-D) Shekel's Family m=7
'Global maximum = 10
LOCAL Xi, Z, Sum, Aji(), Cj() AS EXT
LOCAL i%, jj%, m%
m% = 7 : REDIM Aji(1 TO m%, 1 TO 4), Cj(1 TO m%)
Aji(1,1) = 4## : Aji(1,2) = 4## : Aji(1,3) = 4## : Aji(1,4) = 4## : Cj(1) = 0.1##
Aji(2,1) = 1## : Aji(2,2) = 1## : Aji(2,3) = 1## : Aji(2,4) = 1## : Cj(2) = 0.2##
Aji(3,1) = 8## : Aji(3,2) = 8## : Aji(3,3) = 8## : Aji(3,4) = 8## : Cj(3) = 0.2##
Aji(4,1) = 6## : Aji(4,2) = 6## : Aji(4,3) = 6## : Aji(4,4) = 6## : Cj(4) = 0.4##
Aji(5,1) = 3## : Aji(5,2) = 7## : Aji(5,3) = 3## : Aji(5,4) = 7## : Cj(5) = 0.4##
Aji(6,1) = 2## : Aji(6,2) = 9## : Aji(6,3) = 2## : Aji(6,4) = 9## : Cj(6) = 0.6##
Aji(7,1) = 5## : Aji(7,2) = 5## : Aji(7,3) = 3## : Aji(7,4) = 3## : Cj(7) = 0.3##
Z = 0##
FOR jj% = 1 TO m% 'NOTE: Index jj% is used to avoid same variable name as j%
  Sum = 0##
  FOR i% = 1 TO 4 'shekel's family is 4-D only
    Xi = R(p%,i%,j%)
    Sum = Sum + (Xi-Aji(jj%,i%))^2
  NEXT i%
  Z = Z + 1##/(Sum + Cj(jj%))
NEXT jj%
F22 = Z
END FUNCTION 'F22
'-----
FUNCTION F23(R(),Nd%,p%,j%) 'F23 (4-D) Shekel's Family m=10
'Global maximum = 10
LOCAL Xi, Z, Sum, Aji(), Cj() AS EXT
LOCAL i%, jj%, m%

```

```

m% = 10 : REDIM Aji(1 TO m%, 1 TO 4), Cj(1 TO m%)

Aji(1,1) = 4## : Aji(1,2) = 4## : Aji(1,3) = 4## : Aji(1,4) = 4## : Cj(1) = 0.1##
Aji(2,1) = 1## : Aji(2,2) = 1## : Aji(2,3) = 1## : Aji(2,4) = 1## : Cj(2) = 0.2##
Aji(3,1) = 8## : Aji(3,2) = 8## : Aji(3,3) = 8## : Aji(3,4) = 8## : Cj(3) = 0.2##
Aji(4,1) = 6## : Aji(4,2) = 6## : Aji(4,3) = 6## : Aji(4,4) = 6## : Cj(4) = 0.4##
Aji(5,1) = 3## : Aji(5,2) = 7## : Aji(5,3) = 3## : Aji(5,4) = 7## : Cj(5) = 0.4##
Aji(6,1) = 2## : Aji(6,2) = 9## : Aji(6,3) = 2## : Aji(6,4) = 9## : Cj(6) = 0.6##
Aji(7,1) = 5## : Aji(7,2) = 5## : Aji(7,3) = 3## : Aji(7,4) = 3## : Cj(7) = 0.3##
Aji(8,1) = 8## : Aji(8,2) = 1## : Aji(8,3) = 8## : Aji(8,4) = 1## : Cj(8) = 0.7##
Aji(9,1) = 6## : Aji(9,2) = 2## : Aji(9,3) = 6## : Aji(9,4) = 2## : Cj(9) = 0.5##
Aji(10,1) = 7## : Aji(10,2) = 3.6## : Aji(10,3) = 7## : Aji(10,4) = 3.6## : Cj(10) = 0.5##

Z = 0##

FOR jj% = 1 TO m% 'NOTE: Index jj% is used to avoid same variable name as j&
  Sum = 0##
  FOR i% = 1 TO 4 'shekel's family is 4-D only
    Xi = R(p%,i%,j&)
    Sum = Sum + (Xi-Aji(jj%,i%))^2
  NEXT i%
  Z = Z + 1##/(Sum + Cj(jj%))
NEXT jj%

F23 = Z

END FUNCTION 'F23

'===== END FUNCTION DEFINITIONS =====
SUB Plot2DbestProbeTrajectories(NumTrajectories%,M(),R(),Np%,Nd%,LastStep&,FunctionName$)
LOCAL TrajectoryNumber%, ProbeNumber%, StepNumber&, N%, M%, ProcID??
LOCAL MaximumFitness, MinimumFitness AS EXT
LOCAL BestProbeThisStep%()
LOCAL BestFitnessThisStep(), TempFitness() AS EXT
LOCAL Annotation$, xCoord$, yCoord$, GnuPlotEXE$, PlotwithLines$
Annotation$ = ""
PlotwithLines$ = "YES" "NO"
NumTrajectories% = MIN(Np%,NumTrajectories%)
GnuPlotEXE$ = "wgnuplot.exe"
'----- Get Min/Max Fitnesses -----
MaximumFitness = M(1,0) : MinimumFitness = M(1,0) 'Note: M(p%,j&)
FOR StepNumber& = 0 TO LastStep&
  FOR ProbeNumber% = 1 TO Np%
    IF M(ProbeNumber%,StepNumber&) >= MaximumFitness THEN MaximumFitness = M(ProbeNumber%,StepNumber&)
    IF M(ProbeNumber%,StepNumber&) <= MinimumFitness THEN MinimumFitness = M(ProbeNumber%,StepNumber&)
  NEXT ProbeNumber%
NEXT StepNumber%
'----- Copy Fitness Array M() into TempFitness to Preserve M() -----
REDIM TempFitness(1 TO Np%, 0 TO LastStep&)
FOR StepNumber& = 0 TO LastStep&
  FOR ProbeNumber% = 1 TO Np%
    TempFitness(ProbeNumber%,StepNumber&) = M(ProbeNumber%,StepNumber&)
  NEXT ProbeNumber%
NEXT StepNumber%
'----- LOOP ON TRAJECTORIES -----
FOR TrajectoryNumber% = 1 TO NumTrajectories%
'----- Get Trajectory Coordinate Data -----
REDIM BestFitnessThisStep(0 TO LastStep&), BestProbeThisStep%(0 TO LastStep&)
FOR StepNumber& = 0 TO LastStep&
  BestFitnessThisStep(StepNumber&) = TempFitness(1,StepNumber&)
  FOR ProbeNumber% = 1 TO Np%
    IF TempFitness(ProbeNumber%,StepNumber&) >= BestFitnessThisStep(StepNumber&) THEN
      BestFitnessThisStep(StepNumber&) = TempFitness(ProbeNumber%,StepNumber&)
      BestProbeThisStep%(StepNumber&) = ProbeNumber%
    END IF
  NEXT ProbeNumber%
NEXT StepNumber&
'----- Create Plot Data File -----
N% = FREEFILE
SELECT CASE TrajectoryNumber%
CASE 1 : OPEN "t1" FOR OUTPUT AS #N%
CASE 2 : OPEN "t2" FOR OUTPUT AS #N%
CASE 3 : OPEN "t3" FOR OUTPUT AS #N%
CASE 4 : OPEN "t4" FOR OUTPUT AS #N%
CASE 5 : OPEN "t5" FOR OUTPUT AS #N%
CASE 6 : OPEN "t6" FOR OUTPUT AS #N%
CASE 7 : OPEN "t7" FOR OUTPUT AS #N%
CASE 8 : OPEN "t8" FOR OUTPUT AS #N%
CASE 9 : OPEN "t9" FOR OUTPUT AS #N%

```



```

SELECT CASE Probenumber%
CASE 1 : OPEN "p1" FOR OUTPUT AS #N%
CASE 2 : OPEN "p2" FOR OUTPUT AS #N%
CASE 3 : OPEN "p3" FOR OUTPUT AS #N%
CASE 4 : OPEN "p4" FOR OUTPUT AS #N%
CASE 5 : OPEN "p5" FOR OUTPUT AS #N%
CASE 6 : OPEN "p6" FOR OUTPUT AS #N%
CASE 7 : OPEN "p7" FOR OUTPUT AS #N%
CASE 8 : OPEN "p8" FOR OUTPUT AS #N%
CASE 9 : OPEN "p9" FOR OUTPUT AS #N%
CASE 10 : OPEN "p10" FOR OUTPUT AS #N%
CASE 11 : OPEN "p11" FOR OUTPUT AS #N%
CASE 12 : OPEN "p12" FOR OUTPUT AS #N%
CASE 13 : OPEN "p13" FOR OUTPUT AS #N%
CASE 14 : OPEN "p14" FOR OUTPUT AS #N%
CASE 15 : OPEN "p15" FOR OUTPUT AS #N%
CASE 16 : OPEN "p16" FOR OUTPUT AS #N%

END SELECT

----- write Plot File Data -----
FOR StepNumber& = 0 TO LastStep&
PRINT #N%, USING$( "#####.#####.#####.#####",R(Probenumber%,1,StepNumber&),R(Probenumber%,2,StepNumber&))
NEXT StepNumber%
CLOSE #N%
NEXT Probenumber%

----- Plot Trajectories -----
'usage: CALL CreateGnuPlotINIfile(PlotWindowULC_X%,PlotWindowULC_Y%,PlotWindowWidth%,PlotWindowHeight%)
CALL CreateGnuPlotINIfile(0.17##*ScreenWidth&,0.22##*ScreenHeight&,0.7##*ScreenWidth&,0.7##*ScreenHeight&)
Annotation$ = ""
N% = FREEFILE
OPEN "cmd2d.gp" FOR OUTPUT AS #N%
PRINT #N%, "set xrange ["+REMOVE$(STR$(Ximin(1)),ANY"" )+":"+REMOVE$(STR$(Ximax(1)),ANY" ")+""]
PRINT #N%, "set yrange ["+REMOVE$(STR$(Yimin(2)),ANY" ")+"":"+REMOVE$(STR$(Yimax(2)),ANY" ")+""]
PRINT #N%, "set grid xtics " + "10"
PRINT #N%, "set grid ytics " + "10"
PRINT #N%, "set grid mxtics"
PRINT #N%, "set grid mytics"
PRINT #N%, "show grid"
PRINT #N%, "set title " + Quote$ + "2D " + FunctionName$ + " INDIVIDUAL PROBE TRAJECTORIES\n(ORDERED BY PROBE #)" + "\n" + RunID$ + Quote$
PRINT #N%, "set xlabel " + Quote$ + "X1\n\n" + Quote$
PRINT #N%, "set ylabel " + Quote$ + "X2" + Quote$

IF PlotWithLines$ = "YES" THEN
SELECT CASE NumTrajectories%
CASE 1 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1"
CASE 2 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2"+Quote$+" w l"
CASE 3 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2"+Quote$+" w l,"+Quote$+"p3"+Quote$+" w l"
CASE 4 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2"+Quote$+" w l,"+Quote$+"p3"+Quote$+" w l,"+Quote$+"p4"+Quote$+" w l"
CASE 5 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2"+Quote$+" w l,"+Quote$+"p3"+Quote$+" w l,"+Quote$+"p4"+Quote$+" w l,"+Quote$+"p5"+Quote$+" w l"
CASE 6 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2"+Quote$+" w l,"+Quote$+"p3"+Quote$+" w l,"+Quote$+"p4"+Quote$+" w l,"+Quote$+"p5"+Quote$+" w l,"+Quote$+"p6"+Quote$+" w l"
CASE 7 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2"+Quote$+" w l,"+Quote$+"p3"+Quote$+" w l,"+Quote$+"p4"+Quote$+" w l,"+Quote$+"p5"+Quote$+" w l,"+Quote$+"p6"+Quote$+" w l,"+Quote$+"p7"+Quote$+" w l"
CASE 8 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2"+Quote$+" w l,"+Quote$+"p3"+Quote$+" w l,"+Quote$+"p4"+Quote$+" w l,"+Quote$+"p5"+Quote$+" w l,"+Quote$+"p6"+Quote$+" w l,"+Quote$+"p7"+Quote$+" w l"
CASE 9 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2"+Quote$+" w l,"+Quote$+"p3"+Quote$+" w l,"+Quote$+"p4"+Quote$+" w l,"+Quote$+"p5"+Quote$+" w l,"+Quote$+"p6"+Quote$+" w l,"+Quote$+"p7"+Quote$+" w l,"+Quote$+"p8"+Quote$+" w l"
CASE 10 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2" +Quote$+" w l,"+Quote$+"p3" +Quote$+" w l,"+Quote$+"p4" +Quote$+" w l,"+Quote$+"p5"+Quote$+" w l,"+Quote$+"p6"+Quote$+" w l,"+Quote$+"p7"+Quote$+" w l,"+Quote$+"p8" +Quote$+" w l,"+Quote$+"p9" +Quote$+" w l"
CASE 11 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2" +Quote$+" w l,"+Quote$+"p3" +Quote$+" w l,"+Quote$+"p4" +Quote$+" w l,"+Quote$+"p5" +Quote$+" w l,"+Quote$+"p6" +Quote$+" w l,"+Quote$+"p7" +Quote$+" w l,"+Quote$+"p8" +Quote$+" w l,"+Quote$+"p9" +Quote$+" w l,"+Quote$+"p10"+Quote$+" w l"
CASE 12 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2" +Quote$+" w l,"+Quote$+"p3" +Quote$+" w l,"+Quote$+"p4" +Quote$+" w l,"+Quote$+"p5" +Quote$+" w l,"+Quote$+"p6" +Quote$+" w l,"+Quote$+"p7" +Quote$+" w l,"+Quote$+"p8" +Quote$+" w l,"+Quote$+"p9" +Quote$+" w l,"+Quote$+"p10"+Quote$+" w l,"+Quote$+"p11"+Quote$+" w l"
CASE 13 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2" +Quote$+" w l,"+Quote$+"p3" +Quote$+" w l,"+Quote$+"p4" +Quote$+" w l,"+Quote$+"p5" +Quote$+" w l,"+Quote$+"p6" +Quote$+" w l,"+Quote$+"p7" +Quote$+" w l,"+Quote$+"p8" +Quote$+" w l,"+Quote$+"p9" +Quote$+" w l,"+Quote$+"p10"+Quote$+" w l,"+Quote$+"p11"+Quote$+" w l,"+Quote$+"p12"+Quote$+" w l"
CASE 14 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2" +Quote$+" w l,"+Quote$+"p3" +Quote$+" w l,"+Quote$+"p4" +Quote$+" w l,"+Quote$+"p5" +Quote$+" w l,"+Quote$+"p6" +Quote$+" w l,"+Quote$+"p7" +Quote$+" w l,"+Quote$+"p8" +Quote$+" w l,"+Quote$+"p9" +Quote$+" w l,"+Quote$+"p10"+Quote$+" w l,"+Quote$+"p11"+Quote$+" w l,"+Quote$+"p12"+Quote$+" w l,"+Quote$+"p13" +Quote$+" w l"
CASE 15 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2" +Quote$+" w l,"+Quote$+"p3" +Quote$+" w l,"+Quote$+"p4" +Quote$+" w l,"+Quote$+"p5" +Quote$+" w l,"+Quote$+"p6" +Quote$+" w l,"+Quote$+"p7" +Quote$+" w l,"+Quote$+"p8" +Quote$+" w l,"+Quote$+"p9" +Quote$+" w l,"+Quote$+"p10"+Quote$+" w l,"+Quote$+"p11"+Quote$+" w l,"+Quote$+"p12"+Quote$+" w l,"+Quote$+"p13" +Quote$+" w l,"+Quote$+"p14"+Quote$+" w l"
CASE 16 : PRINT #N%, "plot "+Quote$+"p1" +Quote$+" w l lw 1,"+Quote$+"p2" +Quote$+" w l,"+Quote$+"p3" +Quote$+" w l,"+Quote$+"p4" +Quote$+" w l,"+Quote$+"p5" +Quote$+" w l,"+Quote$+"p6" +Quote$+" w l,"+Quote$+"p7" +Quote$+" w l,"+Quote$+"p8" +Quote$+" w l,"+Quote$+"p9" +Quote$+" w l,"+Quote$+"p10"+Quote$+" w l,"+Quote$+"p11"+Quote$+" w l,"+Quote$+"p12"+Quote$+" w l,"+Quote$+"p13" +Quote$+" w l,"+Quote$+"p14"+Quote$+" w l,"+Quote$+"p15"+Quote$+" w l"
END SELECT
ELSE
SELECT CASE NumTrajectories%
CASE 1 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1"
CASE 2 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$
CASE 3 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" ,"+Quote$+"p3"+Quote$
CASE 4 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" ,"+Quote$+"p3"+Quote$+" ,"+Quote$+"p4"+Quote$

```

```

"+Quote$+"p5"+Quote$
CASE 5 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$
CASE 6 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$+" "+Quote$+"p6"+Quote$
CASE 7 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$+" "+Quote$+"p6"+Quote$+" "+Quote$+"p7"+Quote$
CASE 8 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$+" "+Quote$+"p6"+Quote$+" "+Quote$+"p7"+Quote$+" "+Quote$+"p8"+Quote$
CASE 9 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$+" "+Quote$+"p6"+Quote$+" "+Quote$+"p7"+Quote$+" "+Quote$+"p8"+Quote$+" "+Quote$+"p9"+Quote$
CASE 10 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$+" "+Quote$+"p6"+Quote$+" "+Quote$+"p7"+Quote$+" "+Quote$+"p8"+Quote$+" "+Quote$+"p9"+Quote$+" "+Quote$+"p10"+Quote$
CASE 11 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$+" "+Quote$+"p6"+Quote$+" "+Quote$+"p7"+Quote$+" "+Quote$+"p8"+Quote$+" "+Quote$+"p9"+Quote$+" "+Quote$+"p10"+Quote$+"
"+Quote$+"p11"+Quote$
CASE 12 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$+" "+Quote$+"p6"+Quote$+" "+Quote$+"p7"+Quote$+" "+Quote$+"p8"+Quote$+" "+Quote$+"p9"+Quote$+" "+Quote$+"p10"+Quote$+"
"+Quote$+"p11"+Quote$+" "+Quote$+"p12"+Quote$
CASE 13 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$+" "+Quote$+"p6"+Quote$+" "+Quote$+"p7"+Quote$+" "+Quote$+"p8"+Quote$+" "+Quote$+"p9"+Quote$+" "+Quote$+"p10"+Quote$+"
"+Quote$+"p11"+Quote$+" "+Quote$+"p12"+Quote$+" "+Quote$+"p13"+Quote$
CASE 14 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$+" "+Quote$+"p6"+Quote$+" "+Quote$+"p7"+Quote$+" "+Quote$+"p8"+Quote$+" "+Quote$+"p9"+Quote$+" "+Quote$+"p10"+Quote$+"
"+Quote$+"p11"+Quote$+" "+Quote$+"p12"+Quote$+" "+Quote$+"p13"+Quote$+" "+Quote$+"p14"+Quote$
CASE 15 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$+" "+Quote$+"p6"+Quote$+" "+Quote$+"p7"+Quote$+" "+Quote$+"p8"+Quote$+" "+Quote$+"p9"+Quote$+" "+Quote$+"p10"+Quote$+"
"+Quote$+"p11"+Quote$+" "+Quote$+"p12"+Quote$+" "+Quote$+"p13"+Quote$+" "+Quote$+"p14"+Quote$+" "+Quote$+"p15"+Quote$
CASE 16 : PRINT #N%, "plot "+Quote$+"p1"+Quote$+" lw 1,"+Quote$+"p2"+Quote$+" "+Quote$+"p3"+Quote$+" "+Quote$+"p4"+Quote$+"
"+Quote$+"p5"+Quote$+" "+Quote$+"p6"+Quote$+" "+Quote$+"p7"+Quote$+" "+Quote$+"p8"+Quote$+" "+Quote$+"p9"+Quote$+" "+Quote$+"p10"+Quote$+"
"+Quote$+"p11"+Quote$+" "+Quote$+"p12"+Quote$+" "+Quote$+"p13"+Quote$+" "+Quote$+"p14"+Quote$+" "+Quote$+"p15"+Quote$+" "+Quote$+"p16"+Quote$
END SELECT
END IF
CLOSE #N%
ProcID??? = SHELL(GnuPlotEXE$+" cmd2d.gp -") : CALL Delay(1#)
END SUB 'Plot2DindividualProbeTrajectories()
'-----
SUB Plot3DbestProbeTrajectories(NumTrajectories%,M(),R(),Np%,Nd%,LastStep$,FunctionName$) 'XYZZY
LOCAL TrajectoryNumber%, ProbeNumber%, StepNumber%, N%, M%, ProcID???
LOCAL MaximumFitness, MinimumFitness AS EXT
LOCAL BestProbeThisStep%()
LOCAL BestFitnessThisStep(), TempFitness() AS EXT
LOCAL Annotation$, xCoord$, yCoord$, zCoord$, GnuPlotEXE$, PlotWithLines$
Annotation$ = ""
PlotWithLines$ = "NO" "YES" "NO"
NumTrajectories% = MIN(Np%,NumTrajectories%)
GnuPlotEXE$ = "wgnuplot.exe"
'----- Get Min/Max Fitnesses -----
MaximumFitness = M(1,0) : MinimumFitness = M(1,0) 'Note: M(p%,j&)
FOR StepNumber& = 0 TO LastStep&
FOR ProbeNumber% = 1 TO Np%
IF M(ProbeNumber%,StepNumber&) >= MaximumFitness THEN MaximumFitness = M(ProbeNumber%,StepNumber&)
IF M(ProbeNumber%,StepNumber&) <= MinimumFitness THEN MinimumFitness = M(ProbeNumber%,StepNumber&)
NEXT ProbeNumber%
NEXT StepNumber%
'----- Copy Fitness Array M() into TempFitness to Preserve M() -----
REDIM TempFitness(1 TO Np%, 0 TO LastStep&)
FOR StepNumber& = 0 TO LastStep&
FOR ProbeNumber% = 1 TO Np%
TempFitness(ProbeNumber%,StepNumber&) = M(ProbeNumber%,StepNumber&)
NEXT ProbeNumber%
NEXT StepNumber%
'----- LOOP ON TRAJECTORIES -----
FOR TrajectoryNumber% = 1 TO NumTrajectories%
'----- Get Trajectory Coordinate Data -----
REDIM BestFitnessThisStep(0 TO LastStep&), BestProbeThisStep%(0 TO LastStep&)
FOR StepNumber& = 0 TO LastStep&
BestFitnessThisStep(StepNumber&) = TempFitness(1,StepNumber&)
FOR ProbeNumber% = 1 TO Np%
IF TempFitness(ProbeNumber%,StepNumber&) >= BestFitnessThisStep(StepNumber&) THEN

```



```

ProcID??? = SHELL(GnuPlotEXE$+" cmd3d.gp -") : CALL Delay(1#)
END SUB 'Plot3DbestProbeTrajectories()
'-----
FUNCTION HasDAVGSaturated$(Nsteps&,j&,Np%,Nd%,M(),R(),DiagLength)
LOCAL A$
LOCAL k&
LOCAL SumOfDavg, DavgStepJ AS EXT
LOCAL DavgSatTOL AS EXT
A$ = "NO"
DavgSatTOL = 0.0005## 'tolerance for DAVG saturation
IF j& < Nsteps& + 10 THEN GOTO ExitHasDAVGSaturated 'execute at least 10 steps after averaging interval before performing this check
DavgStepJ = DavgThisStep(j&,Np%,Nd%,M(),R(),DiagLength)
SumOfDavg = 0##
FOR k& = j&-Nsteps&+1 TO j& 'check this step and previous (Nsteps&-1) steps
SumOfDavg = SumOfDavg + DavgThisStep(k&,Np%,Nd%,M(),R(),DiagLength)
NEXT k&
IF ABS(SumOfDavg/Nsteps&-DavgStepJ) =< DavgSatTOL THEN A$ = "YES" 'saturation if (avg value - last value) are within TOL
ExitHasDAVGSaturated:
HasDAVGSaturated$ = A$
END FUNCTION 'HasDAVGSaturated$()
'-----
FUNCTION OscillationInDavg$(j&,Np%,Nd%,M(),R(),DiagLength)
LOCAL A$
LOCAL k&, NumSlopeChanges%
A$ = "NO"
NumSlopeChanges% = 0
IF j& < 15 THEN GOTO ExitDavgOscillation 'wait at least 15 steps
FOR k& = j&-10 TO j&-1 'check previous ten steps
IF (DavgThisStep(k&,Np%,Nd%,M(),R(),DiagLength)-DavgThisStep(k&-1,Np%,Nd%,M(),R(),DiagLength))* _
(DavgThisStep(k&+1,Np%,Nd%,M(),R(),DiagLength)-DavgThisStep(k&,Np%,Nd%,M(),R(),DiagLength)) < 0## THEN INCR NumSlopeChanges%
NEXT j&
IF NumSlopeChanges% >= 3 THEN A$ = "YES"
ExitDavgOscillation:
OscillationInDavg$ = A$
END FUNCTION 'OscillationInDavg$()
'-----
FUNCTION DavgThisStep(j&,Np%,Nd%,M(),R(),DiagLength)
LOCAL BestFitness, TotalDistanceAllProbes, SumSQ AS EXT
LOCAL p%, k&, N%, i%, BestProbeNumber%, BestTimeStep&
' ----- Best Probe #, etc. -----
FOR k& = 0 TO j&
BestFitness = M(1,k&)
FOR p% = 1 TO Np%
IF M(p%,k&) >= BestFitness THEN
BestFitness = M(p%,k&) : BestProbeNumber% = p% : BestTimeStep& = k&
END IF
NEXT p% 'probe #
NEXT k& 'time step
' ----- Average Distance to Best Probe -----
TotalDistanceAllProbes = 0##
FOR p% = 1 TO Np%
SumSQ = 0##
FOR i% = 1 TO Nd%
SumSQ = SumSQ + (R(BestProbeNumber%,i%,BestTimeStep&)-R(p%,i%,j&))^2 'do not exclude p%=BestProbeNumber%(j&) from sum because it adds zero
NEXT i%
TotalDistanceAllProbes = TotalDistanceAllProbes + SQR(SumSQ)
NEXT p%
DavgThisStep = TotalDistanceAllProbes/(DiagLength*(Np%-1)) 'but exclude best probe from average
END FUNCTION 'DavgThisStep$()
'-----
SUB
PlotBestFitnessEvolution(Nd%,Np%,LastStep&,G,DeltaT,Alpha,Beta,Frep,Mbest(),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,Gamma)
LOCAL BestFitness(), GlobalBestFitness AS EXT
LOCAL PlotAnnotation$, PlotTitle$
LOCAL p%, j&, N%
REDIM BestFitness(0 TO LastStep&)

```







```

'-----
SUB InitialProbeDistribution(Np%,Nd%,Nt&,R(),PlaceInitialProbes$,Gamma)
LOCAL DeltaXi, DelX1, DelX2, Di AS EXT
LOCAL NumProbesPerDimension%, p%, i%, k%, NumX1points%, NumX2points%, x1pointNum%, x2pointNum%, AS
SELECT CASE PlaceInitialProbes$
CASE "UNIFORM ON-AXIS"
  IF Nd% > 1 THEN
    NumProbesPerDimension% = Np%\Nd% 'even #
  ELSE
    NumProbesPerDimension% = Np%
  END IF
  FOR i% = 1 TO Nd%
    FOR p% = 1 TO Np%
      R(p%,i%,0) = XiMin(i%) + Gamma*(XiMax(i%)-XiMin(i%))
    NEXT Np%
  NEXT i%
  FOR i% = 1 TO Nd% 'place probes probe line-by-probe line (i% is dimension number)
    DeltaXi = (XiMax(i%)-XiMin(i%))/(NumProbesPerDimension%-1)
    FOR k% = 1 TO NumProbesPerDimension%
      p% = k% + NumProbesPerDimension%*(i%-1) 'probe #
      R(p%,i%,0) = XiMin(i%) + (k%-1)*DeltaXi
    NEXT k%
  NEXT i%
CASE "UNIFORM ON-DIAGONAL"
  FOR p% = 1 TO Np%
    FOR i% = 1 TO Nd%
      DeltaXi = (XiMax(i%)-XiMin(i%))/(Np%-1)
      R(p%,i%,0) = XiMin(i%) + (p%-1)*DeltaXi
    NEXT i%
  NEXT p%
CASE "2D GRID"
  NumProbesPerDimension% = SQR(Np%) : NumX1points% = NumProbesPerDimension% : NumX2points% = NumX1points% 'broken down for possible future use
  DelX1 = (XiMax(1)-XiMin(1))/(NumX1points%-1)
  DelX2 = (XiMax(2)-XiMin(2))/(NumX2points%-1)
  FOR x1pointNum% = 1 TO NumX1points%
    FOR x2pointNum% = 1 TO NumX2points%
      p% = NumX1points%*(x1pointNum%-1)+x2pointNum% 'probe #
      R(p%,1,0) = XiMin(1) + DelX1*(x1pointNum%-1) 'x1 coord
      R(p%,2,0) = XiMin(2) + DelX2*(x2pointNum%-1) 'x2 coord
    NEXT x2pointNum%
  NEXT x1pointNum%
CASE "RANDOM"
  FOR p% = 1 TO Np%
    FOR i% = 1 TO Nd%
      R(p%,i%,0) = XiMin(i%) + RandomNum(0##,1##)*(XiMax(i%)-XiMin(i%))
    NEXT i%
  NEXT p%
END SELECT
END SUB 'InitialProbeDistribution()
'-----
SUB
ChangeRunParameters(NumProbesPerDimension%,Np%,Nd%,Nt&,G,Alpha,Beta,DeltaT,Frep,PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$)
'THIS PROCEDURE NOT USED
LOCAL A$, DefaultValue$
A$ = INPUTBOX$("# dimensions?","Change # Dimensions (" +FunctionName$+)",NoSpaces$(Nd%+0,0)) : Nd% = VAL(A$) : IF Nd% < 1 OR Nd% > 500 THEN Nd% = 2
IF Nd% > 1 THEN NumProbesPerDimension% = 2*((NumProbesPerDimension%+1)\2) 'require an even # probes on each probe line to avoid overlapping at origin
(in symmetrical spaces at least...)
IF Nd% = 1 THEN NumProbesPerDimension% = MAX(NumProbesPerDimension%,3) 'at least 3 probes on x-axis for 1-D functions
Np% = NumProbesPerDimension%*Nd%
A$ = INPUTBOX$("# time steps?","Change # Steps (" +FunctionName$+)",NoSpaces$(Nt&+0,0)) : Nt& = VAL(A$) : IF Nt& < 3 THEN Nt& = 50
A$ = INPUTBOX$("Grav Const G?","Change G (" +FunctionName$+)",NoSpaces$(G,2)) : G = VAL(A$) : IF G < -100## OR G > 100## THEN G = 2##
A$ = INPUTBOX$("Alpha?","Change Alpha (" +FunctionName$+)",NoSpaces$(Alpha,2)) : Alpha = VAL(A$) : IF Alpha < -50## OR Alpha > 50## THEN Alpha = 2##
A$ = INPUTBOX$("Beta?","Change Beta (" +FunctionName$+)",NoSpaces$(Beta,2)) : Beta = VAL(A$) : IF Beta < -50## OR Beta > 50## THEN Beta = 2##
A$ = INPUTBOX$("Delta T","Change Delta-T (" +FunctionName$+)",NoSpaces$(DeltaT,2)) : DeltaT = VAL(A$) : IF DeltaT =< 0## THEN DeltaT = 1##

```

```

A$ = INPUTBOX("Frep [0-1]?", "Change Frep (" + FunctionName$ + ")", NoSpaces$(Frep, 3)) : Frep = VAL(A$) : IF Frep < 0## OR Frep > 1## THEN Frep
= 0.5##
' ----- Initial Probe Distribution -----
SELECT CASE PlaceInitialProbes$
CASE "UNIFORM ON-AXIS" : DefaultValue$ = "1"
CASE "UNIFORM ON-DIAGONAL" : DefaultValue$ = "2"
CASE "2D GRID" : DefaultValue$ = "3"
CASE "RANDOM" : DefaultValue$ = "4"
END SELECT
A$ = INPUTBOX("Initial Probes?" + CHR$(13) + "1 - UNIFORM ON-AXIS" + CHR$(13) + "2 - UNIFORM ON-DIAGONAL" + CHR$(13) + "3 - 2D GRID" + CHR$(13) + "4 -
RANDOM", "Initial Probe Distribution (" + FunctionName$ + ")", DefaultValue$)
IF VAL(A$) < 1 OR VAL(A$) > 4 THEN A$ = "1"
SELECT CASE VAL(A$)
CASE 1 : PlaceInitialProbes$ = "UNIFORM ON-AXIS"
CASE 2 : PlaceInitialProbes$ = "UNIFORM ON-DIAGONAL"
CASE 3 : PlaceInitialProbes$ = "2D GRID"
CASE 4 : PlaceInitialProbes$ = "RANDOM"
END SELECT
IF Nd% = 1 AND PlaceInitialProbes$ = "UNIFORM ON-DIAGONAL" THEN PlaceInitialProbes$ = "UNIFORM ON-AXIS" 'cannot do diagonal in 1-D space
IF Nd% > 2 AND PlaceInitialProbes$ = "2D GRID" THEN PlaceInitialProbes$ = "UNIFORM ON-AXIS" '2D grid is available only in 2 dimensions!
' ----- Initial Acceleration -----
SELECT CASE InitialAcceleration$
CASE "ZERO" : DefaultValue$ = "1"
CASE "FIXED" : DefaultValue$ = "2"
CASE "RANDOM" : DefaultValue$ = "3"
END SELECT
A$ = INPUTBOX("Initial Acceleration?" + CHR$(13) + "1 - ZERO" + CHR$(13) + "2 - FIXED" + CHR$(13) + "3 - RANDOM", "Initial Acceleration
(" + FunctionName$ + ")", DefaultValue$)
IF VAL(A$) < 1 OR VAL(A$) > 3 THEN A$ = "1"
SELECT CASE VAL(A$)
CASE 1 : InitialAcceleration$ = "ZERO"
CASE 2 : InitialAcceleration$ = "FIXED"
CASE 3 : InitialAcceleration$ = "RANDOM"
END SELECT
' ----- Reposition Factor -----
SELECT CASE RepositionFactor$
CASE "FIXED" : DefaultValue$ = "1"
CASE "VARIABLE" : DefaultValue$ = "2"
CASE "RANDOM" : DefaultValue$ = "3"
END SELECT
A$ = INPUTBOX("Reposition Factor?" + CHR$(13) + "1 - FIXED" + CHR$(13) + "2 - VARIABLE" + CHR$(13) + "3 - RANDOM", "Retrieve Probes
(" + FunctionName$ + ")", DefaultValue$)
IF VAL(A$) < 1 OR VAL(A$) > 3 THEN A$ = "1"
SELECT CASE VAL(A$)
CASE 1 : RepositionFactor$ = "FIXED"
CASE 2 : RepositionFactor$ = "VARIABLE"
CASE 3 : RepositionFactor$ = "RANDOM"
END SELECT
END SUB 'ChangeRunParameters()
'-----
FUNCTION NoSpaces$(X, NumDigits%) : NoSpaces$ = REMOVE$(STR$(X, NumDigits%), ANY " ") : END FUNCTION
'-----
FUNCTION TerminateNowForSaturation$(j&, Nd%, Np%, Nt&, G, DeltaT, Alpha, Beta, R(C), A(C), M(C))
LOCAL A$, i&, p%, NumStepsForAveraging&
LOCAL BestFitness, AvgFitness, FitnessTOL AS EXT 'terminate if avg fitness does not change over NumStepsForAveraging& time steps
FitnessTOL = 0.0001## : NumStepsForAveraging& = 10
A$ = "NO"
IF j& >= NumStepsForAveraging+10 THEN 'wait until step 10 to start checking for fitness saturation
AvgFitness = 0##
FOR i& = j&-NumStepsForAveraging+1 TO j& 'avg fitness over current step & previous NumStepsForAveraging&-1 steps
BestFitness = M(1, i&)
FOR p% = 1 TO Np%
IF M(p%, i&) >= BestFitness THEN BestFitness = M(p%, i&)
NEXT p%
AvgFitness = AvgFitness + BestFitness
NEXT i&
AvgFitness = AvgFitness/NumStepsForAveraging&
IF ABS(AvgFitness-BestFitness) < FitnessTOL THEN A$ = "YES" 'compare avg fitness to best fitness at this step
END IF
TerminateNowForSaturation$ = A$
END FUNCTION 'TerminateNowForSaturation$()
'-----
FUNCTION MagVector(V(), N%) 'returns magnitude of Nx1 column vector V
LOCAL SumSq AS EXT
LOCAL i%
SumSq = 0## : FOR i% = 1 TO N% : SumSq = SumSq + V(i%)^2 : NEXT i% : MagVector = SQR(SumSq)
END FUNCTION 'MagVector()
'---
FUNCTION UnitStep(x)

```

```

LOCAL Z AS EXT
  IF X < 0## THEN
    Z = 0##
  ELSE
    Z = 1##
  END IF
  UnitStep = Z
END FUNCTION 'UnitStep()
'---

SUB Plot1Dfunction(FunctionName$,R()) 'plots 1D function on-screen
LOCAL NumPoints%, i%, N%
LOCAL DeltaX, X AS EXT
  NumPoints% = 32001
  DeltaX = (XiMax(1)-XiMin(1))/(NumPoints%-1)
  N% = FREEFILE
  SELECT CASE FunctionName$
    CASE "ParrottF4" 'PARROTT F4 FUNCTION
      OPEN "ParrottF4" FOR OUTPUT AS #N%
      FOR i% = 1 TO NumPoints%
        R(1,1,0) = XiMin(1) + (i%-1)*DeltaX
        PRINT #N%, USING$( "#.##### #.#####",R(1,1,0),ParrottF4(R(),1,1,0))
      NEXT i%
      CLOSE #N%
      CALL CreateGnuPlotINIfile(0.2##*ScreenWidth&,0.2##*ScreenHeight&,0.6##*ScreenWidth&,0.6##*ScreenHeight&)
      CALL Twodplot("ParrottF4","Parrott F4 Function","0.7","0.7","X\n\n.", "\n\nParrott F4(X)", "", "", "0", "1", "0", "1", "", "", "wgnuplot.exe", " with
lines linewidth 2", "")
    END SELECT
  END SUB
'-----

SUB CLEANUP 'probe coordinate plot files
  IF DIR$("p1") <> "" THEN KILL "p1"
  IF DIR$("p2") <> "" THEN KILL "p2"
  IF DIR$("p3") <> "" THEN KILL "p3"
  IF DIR$("p4") <> "" THEN KILL "p4"
  IF DIR$("p5") <> "" THEN KILL "p5"
  IF DIR$("p6") <> "" THEN KILL "p6"
  IF DIR$("p7") <> "" THEN KILL "p7"
  IF DIR$("p8") <> "" THEN KILL "p8"
  IF DIR$("p9") <> "" THEN KILL "p9"
  IF DIR$("p10") <> "" THEN KILL "p10"
  IF DIR$("p11") <> "" THEN KILL "p11"
  IF DIR$("p12") <> "" THEN KILL "p12"
  IF DIR$("p13") <> "" THEN KILL "p13"
  IF DIR$("p14") <> "" THEN KILL "p14"
  IF DIR$("p15") <> "" THEN KILL "p15"
END SUB
'-----

SUB Plot2Dfunction(FunctionName$,R())
LOCAL A$
LOCAL NumPoints%, i%, k%, N%
LOCAL DelX1, DelX2, Z AS EXT
  SELECT CASE FunctionName$
    CASE "BOWTIE" : NumPoints% = 5
    CASE "YAGI" : NumPoints% = 5
    CASE "PBM_1", "PBM_2", "PBM_3", "PBM_4", "PBM_5" : NumPoints% = 25
    CASE ELSE : NumPoints% = 100
  END SELECT
  N% = FREEFILE : OPEN "TwoDplot.DAT" FOR OUTPUT AS #N%
  DelX1 = (XiMax(1)-XiMin(1))/(NumPoints%-1) : DelX2 = (XiMax(2)-XiMin(2))/(NumPoints%-1)
  FOR i% = 1 TO NumPoints%
    R(1,1,0) = XiMin(1) + (i%-1)*DelX1 'x1 value
    FOR k% = 1 TO NumPoints%
      R(1,2,0) = XiMin(2) + (k%-1)*DelX2 'x2 value
      Z = ObjectiveFunction(R(),2,1,0,FunctionName$)
      PRINT #N%, USING$( "##### ^^^",R(1,1,0),R(1,2,0),Z)
    NEXT k%
    PRINT #N%, ""
  NEXT i%
  CLOSE #N%
  CALL CreateGnuPlotINIfile(0.1##*ScreenWidth&,0.1##*ScreenHeight&,0.6##*ScreenWidth&,0.6##*ScreenHeight&)
  A$ = "" : IF INSTR(FunctionName$, "PBM_") > 0 THEN A$ = "Coarse "
  CALL Threedplot2("TwoDplot.DAT", A$+"Plot_of "+FunctionName$+" Function", "", "0.6", "0.6", "1.2", _
"x1", "x2", "z=F(x1,x2)", "", "", "wgnuplot.exe", "", "", "", "", "")

```

```

END SUB
'-----
SUB TwoDPlot3Curves(NumCurves%,PlotFileName1$,PlotFileName2$,PlotFileName3$,PlotTitle$,Annotation$,xCoord$,yCoord$,XaxisLabel$,YaxisLabel$, _
LogXaxis$,LogYaxis$,xMin$,xMax$,yMin$,yMax$,xTics$,yTics$,GnuPlotEXE$)
LOCAL N%
LOCAL LineSize$
LineSize$ = "2"
N% = FREEFILE
OPEN "cmd2d.gp" FOR OUTPUT AS #N%
IF LogXaxis$ = "YES" AND LogYaxis$ = "NO" THEN PRINT #N%, "set logscale x"
IF LogXaxis$ = "NO" AND LogYaxis$ = "YES" THEN PRINT #N%, "set logscale y"
IF LogXaxis$ = "YES" AND LogYaxis$ = "YES" THEN PRINT #N%, "set logscale xy"
IF xMin$ <> "" AND xMax$ <> "" THEN PRINT #N%, "set xrange ["+xMin$+":"+xMax$+"]"
IF yMin$ <> "" AND yMax$ <> "" THEN PRINT #N%, "set yrange ["+yMin$+":"+yMax$+"]"
PRINT #N%, "set label "+Quote$+Annotation$+Quote$+" at graph "+xCoord$+","+yCoord$
PRINT #N%, "set grid xtics"
PRINT #N%, "set grid ytics"
PRINT #N%, "set xtics "+xTics$
PRINT #N%, "set ytics "+yTics$
PRINT #N%, "set grid mxtics"
PRINT #N%, "set grid mytics"
PRINT #N%, "set title "+Quote$+PlotTitle$+Quote$
PRINT #N%, "set xlabel "+Quote$+XaxisLabel$+Quote$
PRINT #N%, "set ylabel "+Quote$+YaxisLabel$+Quote$
SELECT CASE NumCurves%
CASE 1
PRINT #N%, "plot " + Quote$ + PlotFileName1$ + Quote$ + " with lines linewidth " + LineSize$
CASE 2
PRINT #N%, "plot " + Quote$ + PlotFileName1$ + Quote$ + " with lines linewidth " + LineSize$ + ", " + _
Quote$ + PlotFileName2$ + Quote$ + " with lines linewidth " + LineSize$
CASE 3
PRINT #N%, "plot " + Quote$ + PlotFileName1$ + Quote$ + " with lines linewidth " + LineSize$ + ", " + _
Quote$ + PlotFileName2$ + Quote$ + " with lines linewidth " + LineSize$ + ", " + _
Quote$ + PlotFileName3$ + Quote$ + " with lines linewidth " + LineSize$
END SELECT
CLOSE #N%
SHELL (GnuPlotEXE$+" cmd2d.gp -")
CALL Delay(1##)
END SUB 'TwoDPlot3Curves()
'---
FUNCTION Fibonacci&&(N%) 'RETURNS Nth FIBONACCI NUMBER
LOCAL i%, Fn&&, Fn1&&, Fn2&&
LOCAL A$
IF N% > 91 OR N% < 0 THEN
MSGBOX("ERROR! Fibonacci argument"+STR$(N%)+ " > 91. Out of range or < 0...") : EXIT FUNCTION
END IF
SELECT CASE N%
CASE 0: Fn&& = 1
CASE ELSE
Fn&& = 0 : Fn2&& = 1 : i% = 0
FOR i% = 1 TO N%
Fn&& = Fn1&& + Fn2&&
Fn1&& = Fn2&&
Fn2&& = Fn&&
NEXT i% 'LOOP
END SELECT
Fibonacci&& = Fn&&
END FUNCTION 'Fibonacci&&()
'-----
FUNCTION RandomNum(a,b) 'Returns random number X, a<= X < b.
RandomNum = a + (b-a)*RND
END FUNCTION 'RandomNum()
'-----
FUNCTION GaussianDeviate(Mu,Sigma) 'returns NORMAL (Gaussian) random deviate with mean Mu and standard deviation Sigma (variance = Sigma^2)
'Refs: (1) Press, W.H., Flannery, B.P., Teukolsky, S.A., and Vetterling, W.T., "Numerical Recipes: The Art of Scientific Computing,"
$7.2, Cambridge University Press, Cambridge, UK, 1986.
(2) Shinzato, T., "Box Muller Method," 2007, http://www.sp.dis.titech.ac.jp/~shinzato/boxmuller.pdf
LOCAL s, t, Z AS EXT
s = RND : t = RND
Z = Mu + Sigma*SQR(-2##*LOG(s))*COS(TwoPi*t)
GaussianDeviate = Z
END FUNCTION 'GaussianDeviate()
'-----
SUB ContourPlot(PlotFileName$,PlotTitle$,Annotation$,xCoord$,yCoord$,zCoord$, _
XaxisLabel$,YaxisLabel$,ZaxisLabel$,zMin$,zMax$,GnuPlotEXE$,A$)
LOCAL N%

```

```

N% = FREEFILE
OPEN "cmd3d.gp" FOR OUTPUT AS #N%
PRINT #N%, "show surface"
PRINT #N%, "set hidden3d"
IF zMin$ <> "" AND zMax$ <> "" THEN PRINT #N%, "set zrange ["+zMin$+":"zMax$+"]"
PRINT #N%, "set label "+Quote$+Annotation$+Quote$+" at graph "+xCoord$+","+yCoord$+","+zCoord$
PRINT #N%, "show label"
PRINT #N%, "set grid xtics ytics ztics"
PRINT #N%, "show grid"
PRINT #N%, "set title "+Quote$+PlotTitle$+Quote$
PRINT #N%, "set xlabel "+Quote$+XaxisLabel$+Quote$
PRINT #N%, "set ylabel "+Quote$+YaxisLabel$+Quote$
PRINT #N%, "set zlabel "+Quote$+ZaxisLabel$+Quote$
PRINT #N%, "splot "+Quote$+PlotFileName$+Quote$+AS " notitle with linespoints" 'AS" notitle with lines"
CLOSE #N%

SHELL(GnuPlotEXE$+" cmd3d.gp -")

END SUB 'ContourPlot()

'---

SUB ThreeDplot(PlotFileName$,PlotTitle$,Annotation$,xCoord$,yCoord$,zCoord$, _
XaxisLabel$,YaxisLabel$,ZaxisLabel$,zMin$,zMax$,GnuPlotEXE$,AS)

LOCAL N%, ProcessID???

N% = FREEFILE
OPEN "cmd3d.gp" FOR OUTPUT AS #N%
PRINT #N%, "set pm3d"
PRINT #N%, "show pm3d"
IF zMin$ <> "" AND zMax$ <> "" THEN PRINT #N%, "set zrange ["+zMin$+":"zMax$+"]"
PRINT #N%, "set label "+Quote$+Annotation$+Quote$+" at graph "+xCoord$+","+yCoord$+","+zCoord$
PRINT #N%, "show label"
PRINT #N%, "set grid xtics ytics ztics"
PRINT #N%, "show grid"
PRINT #N%, "set title "+Quote$+PlotTitle$+Quote$
PRINT #N%, "set xlabel "+Quote$+XaxisLabel$+Quote$
PRINT #N%, "set ylabel "+Quote$+YaxisLabel$+Quote$
PRINT #N%, "set zlabel "+Quote$+ZaxisLabel$+Quote$
PRINT #N%, "splot "+Quote$+PlotFileName$+Quote$+AS+" notitle" with lines"
CLOSE #N%

SHELL(GnuPlotEXE$+" cmd3d.gp -") : CALL Delay(1#)

END SUB 'ThreeDplot()

'---

SUB ThreeDplot2(PlotFileName$,PlotTitle$,Annotation$,xCoord$,yCoord$,zCoord$, _
XaxisLabel$,YaxisLabel$,ZaxisLabel$,zMin$,zMax$,GnuPlotEXE$,AS,xStart$,xStop$,yStart$,yStop$)

LOCAL N%

N% = FREEFILE
OPEN "cmd3d.gp" FOR OUTPUT AS #N%
PRINT #N%, "set pm3d"
PRINT #N%, "show pm3d"
PRINT #N%, "set hidden3d"
PRINT #N%, "set view 45, 45, 1, 1"
IF zMin$ <> "" AND zMax$ <> "" THEN PRINT #N%, "set zrange ["+zMin$+":"zMax$+"]"
PRINT #N%, "set xrange [" + xStart$ + ":" + xStop$ + "]"
PRINT #N%, "set yrange [" + yStart$ + ":" + yStop$ + "]"
PRINT #N%, "set label " + Quote$ + Annotation$ + Quote$+" at graph "+xCoord$+","+yCoord$+","+zCoord$
PRINT #N%, "show label"
PRINT #N%, "set grid xtics ytics ztics"
PRINT #N%, "show grid"
PRINT #N%, "set title " + Quote$+PlotTitle$ + Quote$
PRINT #N%, "set xlabel " + Quote$+XaxisLabel$ + Quote$
PRINT #N%, "set ylabel " + Quote$+YaxisLabel$ + Quote$
PRINT #N%, "set zlabel " + Quote$+ZaxisLabel$ + Quote$
PRINT #N%, "splot " + Quote$+PlotFileName$ + Quote$ + AS + " notitle with lines"
CLOSE #N%

SHELL(GnuPlotEXE$+" cmd3d.gp -")

END SUB 'ThreeDplot2()

'---

SUB Twodplot2Curves(PlotFileName1$,PlotFileName2$,PlotTitle$,Annotation$,xCoord$,yCoord$,XaxisLabel$,YaxisLabel$, _
LogXaxis$,LogYaxis$,xMin$,xMax$,yMin$,yMax$,XTics$,YTics$,GnuPlotEXE$,LineStyle)

LOCAL N%, ProcessID???

N% = FREEFILE
OPEN "cmd2d.gp" FOR OUTPUT AS #N%
PRINT #N%, "set output "+Quote$+"test.plt"+Quote$+" tried this 3/11/06, didn't work..."
IF LogXaxis$ = "YES" AND LogYaxis$ = "NO" THEN PRINT #N%, "set logscale x"
IF LogXaxis$ = "NO" AND LogYaxis$ = "YES" THEN PRINT #N%, "set logscale y"
IF LogXaxis$ = "YES" AND LogYaxis$ = "YES" THEN PRINT #N%, "set logscale xy"
IF xMin$ <> "" AND xMax$ <> "" THEN PRINT #N%, "set xrange ["+xMin$+":"xMax$+"]"
IF yMin$ <> "" AND yMax$ <> "" THEN PRINT #N%, "set yrange ["+yMin$+":"yMax$+"]"
PRINT #N%, "set label "+Quote$+Annotation$+Quote$+" at graph "+xCoord$+","+yCoord$
PRINT #N%, "set grid xtics"
PRINT #N%, "set grid ytics"
PRINT #N%, "set grid xtics"
PRINT #N%, "set ytics "+YTics$
PRINT #N%, "set grid mxtics"
PRINT #N%, "set grid mytics"
PRINT #N%, "set title "+Quote$+PlotTitle$+Quote$
PRINT #N%, "set xlabel "+Quote$+XaxisLabel$+Quote$
PRINT #N%, "set ylabel "+Quote$+YaxisLabel$+Quote$
PRINT #N%, "plot "+Quote$+PlotFileName1$+Quote$+" with lines linewidth "+REMOVE$(STR$(LineStyle),ANY"")+"," + _
Quote$+PlotFileName2$+Quote$+" with points pointsize 0.05"+REMOVE$(STR$(LineStyle),ANY" ")
CLOSE #N%

ProcessID??? = SHELL(GnuPlotEXE$+" cmd2d.gp -") : CALL Delay(1#)

END SUB 'Twodplot2Curves()

'---

```

```

SUB Probe2Dplots(ProbePlotsFileList$,PlotTitle$,Annotation$,xCoord$,yCoord$,xAxisLabel$,yAxisLabel$, _
LogXaxis$,LogYaxis$,xMin$,xMax$,yMin$,yMax$,xTics$,yTics$,GnuPlotEXE$)

LOCAL N%, ProcessID???
N% = FREEFILE
OPEN "cmd2d.gp" FOR OUTPUT AS #N%
IF LogXaxis$ = "YES" AND LogYaxis$ = "NO" THEN PRINT #N%, "set logscale x"
IF LogXaxis$ = "NO" AND LogYaxis$ = "YES" THEN PRINT #N%, "set logscale y"
IF LogXaxis$ = "YES" AND LogYaxis$ = "YES" THEN PRINT #N%, "set logscale xy"
IF xMin$ <> "" AND xMax$ <> "" THEN PRINT #N%, "set xrange ["+xMin$+":"+xMax$+"]"
IF yMin$ <> "" AND yMax$ <> "" THEN PRINT #N%, "set yrange ["+yMin$+":"+yMax$+"]"
PRINT #N%, "set label "+Quote$+Annotation$+Quote$+" at graph "+xCoord$+","+yCoord$
PRINT #N%, "set grid xtics"
PRINT #N%, "set grid ytics"
PRINT #N%, "set xtics "+xTics$
PRINT #N%, "set ytics "+yTics$
PRINT #N%, "set grid mxtics"
PRINT #N%, "set grid mytics"
PRINT #N%, "set title "+Quote$+PlotTitle$+Quote$
PRINT #N%, "set xlabel "+Quote$+XaxisLabel$+Quote$
PRINT #N%, "set ylabel "+Quote$+YaxisLabel$+Quote$
PRINT #N%, ProbePlotsFileList$
CLOSE #N%
ProcessID??? = SHELL(GnuPlotEXE$+" cmd2d.gp -") : CALL Delay(1##)
END SUB 'Probe2Dplots()

'---
SUB Show2Dprobes(RC),Np%,Nt%,j&,Frep,BestFitness,BestProbeNumber%,BestTimeStep&,FunctionName$,RepositionFactor$,Gamma)
LOCAL N%, p%
LOCAL A$, PlotFileName$, PlotTitle$, Symbols$
LOCAL xMin$, xMax$, yMin$, yMax$
LOCAL s1, s2, s3, s4 AS EXT
PlotFileName$ = "Probes("+REMOVE$(STR$(j&),ANY" ")+" )"
IF j& > 0 THEN 'PLOT PROBES AT THIS TIME STEP
PlotTitle$ = "\nLOCATIONS OF "+REMOVE$(STR$(Np%),ANY" ") + " PROBES AT TIME STEP" + STR$(j&) + " / " + REMOVE$(STR$(Nt&),ANY" ") + "\n" +
"Fitness = "+REMOVE$(STR$(ROUND(BestFitness,3)),ANY" ") + ", Probe #" + REMOVE$(STR$(BestProbeNumber%),ANY" ") + " at Step #" +
REMOVE$(STR$(BestTimeStep&),ANY" ") + " [Frep = "+REMOVE$(STR$(Frep,4),ANY" ") + " + RepositionFactor$ + "]"
ELSE 'PLOT INITIAL PROBE DISTRIBUTION
PlotTitle$ = "\nLOCATIONS OF "+REMOVE$(STR$(Np%),ANY" ") + " INITIAL PROBES FOR " + FunctionName$ + " FUNCTION\n[gamma =
"+STR$(ROUND(Gamma,3))+"]\n"
END IF
N% = FREEFILE : OPEN PlotFileName$ FOR OUTPUT AS #N%
FOR p% = 1 TO Np% : PRINT #N%, USING$("#####.#####.#####.#####",R(p%,1,j&),R(p%,2,j&)) : NEXT p%
CLOSE #N%
s1 = 1.1## : s2 = 1.1## : s3 = 1.1## : s4 = 1.1## 'expand plots axes by 10%
IF xMin(1) > 0## THEN s1 = 0.9##
IF xMax(1) < 0## THEN s2 = 0.9##
IF xMin(2) > 0## THEN s3 = 0.9##
IF xMax(2) < 0## THEN s4 = 0.9##
xMin$ = REMOVE$(STR$(s1*xMin(1),2),ANY" ")
xMax$ = REMOVE$(STR$(s2*xMax(1),2),ANY" ")
yMin$ = REMOVE$(STR$(s3*yMin(2),2),ANY" ")
yMax$ = REMOVE$(STR$(s4*yMax(2),2),ANY" ")
CALL TwoDplot(PlotFileName$,PlotTitle$,0.6,"0.7","x1\n","nx2","NO","NO",xMin$,xMax$,yMin$,yMax$,5,"5","wgnuplot.exe", " pointsize 1 linewidth
2","")
KILL PlotFileName$ 'erase plot data file after probes have been displayed
END SUB 'Show2Dprobes()

'---
SUB Show3Dprobes(RC),Np%,Nd%,Nt%,j&,Frep,BestFitness,BestProbeNumber%,BestTimeStep&,FunctionName$,RepositionFactor$,Gamma)
LOCAL N%, p%, PlotWindowULC_X%, PlotWindowULC_Y%, PlotWindowWidth%, PlotWindowHeight%, PlotWindowOffset%
LOCAL A$, PlotFileName$, PlotTitle$, Symbols$, Annotation$
LOCAL xMin$, xMax$, yMin$, yMax$, zMin$, zMax$
LOCAL s1, s2, s3, s4, s5, s6 AS EXT
PlotFileName$ = "Probes("+REMOVE$(STR$(j&),ANY" ")+" )"
IF j& > 0 THEN 'PLOT PROBES AT THIS TIME STEP
PlotTitle$ = "\nLOCATIONS OF "+REMOVE$(STR$(Np%),ANY" ") + " PROBES AT TIME STEP" + STR$(j&) + " / " + REMOVE$(STR$(Nt&),ANY" ") + "\n" +
"Fitness = "+REMOVE$(STR$(ROUND(BestFitness,3)),ANY" ") + ", Probe #" + REMOVE$(STR$(BestProbeNumber%),ANY" ") + " at Step #" +
REMOVE$(STR$(BestTimeStep&),ANY" ") + " [Frep = "+REMOVE$(STR$(Frep,4),ANY" ") + " + RepositionFactor$ + "]"
ELSE 'PLOT INITIAL PROBE DISTRIBUTION
A$ = "" : IF Gamma > 0## AND Gamma < 1## THEN A$ = "0"
PlotTitle$ = "\n"+REMOVE$(STR$(Np%),ANY" ") + "-PROBE IPD FOR FUNCTION " + FunctionName$ + ", GAMMA = "+A$+REMOVE$(STR$(ROUND(Gamma,3)),ANY" ")
END IF
' ----- Probe Coordinates -----
N% = FREEFILE : OPEN PlotFileName$ FOR OUTPUT AS #N%
PRINT #N%, USING$("#####.#####.#####.#####.#####.#####",R(1.1,j&),R(1.2,j&),R(1.3,j&)) 'This line repeats Probe #1's coordinates. It's
necessary 'to deal with a plotting artifact in GnuPlot!
FOR p% = 1 TO Np% : PRINT #N%, USING$("#####.#####.#####.#####.#####.#####",R(p%,1,j&),R(p%,2,j&),R(p%,3,j&)) : NEXT p%
CLOSE #N%

```



```

----- Principal Diagonal -----
N% = FREEFILE : OPEN "diag" FOR OUTPUT AS #N%
  PRINT #N%, USING$( "#####.#####.#####.#####.#####",XiMin(1),XiMin(2),XiMin(3))
  PRINT #N%, ""
  PRINT #N%, USING$( "#####.#####.#####.#####.#####",XiMax(1),XiMax(2),XiMax(3))
CLOSE #N%

----- Probe Line #1 -----
N% = FREEFILE : OPEN "probeline1" FOR OUTPUT AS #N%
  PRINT #N%, USING$( "#####.#####.#####.#####.#####",R(1,1,j&),R(1,2,j&),R(1,3,j&))
  PRINT #N%, ""
  PRINT #N%, USING$( "#####.#####.#####.#####.#####",R(Np%/Nd%,1,j&),R(Np%/Nd%,2,j&),R(Np%/Nd%,3,j&))
CLOSE #N%

----- Probe Line #2 -----
N% = FREEFILE : OPEN "probeline2" FOR OUTPUT AS #N%
  PRINT #N%, USING$( "#####.#####.#####.#####.#####",R(1+Np%/Nd%,1,j&),R(1+Np%/Nd%,2,j&),R(1+Np%/Nd%,3,j&))
  PRINT #N%, ""
  PRINT #N%, USING$( "#####.#####.#####.#####.#####",R(2+Np%/Nd%,1,j&),R(2+Np%/Nd%,2,j&),R(2+Np%/Nd%,3,j&))
CLOSE #N%

----- Probe Line #3 -----
N% = FREEFILE : OPEN "probeline3" FOR OUTPUT AS #N%
  PRINT #N%, USING$( "#####.#####.#####.#####.#####",R(1+2*Np%/Nd%,1,j&),R(1+2*Np%/Nd%,2,j&),R(1+2*Np%/Nd%,3,j&))
  PRINT #N%, ""
  PRINT #N%, USING$( "#####.#####.#####.#####.#####",R(3+Np%/Nd%,1,j&),R(3+Np%/Nd%,2,j&),R(3+Np%/Nd%,3,j&))
CLOSE #N%

----- RE-PLOT PROBE #1 BECAUSE OF SOME ARTIFACT THAT DROPS IT FROM PROBE LINE #1 ?????? -----
N% = FREEFILE : OPEN "probe1" FOR OUTPUT AS #N%
  PRINT #N%, USING$( "#####.#####.#####.#####.#####",R(1,1,j&),R(1,2,j&),R(1,3,j&))
  PRINT #N%, USING$( "#####.#####.#####.#####.#####",R(1,1,j&),R(1,2,j&),R(1,3,j&))
CLOSE #N%

s1 = 1.1## : s2 = s1 : s3 = s1 : s4 = s1 : s5 = s1 : s6 = s1 'expand plots axes by 10%
IF XiMin(1) > 0## THEN s1 = 0.9##
IF XiMax(1) < 0## THEN s2 = 0.9##
IF XiMin(2) > 0## THEN s3 = 0.9##
IF XiMax(2) < 0## THEN s4 = 0.9##
IF XiMin(3) > 0## THEN s5 = 0.9##
IF XiMax(3) < 0## THEN s6 = 0.9##

xMin$ = REMOVE$(STR$(s1*XiMin(1),2),.ANY" ")
xMax$ = REMOVE$(STR$(s2*XiMax(1),2),.ANY" ")
yMin$ = REMOVE$(STR$(s3*XiMin(2),2),.ANY" ")
yMax$ = REMOVE$(STR$(s4*XiMax(2),2),.ANY" ")
zMin$ = REMOVE$(STR$(s5*XiMin(3),2),.ANY" ")
zMax$ = REMOVE$(STR$(s6*XiMax(3),2),.ANY" ")

'USAGE: CALL ThreeDplot3(PlotFileName$,PlotTitle$,Annotation$,xCoord$,yCoord$,zCoord$, _
      XaxisLabel$,YaxisLabel$,ZaxisLabel$,zMin$,zMax$,GnuPlotEXE$,xStart$,xStop$,yStart$,yStop$)
PlotWindowULC_X% = 50 : PlotWindowULC_Y% = 50 : PlotWindowWidth% = 1000 : PlotWindowHeight% = 800
PlotWindowOffset% = 100*Gamma
CALL CreateGnuPlotINIfile(PlotWindowULC_X%+PlotWindowOffset%,PlotWindowULC_Y%+PlotWindowOffset%,PlotWindowWidth%,PlotWindowHeight%)
CALL ThreeDplot3(PlotFileName$,PlotTitle$,Annotation$, "0.6", "0.7", "0.8" _
      "x1", "x2", "x3", zMin$, zMax$, "wgnuplot.exe", xMin$, xMax$, yMin$, yMax$)
'KILL PlotFileName$ 'erase plot data file after probes have been displayed
END SUB 'Show3Dprobes()

'---
SUB ThreeDplot3(PlotFileName$,PlotTitle$,Annotation$,xCoord$,yCoord$,zCoord$, _
      XaxisLabel$,YaxisLabel$,ZaxisLabel$,zMin$,zMax$,GnuPlotEXE$,xStart$,xStop$,yStart$,yStop$)
  LOCAL N%, ProcID???
  N% = FREEFILE
  OPEN "cmd3d.gp" FOR OUTPUT AS #N%
  PRINT #N%, "set pm3d"
  PRINT #N%, "show pm3d"
  PRINT #N%, "set hidden3d"
  PRINT #N%, "set view 45, 45, 1, 1"
  PRINT #N%, "set view 45, 60, 1, 1"
  IF zMin$ <> "" AND zMax$ <> "" THEN PRINT #N%, "set zrange [ "+zMin$+" : "+zMax$+" ]"
  PRINT #N%, "set xrange [ "+xStart$+" : "+xStop$+" ]"
  PRINT #N%, "set yrange [ "+yStart$+" : "+yStop$+" ]"
  PRINT #N%, "set label " + Quote$ + Annotation$ + Quote$+" at graph "+xCoord$+" , "+yCoord$+" , "+zCoord$
  PRINT #N%, "show label"
  PRINT #N%, "set grid xtics ytics ztics"
  PRINT #N%, "show grid"
  PRINT #N%, "set title " + Quote$+PlotTitle$ + Quote$
  PRINT #N%, "set xlabel " + Quote$+XaxisLabel$ + Quote$
  PRINT #N%, "set ylabel " + Quote$+YaxisLabel$ + Quote$
  PRINT #N%, "set zlabel " + Quote$+ZaxisLabel$ + Quote$
  PRINT #N%, "unset colorbox"
  print #N%, "set style fill"
  PRINT #N%, "splot " + Quote$+PlotFileName$ + Quote$ + " notitle lw 1 pt 8, " _
    + Quote$ + "diag" + Quote$ + " notitle w l, " _
    + Quote$ + "probeline1" + Quote$ + " notitle w l, " _
    + Quote$ + "probeline2" + Quote$ + " notitle w l, " _
    + Quote$ + "probeline3" + Quote$ + " notitle w l"
  CLOSE #N%
  ProcID??? = SHELL(GnuPlotEXE$+" cmd3d.gp -")
  CALL Delay(1##)
END SUB 'ThreeDplot3()

'-----

```

```

SUB TwoDPlot(PlotFileName$,PlotTitle$,xCoord$,yCoord$,xAxisLabel$,yAxisLabel$,
LogXaxis$,LogYaxis$,xMin$,xMax$,yMin$,yMax$,xTics$,yTics$,GnuPlotEXE$,Linetype$,Annotation$)

LOCAL N%, ProcessID???

N% = FREEFILE

OPEN "cmd2d.gp" FOR OUTPUT AS #N%

IF LogXaxis$ = "YES" AND LogYaxis$ = "NO" THEN PRINT #N%, "set logscale x"
IF LogXaxis$ = "NO" AND LogYaxis$ = "YES" THEN PRINT #N%, "set logscale y"
IF LogXaxis$ = "YES" AND LogYaxis$ = "YES" THEN PRINT #N%, "set logscale xy"

IF xMin$ <> "" AND xMax$ <> "" THEN PRINT #N%, "set xrange ["+xMin$+":"+xMax$+"]"
IF yMin$ <> "" AND yMax$ <> "" THEN PRINT #N%, "set yrange ["+yMin$+":"+yMax$+"]"

PRINT #N%, "set label " + Quote$ + Annotation$ + Quote$ + " at graph " + xCoord$ + " , " + yCoord$
PRINT #N%, "set grid xtics " + XTics$
PRINT #N%, "set grid ytics " + YTics$
PRINT #N%, "set grid mxtics"
PRINT #N%, "set grid mytics"
PRINT #N%, "show grid"
PRINT #N%, "set title " + Quote$+PlotTitle$+Quote$
PRINT #N%, "set xlabel " + Quote$+XaxisLabel$+Quote$
PRINT #N%, "set ylabel " + Quote$+YaxisLabel$+Quote$

PRINT #N%, "plot "+Quote$+PlotFileName$+Quote$+" notitle"+Linetype$

CLOSE #N%

ProcessID??? = SHELL(GnuPlotEXE$+" cmd2d.gp -") : CALL Delay(1#)

END SUB 'TwoDPlot()

'-----
SUB CreateGnuPlotINIfile(PlotWindowULC_X%,PlotWindowULC_Y%,PlotWindowWidth%,PlotWindowHeight%)

LOCAL N%, WinPath$, A$, B$, WindowsDirectory$

WinPath$ = UCASE$(ENVIRON$("Path"))'DIRS("C:\WINDOWS",23)

DO
  B$ = A$
  A$ = EXTRACT$(WinPath$,",")
  WinPath$ = REMOVE$(WinPath$,A$+";")
  IF RIGHT$(A$,7) = "WINDOWS" OR A$ = B$ THEN EXIT LOOP
  IF RIGHT$(A$,5) = "INNT" OR A$ = B$ THEN EXIT LOOP
LOOP

WindowsDirectory$ = A$

N% = FREEFILE

'----- WGNUPLOT.INPUT FILE -----
OPEN WindowsDirectory$+"\wgnuplot.ini" FOR OUTPUT AS #N%

PRINT #N%,"[WGNUPLOT]"
PRINT #N%,"TextOrigin=0 0"
PRINT #N%,"TextSize=640 150"
PRINT #N%,"TextFont=Terminal,9"
PRINT #N%,"GraphOrigin="+REMOVE$(STR$(PlotWindowULC_X%),ANY" ")+" "+REMOVE$(STR$(PlotWindowULC_Y%),ANY" ")
PRINT #N%,"GraphSize="+REMOVE$(STR$(PlotWindowWidth%),ANY" ")+" "+REMOVE$(STR$(PlotWindowHeight%),ANY" ")
PRINT #N%,"GraphFont=Arial,10"
PRINT #N%,"GraphColor=1"
PRINT #N%,"GraphToTop=1"
PRINT #N%,"GraphBackground=255 255 255"
PRINT #N%,"Border=0 0 0 0"
PRINT #N%,"Axis=192 192 192 2 2"
PRINT #N%,"Line1=0 0 255 0 0"
PRINT #N%,"Line2=0 255 0 0 1"
PRINT #N%,"Line3=255 0 0 0 2"
PRINT #N%,"Line4=255 0 255 0 3"
PRINT #N%,"Line5=0 0 128 0 4"

CLOSE #N%

END SUB 'CreateGnuPlotINIfile()

'-----
SUB Delay(NumSecs)

LOCAL StartTime, StopTime AS EXT

StartTime = TIMER

DO UNTIL (StopTime-StartTime) >= NumSecs
  StopTime = TIMER
LOOP

END SUB 'Delay()

'-----
SUB MathematicalConstants
EulerConst = 0.577215664901532860606512##
Pi = 3.141592653589793238462643##
Pi2 = Pi/2##
Pi4 = Pi/4##
TwoPi = 2##*Pi
FourPi = 4##*Pi
e = 2.718281828459045235360287##
Root2 = 1.4142135623730950488##
END SUB

'-----
SUB AlphabetAndDigits
Alphabet$ = "ABCDEFGHIJKLMNOPQRSTUVWXYZabcdefghijklmnopqrstuvwxyz"
Digits$ = "0123456789"
RunID$ = REMOVE$(DATE$+"_"+TIME$,ANY Alphabet$+" :~/")
END SUB

'-----
SUB SpecialSymbols
Quote$ = CHR$(34) 'Quotation mark "
SpecialCharacters$ = "() , # ; : / _"
END SUB

```

```

'-----
SUB EMconstants
Mu0 = 4E-7##*pi 'hy/meter
Eps0 = 8.854##*1E-12 'fd/meter
c = 2.998E8## 'velocity of light, 1##/SQR(Mu0*Eps0) 'meters/sec
eta0 = SQR(Mu0/Eps0) 'impedance of free space, ohms
END SUB

'-----
SUB ConversionFactors
Rad2Deg = 180##/pi
Deg2Rad = 1##/Rad2Deg
Feet2Meters = 0.3048##
Meters2Feet = 1##/Feet2Meters
Inches2Meters = 0.0254##
Meters2Inches = 1##/Inches2Meters
Miles2Meters = 1609.344##
Meters2Miles = 1##/Miles2Meters
NautMi2Meters = 1852##
Meters2NautMi = 1##/NautMi2Meters
END SUB

'-----
SUB ShowConstants 'puts up msgbox showing all constants
LOCAL A$

A$ = _
"Mathematical Constants:"+CHR$(13)+_
"Euler const="+STR$(EulerConst)+CHR$(13)+_
"pi="+STR$(pi)+CHR$(13)+_
"pi/2="+STR$(Pi2)+CHR$(13)+_
"pi/4="+STR$(Pi4)+CHR$(13)+_
"2pi="+STR$(TwoPi)+CHR$(13)+_
"4pi="+STR$(FourPi)+CHR$(13)+_
"e="+STR$(e)+CHR$(13)+_
"sqr2="+STR$(root2)+CHR$(13)+CHR$(13)+_
"Alphabet, Digits & Special Characters:"+CHR$(13)+_
"Alphabet="+Alphabet$+CHR$(13)+_
"Digits="+Digits$+CHR$(13)+_
"quote="+Quotes$+CHR$(13)+_
"Spec chars="+SpecialCharacters$+CHR$(13)+CHR$(13)+_
"&M Constants:"+CHR$(13)+_
"Mu0="+STR$(Mu0)+CHR$(13)+_
"Eps0="+STR$(Eps0)+CHR$(13)+_
"c="+STR$(c)+CHR$(13)+_
"Eta0="+STR$(eta0)+CHR$(13)+CHR$(13)+_
"Conversion Factors:"+CHR$(13)+_
"Rad2Deg="+STR$(Rad2Deg)+CHR$(13)+_
"Deg2Rad="+STR$(Deg2Rad)+CHR$(13)+_
"ft2meters="+STR$(Feet2Meters)+CHR$(13)+_
"meters2ft="+STR$(Meters2Feet)+CHR$(13)+_
"Inches2Meters="+STR$(Inches2Meters)+CHR$(13)+_
"Meters2Inches="+STR$(Meters2Inches)+CHR$(13)+_
"Miles2Meters="+STR$(Miles2Meters)+CHR$(13)+_
"Meters2Miles="+STR$(Meters2Miles)+CHR$(13)+_
"NautMi2Meters="+STR$(NautMi2Meters)+CHR$(13)+_
"Meters2NautMi="+STR$(Meters2NautMi)+CHR$(13)+CHR$(13)

MSGBOX(A$)
END SUB

'-----
SUB DisplayRmatrix(Np%,Nd%,Nt&,R())
LOCAL p%, i%, j&, A$

A$ = "Position Vector Matrix R()"+CHR$(13)
FOR p% = 1 TO Np%
FOR i% = 1 TO Nd%
FOR j& = 0 TO Nt&
A$ = A$ + "R(" +STR$(p%)+", " +STR$(i%)+", " +STR$(j&)+ " )="+STR$(R(p%,i%,j&)) + CHR$(13)
NEXT j&
NEXT i%
NEXT p%
MSGBOX(A$)
END SUB

'-----
SUB DisplayRmatrixThisTimeStep(Np%,Nd%,j&,R(),Gamma)
LOCAL p%, i%, A$, B$

A$ = "Position Vector Matrix R() at step "+STR$(j&)+", Gamma="+STR$(Gamma)+" "+CHR$(13)+CHR$(13)
FOR p% = 1 TO Np%
A$ = A$ + "Probe#"+REMOVE$(STR$(p%),ANY" "): "
B$ = ""
FOR i% = 1 TO Nd%
B$ = B$ + " " + USING$( "###.##",R(p%,i%,j&))
NEXT i%
A$ = A$ + B$ + CHR$(13)
NEXT p%
MSGBOX(A$)
END SUB

'-----
SUB DisplayAmatrix(Np%,Nd%,Nt&,A())
LOCAL p%, i%, j&, A$

A$ = "Acceleration Vector Matrix A()"+CHR$(13)
FOR p% = 1 TO Np%

```

```

        FOR i% = 1 TO Nd%
            FOR j& = 0 TO Nt&
                A$ = A$ + "A(" + STR$(p%) + ", " + STR$(i%) + ", " + STR$(j&) + ") = " + STR$(A(p%, i%, j&)) + CHR$(13)
            NEXT j&
        NEXT i%
    NEXT p%
    MSGBOX(A$)
END SUB
'-----
SUB DisplayAmatrixThisTimeStep(Np%, Nd%, j&, A())
LOCAL p%, i%, A$
A$ = "Acceleration matrix A() at step " + STR$(j&) + ": " + CHR$(13)
FOR p% = 1 TO Np%
    FOR i% = 1 TO Nd%
        A$ = A$ + "A(" + STR$(p%) + ", " + STR$(i%) + ", " + STR$(j&) + ") = " + STR$(A(p%, i%, j&)) + CHR$(13)
    NEXT i%
NEXT p%
MSGBOX(A$)
END SUB
'-----
SUB DisplayMmatrix(Np%, Nt&, M())
LOCAL p%, j&, A$
A$ = "Fitness Matrix M() " + CHR$(13)
FOR p% = 1 TO Np%
    FOR j& = 0 TO Nt&
        A$ = A$ + "M(" + STR$(p%) + ", " + STR$(j&) + ") = " + STR$(M(p%, j&)) + CHR$(13)
    NEXT j&
NEXT p%
MSGBOX(A$)
END SUB
'-----
SUB DisplayMbestMatrix(Np%, Nt&, Mbest())
LOCAL p%, j&, A$
A$ = "Np= " + STR$(Np%) + " Nt=" + STR$(Nt&) + CHR$(13) + "Fitness Matrix Mbest() " + CHR$(13)
FOR p% = 1 TO Np%
    FOR j& = 0 TO Nt&
        A$ = A$ + "Mbest(" + STR$(p%) + ", " + STR$(j&) + ") = " + STR$(Mbest(p%, j&)) + CHR$(13)
    NEXT j&
NEXT p%
MSGBOX(A$)
END SUB
'-----
SUB DisplayMmatrixThisTimeStep(Np%, j&, M())
LOCAL p%, A$
A$ = "Fitness matrix M() at step " + STR$(j&) + ": " + CHR$(13)
FOR p% = 1 TO Np%
    A$ = A$ + "M(" + STR$(p%) + ", " + STR$(j&) + ") = " + STR$(M(p%, j&)) + CHR$(13)
NEXT p%
MSGBOX(A$)
END SUB
'-----
SUB DisplayxiMinMax(Nd%, xiMin(), xiMax())
LOCAL i%, A$
A$ = ""
FOR i% = 1 TO Nd%
    A$ = A$ + "xiMin(" + STR$(i%) + ") = " + STR$(xiMin(i%)) + " xiMax(" + STR$(i%) + ") = " + STR$(xiMax(i%)) + CHR$(13)
NEXT i%
MSGBOX(A$)
END SUB
'-----
SUB DisplayRunParameters2(FunctionName$, Nd%, Np%, Nt&, G, DeltaT, Alpha, Beta, Freq, PlaceInitialProbes$, InitialAcceleration$, RepositionFactor$)
LOCAL A$
A$ = "Function = " + FunctionName$ + CHR$(13) + _
    "Nd = " + STR$(Nd%) + CHR$(13) + _
    "Np = " + STR$(Np%) + CHR$(13) + _
    "Nt = " + STR$(Nt&) + CHR$(13) + _

```

```

"G = "+STR$(G)+CHR$(13)+_
"DeltaT = "+STR$(DeltaT)+CHR$(13)+_
"Alpha = "+STR$(Alpha)+CHR$(13)+_
"Beta = "+STR$(Beta)+CHR$(13)+_
"Frep = "+STR$(Frep)+CHR$(13)+_
"Init Probes: "+PlaceInitialProbes$+CHR$(13)+_
"Init Accl: "+InitialAcceleration$+CHR$(13)+_
"Retrive Method: "+RepositionFactor$+CHR$(13)

MSGBOX(A$)

END SUB

'-----

SUB
TabulateDprobeCoordinates(MaxDprobesPlotted%,Nd%,Np%,LastStep&,G,DeltaT,Alpha,Beta,Frep,R(C),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,Gamma)

LOCAL N%, ProbeNum%, FileHeader$, A$, B$, C$, D$, E$, F$, H$, StepNum&, FieldNumber% 'kludgy, yes, but it accomplishes its purpose...

CALL
GetPlotAnnotation(FileHeader$,Nd%,Np%,LastStep&,G,DeltaT,Alpha,Beta,Frep,R(C),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,Gamma)

REPLACE "\n" WITH " " IN FileHeader$
FileHeader$ = LEFT$(FileHeader$,LEN(FileHeader$)-2)
FileHeader$ = "PROBE COORDINATES" + CHR$(13) +_
"-----" + CHR$(13) + FileHeader$

N% = FREEFILE : OPEN "ProbeCoordinates.DAT" FOR OUTPUT AS #N%
A$ = " Step # " : B$ = " ---- " : C$ = ""
FOR ProbeNum% = 1 TO Np% 'create out data file header
SELECT CASE ProbeNum%
CASE 1 TO 9 : E$ = "" : F$ = " " : H$ = " "
CASE 10 TO 99 : E$ = "-" : F$ = " " : H$ = " "
CASE 100 TO 999 : E$ = "--" : F$ = " " : H$ = " "
END SELECT
A$ = A$ + "P" + NoSpaces$(ProbeNum%+0,0) + F$ 'note: adding zero to ProbeNum% necessary to convert to floating point...
B$ = B$ + E$ + "-" + H$
C$ = C$ + "#####.### "
C$ = C$ + "##.#####"
NEXT ProbeNum%

PRINT #N%, FileHeader$ + CHR$(13) : PRINT #N%, A$ : PRINT #N%, B$
FOR StepNum& = 0 TO LastStep&
D$ = USING$("##### ",StepNum&)
FOR ProbeNum% = 1 TO Np% : D$ = D$ + USING$(C$,R(ProbeNum%,1,StepNum&)) : NEXT ProbeNum%
PRINT #N%, D$
NEXT StepNum&

CLOSE #N%
END SUB 'TabulateDprobeCoordinates()

'-----

SUB
PlotDprobePositions(MaxDprobesPlotted%,Nd%,Np%,LastStep&,G,DeltaT,Alpha,Beta,Frep,R(C),PlaceInitialProbes$,InitialAcceleration$,RepositionFactor$,FunctionName$,Gamma)
'plots on-screen 1D function probe positions vs time step if Np <= 10

LOCAL ProcessID???, N%, n1%, n2%, n3%, n4%, n5%, n6%, n7%, n8%, n9%, n10%, n11%, n12%, n13%, n14%, n15%, ProbeNum%, StepNum&, A$

LOCAL PlotAnnotation$

IF Np% > MaxDprobesPlotted% THEN EXIT SUB
CALL CLEANUP 'delete old "px" plot files, if any
ProbeNum% = 0

DO 'create output data files, probe-by-probe
INCR ProbeNum% : n1% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n1% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n2% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n2% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n3% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n3% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n4% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n4% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n5% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n5% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n6% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n6% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n7% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n7% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n8% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n8% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n9% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n9% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n10% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n10% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n11% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n11% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n12% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n12% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n13% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n13% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n14% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n14% : IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : n15% = FREEFILE : OPEN "P"+REMOVE$(STR$(ProbeNum%),ANY" ") FOR OUTPUT AS #n15% : IF ProbeNum% = Np% THEN EXIT LOOP
LOOP

ProbeNum% = 0

DO 'output probe positions as a function of time step
INCR ProbeNum% : FOR StepNum& = 0 TO LastStep& : PRINT #n1%, USING$("#####.#####",StepNum&,R(ProbeNum%,1,StepNum&)) : NEXT StepNum& :
IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : FOR StepNum& = 0 TO LastStep& : PRINT #n2%, USING$("#####.#####",StepNum&,R(ProbeNum%,1,StepNum&)) : NEXT StepNum& :
IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : FOR StepNum& = 0 TO LastStep& : PRINT #n3%, USING$("#####.#####",StepNum&,R(ProbeNum%,1,StepNum&)) : NEXT StepNum& :
IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : FOR StepNum& = 0 TO LastStep& : PRINT #n4%, USING$("#####.#####",StepNum&,R(ProbeNum%,1,StepNum&)) : NEXT StepNum& :
IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : FOR StepNum& = 0 TO LastStep& : PRINT #n5%, USING$("#####.#####",StepNum&,R(ProbeNum%,1,StepNum&)) : NEXT StepNum& :
IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : FOR StepNum& = 0 TO LastStep& : PRINT #n6%, USING$("#####.#####",StepNum&,R(ProbeNum%,1,StepNum&)) : NEXT StepNum& :
IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : FOR StepNum& = 0 TO LastStep& : PRINT #n7%, USING$("#####.#####",StepNum&,R(ProbeNum%,1,StepNum&)) : NEXT StepNum& :
IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : FOR StepNum& = 0 TO LastStep& : PRINT #n8%, USING$("#####.#####",StepNum&,R(ProbeNum%,1,StepNum&)) : NEXT StepNum& :
IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : FOR StepNum& = 0 TO LastStep& : PRINT #n9%, USING$("#####.#####",StepNum&,R(ProbeNum%,1,StepNum&)) : NEXT StepNum& :
IF ProbeNum% = Np% THEN EXIT LOOP
INCR ProbeNum% : FOR StepNum& = 0 TO LastStep& : PRINT #n10%, USING$("#####.#####",StepNum&,R(ProbeNum%,1,StepNum&)) : NEXT StepNum& :
IF ProbeNum% = Np% THEN EXIT LOOP

```



```

SUB GetTestFunctionNumber(FunctionName$)
LOCAL hdlg AS DWORD
LOCAL N%, M%
LOCAL FrameWidth&, FrameHeight&, BoxWidth&, BoxHeight&
BoxWidth& = 276 : BoxHeight& = 300 : FrameWidth& = 82 : FrameHeight& = BoxHeight&-5
BoxWidth& = 276 : BoxHeight& = 300 : FrameWidth& = 90 : FrameHeight& = BoxHeight&-5
DIALOG NEW 0, "CENTRAL FORCE OPTIMIZATION TEST FUNCTIONS",,, BoxWidth&, BoxHeight&, %WS_CAPTION OR %WS_SYSMENU, 0 TO hdlg

CONTROL ADD FRAME, hdlg, %IDC_FRAME1, "Test Functions", 5, 2, FrameWidth&, FrameHeight&
CONTROL ADD FRAME, hdlg, %IDC_FRAME2, "GSO Test Functions", 105, 2, FrameWidth&, 255

CONTROL ADD OPTION, hdlg, %IDC_Function_Number1, "Parrott F4", 10, 14, 70, 10, %WS_GROUP OR %WS_TABSTOP
CONTROL ADD OPTION, hdlg, %IDC_Function_Number2, "SGO", 10, 24, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number3, "Goldstein-Price", 10, 34, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number4, "Step", 10, 44, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number5, "Schwefel 2.26", 10, 54, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number6, "Colville", 10, 64, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number7, "Griewank", 10, 74, 70, 10

CONTROL ADD OPTION, hdlg, %IDC_Function_Number31, "PBM #1", 10, 84, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number32, "PBM #2", 10, 94, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number33, "PBM #3", 10, 104, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number34, "PBM #4", 10, 114, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number35, "PBM #5", 10, 124, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number36, "Himmelblau", 10, 134, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number37, "Rosenbrock", 10, 144, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number38, "Sphere", 10, 154, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number39, "HimmelblauLO", 10, 164, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number40, "Tripod", 10, 174, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number41, "Rosenbrock F6", 10, 184, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number42, "Comp Spring", 10, 194, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number43, "Gear Train", 10, 204, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number44, "Loaded Bowtie", 10, 214, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number45, "Yagi Array", 10, 224, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number46, "Reserved", 10, 234, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number47, "Reserved", 10, 244, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number48, "Reserved", 10, 254, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number49, "Reserved", 10, 264, 70, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number50, "Reserved", 10, 274, 70, 10

----- Test Functions from GSO Paper -----
CONTROL ADD OPTION, hdlg, %IDC_Function_Number8, "F1", 120, 14, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number9, "F2", 120, 24, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number10, "F3", 120, 34, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number11, "F4", 120, 44, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number12, "F5", 120, 54, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number13, "F6", 120, 64, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number14, "F7", 120, 74, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number15, "F8", 120, 84, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number16, "F9", 120, 94, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number17, "F10", 120, 104, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number18, "F11", 120, 114, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number19, "F12", 120, 124, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number20, "F13", 120, 134, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number21, "F14", 120, 144, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number22, "F15", 120, 154, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number23, "F16", 120, 164, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number24, "F17", 120, 174, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number25, "F18", 120, 184, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number26, "F19", 120, 194, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number27, "F20", 120, 204, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number28, "F21", 120, 214, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number29, "F22", 120, 224, 40, 10
CONTROL ADD OPTION, hdlg, %IDC_Function_Number30, "F23", 120, 234, 40, 10

CONTROL SET OPTION hdlg, %IDC_Function_Number1, %IDC_Function_Number3 'default to Parrott F4

-----
CONTROL ADD BUTTON, hdlg, %IDOK, "&ok", 200, 0.45##*BoxHeight&, 50, 14

DIALOG SHOW MODAL hdlg CALL dlgProc
CALL Delay(1##)
IF FunctionNumber% < 1 OR FunctionNumber% > 45 THEN
FunctionNumber% = 1 : MSGBOX("Error in function number...")
END IF
SELECT CASE FunctionNumber%
CASE 1 : FunctionName$ = "ParrottF4"
CASE 2 : FunctionName$ = "SGO"
CASE 3 : FunctionName$ = "GP"
CASE 4 : FunctionName$ = "STEP"
CASE 5 : FunctionName$ = "SCHWEFEL_226"
CASE 6 : FunctionName$ = "COLVILLE"
CASE 7 : FunctionName$ = "GRIEWANK"
CASE 8 : FunctionName$ = "F1"
CASE 9 : FunctionName$ = "F2"
CASE 10 : FunctionName$ = "F3"
CASE 11 : FunctionName$ = "F4"
CASE 12 : FunctionName$ = "F5"
CASE 13 : FunctionName$ = "F6"
CASE 14 : FunctionName$ = "F7"
CASE 15 : FunctionName$ = "F8"
CASE 16 : FunctionName$ = "F9"
CASE 17 : FunctionName$ = "F10"
CASE 18 : FunctionName$ = "F11"
CASE 19 : FunctionName$ = "F12"
CASE 20 : FunctionName$ = "F13"
CASE 21 : FunctionName$ = "F14"
CASE 22 : FunctionName$ = "F15"
CASE 23 : FunctionName$ = "F16"
CASE 24 : FunctionName$ = "F17"
CASE 25 : FunctionName$ = "F18"
CASE 26 : FunctionName$ = "F19"
CASE 27 : FunctionName$ = "F20"
CASE 28 : FunctionName$ = "F21"
CASE 29 : FunctionName$ = "F22"
CASE 30 : FunctionName$ = "F23"
CASE 31 : FunctionName$ = "PBM_1"
CASE 32 : FunctionName$ = "PBM_2"
CASE 33 : FunctionName$ = "PBM_3"

```

```

CASE 34: FunctionName$ = "PBM_4"
CASE 35: FunctionName$ = "PBM_5"
CASE 36: FunctionName$ = "HIMMELBLAU"
CASE 37: FunctionName$ = "ROSENBROCK"
CASE 38: FunctionName$ = "SPHERE"
CASE 39: FunctionName$ = "HIMMELBLAUNLO"
CASE 40: FunctionName$ = "TRIPOD"
CASE 41: FunctionName$ = "ROSENBROCKF6"
CASE 42: FunctionName$ = "COMPRESSIONSPRING"
CASE 43: FunctionName$ = "GEARTRAIN"
CASE 44: FunctionName$ = "BOWTIE"
CASE 45: FunctionName$ = "YAGI"

END SELECT

END SUB

'-----
CALLBACK FUNCTION DlgProc() AS LONG
'-----
' callback procedure for the main dialog
'-----
LOCAL c, lRes AS LONG, sText AS STRING

SELECT CASE AS LONG CBMSG
CASE %WM_INITDIALOG' %WM_INITDIALOG is sent right before the dialog is shown.
CASE %WM_COMMAND      ' <- a control is calling
    SELECT CASE AS LONG CBCTL ' <- look at control's id
    CASE %IDOK          ' <- OK button or Enter key was pressed

        IF CBCTMSG = %BN_CLICKED THEN
            '-----
            ' Loop through the Function_Number controls
            ' to see which one is selected
            '-----
            FOR c = %IDC_Function_Number1 TO %IDC_Function_Number50

                CONTROL GET CHECK CBHNDL, c TO lRes

                IF lRes THEN EXIT FOR

            NEXT 'c holds the id for selected test function.

            FunctionNumber% = c-120

            DIALOG END CBHNDL

        END IF

    END SELECT

END SELECT

END FUNCTION

'----- PBM ANTENNA BENCHMARK FUNCTIONS -----

'Reference for benchmarks PBM_1 through PBM_5:
'Pantoja, M F., Bretones, A. R., Martin, R. G., "Benchmark Antenna Problems for Evolutionary
'Optimization Algorithms," IEEE Trans. Antennas & Propagation, vol. 55, no. 4, April 2007,
'pp. 1111-1121

FUNCTION PBM_1(R(),Nd%,p%,j&) 'PBM Benchmark #1: Max D for variable-Length CF Dipole
LOCAL Z, LengthWaves, ThetaRadians AS EXT
LOCAL N%, Nsegs%, FeedSegNum%
LOCAL NumSegs$, FeedSeg$, HalfLength$, Radius$, ThetaDeg$, Lyne$, GainDB$
LengthWaves = R(p%,1,j&)
ThetaRadians = R(p%,2,j&)
ThetaDeg$ = REMOVE$(STR$(ROUND(ThetaRadians*Rad2Deg,2)),ANY" ")
IF TALLY(ThetaDeg$,".") = 0 THEN ThetaDeg$ = ThetaDeg$+"."
Nsegs% = 2*(INT(100*LengthWaves)\2)+1 '100 segs per wavelength, must be an odd #, VOLTAGE SOURCE
FeedSegNum% = Nsegs%\2 + 1 'center segment number, VOLTAGE SOURCE
NumSegs$ = REMOVE$(STR$(Nsegs%),ANY" ")
FeedSeg$ = REMOVE$(STR$(FeedSegNum%),ANY" ")
HalfLength$ = REMOVE$(STR$(ROUND(LengthWaves/2##,6)),ANY" ")
IF TALLY(HalfLength$,".") = 0 THEN HalfLength$ = HalfLength$+"."
Radius$ = "0.00001" 'REMOVE$(STR$(ROUND(LengthWaves/1000##,6)),ANY" ")
N% = FREEFILE
OPEN "PBML.NEC" FOR OUTPUT AS #N%
PRINT #N%,"CM File: PBML.NEC"
PRINT #N%,"CM Run_ID "+DATE$+" "+TIME$
PRINT #N%,"CM Nd="+STR$(Nd%)+", p="+STR$(p%)+", j="+STR$(j&)
PRINT #N%,"CM R(p,1,j)="+STR$(R(p%,1,j&))+", R(p,2,j)="+STR$(R(p%,2,j&))
PRINT #N%,"CE"
PRINT #N%,"GW 1,"+NumSegs$+",0,0,-"+HalfLength$+",0,0,-"+HalfLength$+", "+Radius$
PRINT #N%,"GE"
PRINT #N%,"EX 0,1,"+FeedSeg$+",0,1,,0." 'VOLTAGE SOURCE
PRINT #N%,"FR 0,1,0,0,299,79564,0."
PRINT #N%,"RP 0,1,1,1001,"+ThetaDeg$+",0,0,0,1000." 'gain at 1000 wavelengths range
PRINT #N%,"XQ"
PRINT #N%,"EN"
CLOSE #N%

'
' - - ANGLES - - - - POWER GAINS - - - - POLARIZATION - - - - E(THETA) - - - - E(PHI) - - -
' THETA PHI VERT. HOR. TOTAL AXIAL TILT SENSE MAGNITUDE PHASE MAGNITUDE PHASE
' DEGREES DEGREES DB DB DB RATIO DEG. DEGREES DEGREES DEGREES DEGREES
' 90.00 0.00 3.91 -999.99 3.91 0.00000 0.00 LINEAR 1.29504E-04 5.37 0.00000E+00 -5.24
' 123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x
' 10 20 30 40 50 60 70 80 90 100 110 120

SHELL "n4l_2k1.exe",0
N% = FREEFILE

```



```

OPEN "PBM1.OUT" FOR INPUT AS #N%
WHILE NOT EOF(N%)
  LINE INPUT #N%, Lyne$
  IF INSTR(Lyne$,"DEGREES DEGREES") > 0 THEN EXIT LOOP
WEND 'position at next data line
LINE INPUT #N%, Lyne$
CLOSE #N%
GainDB$ = REMOVE$(MID$(Lyne$,37,8),ANY" ")
PBM_1 = 10^(VAL(GainDB$)/10##) 'directivity
END FUNCTION 'PBM_1()
'-----
FUNCTION PBM_2(R(),Nd%,p%,j&) 'PBM Benchmark #2: Max D for Variable-Separation Array of CF Dipoles
LOCAL Z, DipoleSeparationWaves, ThetaRadians AS EXT
LOCAL N%, i%
LOCAL NumSegs$, FeedSeg$, Radius$, ThetaDeg$, Lyne$, GainDB$, Xcoord$, WireNum$
DipoleSeparationWaves = R(p%,1,j&)
ThetaRadians = R(p%,2,j&)
ThetaDeg$ = REMOVE$(STR$(ROUND(ThetaRadians*Rad2Deg,2)),ANY" ")
IF TALLY(ThetaDeg$,".") = 0 THEN ThetaDeg$ = ThetaDeg$+"."
NumSegs$ = "49"
FeedSeg$ = "25"
Radius$ = "0.00001"
N% = FREEFILE
OPEN "PBM2.NEC" FOR OUTPUT AS #N%
PRINT #N%,"CM File: PBM2.NEC"
PRINT #N%,"CM Run_ID "+DATE$+" "+TIME$
PRINT #N%,"CM Nd="+STR$(Nd%)+", p="+STR$(p%)+", j="+STR$(j&)
PRINT #N%,"CM R(p,1,j)="+STR$(R(p%,1,j&))+", R(p,2,j)="+STR$(R(p%,2,j&))
PRINT #N%,"CE"
FOR i% = -9 TO 9 STEP 2
  WireNum$ = REMOVE$(STR$(((i%+11)\2),ANY" "))
  Xcoord$ = REMOVE$(STR$(i%*DipoleSeparationWaves/2##),ANY" ")
  PRINT #N%,"GW "+WireNum$+", "+NumSegs$+", "+Xcoord$+",0,-0.25,+Xcoord$+",0,.0.25,+Radius$
NEXT i%
PRINT #N%,"GE"
FOR i% = 1 TO 10
  PRINT #N%,"EX 0,+REMOVE$(STR$(i%),ANY" ")+" "+FeedSeg$+",0,1,.0." 'VOLTAGE SOURCE
NEXT i%
PRINT #N%,"FR 0,1,0,0,299.79564,0."
PRINT #N%,"RP 0,1,1,1001,+ThetaDeg$+",90,.0,.0,1000." 'gain at 1000 wavelengths range
PRINT #N%,"XQ"
PRINT #N%,"EN"
CLOSE #N%
'
' - - ANGLES - - - - POWER GAINS - - - - POLARIZATION - - - - E(THETA) - - - - E(PHI) - - -
' THETA PH1 HOR. TOTAL AXIAL TILT SENSE MAGNITUDE PHASE MAGNITUDE PHASE
' DEGREES DEGREES DB DB DB RATIO DEG. VOLTS/M DEGREES VOLTS/M DEGREES
' 90.00 0.00 3.91 -999.99 3.91 0.00000 0.00 LINEAR 1.29504E-04 5.37 0.00000E+00 5.24
' 123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x
' 10 20 30 40 50 60 70 80 90 100 110 120
SHELL "n41_2k1.exe",0
N% = FREEFILE
OPEN "PBM2.OUT" FOR INPUT AS #N%
WHILE NOT EOF(N%)
  LINE INPUT #N%, Lyne$
  IF INSTR(Lyne$,"DEGREES DEGREES") > 0 THEN EXIT LOOP
WEND 'position at next data line
LINE INPUT #N%, Lyne$
CLOSE #N%
GainDB$ = REMOVE$(MID$(Lyne$,37,8),ANY" ")
IF AddNoiseToPBM2$ = "YES" THEN
  Z = 10^(VAL(GainDB$)/10##) + GaussianDeviate(0##,0.4472##) 'directivity with Gaussian noise (zero mean, 0.2 variance)
ELSE
  Z = 10^(VAL(GainDB$)/10##) 'directivity without noise
END IF
PBM_2 = Z
END FUNCTION 'PBM_2()
'-----
FUNCTION PBM_3(R(),Nd%,p%,j&) 'PBM Benchmark #3: Max D for Circular Dipole Array
LOCAL Beta, ThetaRadians, Alpha, Rev, Imv AS EXT
LOCAL N%, i%
LOCAL NumSegs$, FeedSeg$, Radius$, ThetaDeg$, Lyne$, GainDB$, Xcoord$, Ycoord$, WireNum$, ReEX$, ImEX$
Beta = R(p%,1,j&)
ThetaRadians = R(p%,2,j&)
ThetaDeg$ = REMOVE$(STR$(ROUND(ThetaRadians*Rad2Deg,2)),ANY" ")

```



```

PRINT #N%, "CM R(p,1,j)="+STR$(R(p%,1,j&))+", R(p,2,j)="+STR$(R(p%,2,j&))
PRINT #N%, "CE"

PRINT #N%, "GW 1,5,0,0,-"+FeedZcoord$+",0,0,-"+FeedZcoord$+",0.00001" 'feed wire, 1 segment, 0.01 wvln
PRINT #N%, "GW 2,"+NumSegs$+",0,0,-"+FeedZcoord$+", "+Xcoord$+",0,-"+Zcoord$+",0.00001" 'upper arm
PRINT #N%, "GW 3,"+NumSegs$+",0,0,-"+FeedZcoord$+", "+Xcoord$+",0,-"+Zcoord$+",0.00001" 'lower arm
PRINT #N%, "GE"
PRINT #N%, "EX 0,1,3,0,1,0." 'VOLTAGE SOURCE

PRINT #N%, "FR 0,1,0,0,299.79564,0."
PRINT #N%, "RP 0,1,1,1001,90,0,0,0,0,1000." 'ENDFIRE gain at 1000 wavelengths range
PRINT #N%, "XQ"
PRINT #N%, "EN"

CLOSE #N%

'
' - - ANGLES - - - - POWER GAINS - - - - POLARIZATION - - - - E(THETA) - - - - E(PHI) - - -
' THETA PHI VERT. HOR. TOTAL AXIAL TILT SENSE MAGNITUDE PHASE MAGNITUDE PHASE
' DEGREES DEGREES DB DB DB RATIO DEG. DEGREE VOLTS/M DEGREES VOLTS/M DEGREES
' 90.00 0.00 3.91 -999.99 3.91 0.00000 0.00 LINEAR 1.29504E-04 5.37 0.00000E+00 -5.24
' 123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x
' 10 20 30 40 50 60 70 80 90 100 110 120

SHELL "n4l_2k1.exe",0
N% = FREEFILE
OPEN "PBM4.OUT" FOR INPUT AS #N%
WHILE NOT EOF(N%)
LINE INPUT #N%, Lyne$
IF INSTR(Lyne$, "DEGREES DEGREES") > 0 THEN EXIT LOOP
WEND 'position at next data line
LINE INPUT #N%, Lyne$
CLOSE #N%

GainDB$ = REMOVE$(MID$(Lyne$,37,8),ANY" ")
PBM_4 = 10^(VAL(GainDB$)/10##) 'directivity
END FUNCTION 'PBM_4()

'-----
FUNCTION PBM5(R(),Nd%,p%,j&) 'PBM Benchmark #5: N-element collinear array (Nd=N-1)
LOCAL TotalLengthWaves, Di(), Ystart, Y1, Y2, SumDi AS EXT
LOCAL N%, i%, q%
LOCAL Lyne$, GainDB$
REDIM Di(1 TO Nd%)
FOR i% = 1 TO Nd%
Di(i%) = R(p%,i%,j&) 'dipole separation, wavelengths
NEXT i%
TotalLengthWaves = 0##
FOR i% = 1 TO Nd%
TotalLengthWaves = TotalLengthWaves + Di(i%)
NEXT i%
TotalLengthWaves = TotalLengthWaves + 0.5## 'add half-wavelength of 1 meter at 299.8 MHz
Ystart = -TotalLengthWaves/2##
N% = FREEFILE
OPEN "PBM5.NEC" FOR OUTPUT AS #N%
PRINT #N%, "CM File: PBM5.NEC"
PRINT #N%, "CM Run_ID "+DATE$+" "+TIME$
PRINT #N%, "CM Nd="+STR$(Nd%)+", p="+STR$(p%)+", j="+STR$(j&)
PRINT #N%, "CM R(p,1,j)="+STR$(R(p%,1,j&))+", R(p,2,j)="+STR$(R(p%,2,j&))
PRINT #N%, "CE"

FOR i% = 1 TO Nd%+1
SumDi = 0##
FOR q% = 1 TO i%-1
SumDi = SumDi + Di(q%)
NEXT q%
Y1 = ROUND(Ystart + SumDi,6)
Y2 = ROUND(Y1+0.5##,6) 'add one-half wavelength for other end of dipole
PRINT #N%, "GW "+REMOVE$(STR$(i%),ANY" ")+" ,49,0,-"+REMOVE$(STR$(Y1),ANY" ")+" ,0,0,-"+REMOVE$(STR$(Y2),ANY" ")+" ,0,0.00001"
NEXT i%
PRINT #N%, "GE"
FOR i% = 1 TO Nd%+1
PRINT #N%, "EX 0, "+REMOVE$(STR$(i%),ANY" ")+" ,25,0,1,0." 'VOLTAGE SOURCES
NEXT i%

PRINT #N%, "FR 0,1,0,0,299.79564,0."
PRINT #N%, "RP 0,1,1,1001,90,0,0,0,0,1000." 'gain at 1000 wavelengths range
PRINT #N%, "XQ"
PRINT #N%, "EN"

CLOSE #N%

'
' - - ANGLES - - - - POWER GAINS - - - - POLARIZATION - - - - E(THETA) - - - - E(PHI) - - -
' THETA PHI VERT. HOR. TOTAL AXIAL TILT SENSE MAGNITUDE PHASE MAGNITUDE PHASE
' DEGREES DEGREES DB DB DB RATIO DEG. DEGREE VOLTS/M DEGREES VOLTS/M DEGREES
' 90.00 0.00 3.91 -999.99 3.91 0.00000 0.00 LINEAR 1.29504E-04 5.37 0.00000E+00 -5.24
' 123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x
' 10 20 30 40 50 60 70 80 90 100 110 120

```

```

SHELL "n41_2k1.exe",0
N% = FREEFILE
OPEN "PBM5.OUT" FOR INPUT AS #N%
  WHILE NOT EOF(N%)
    LINE INPUT #N%, Lyne$
    IF INSTR(Lyne$,"DEGREES DEGREES") > 0 THEN EXIT LOOP
  WEND 'position at next data line
  LINE INPUT #N%, Lyne$
CLOSE #N%
GainDB$ = REMOVE$(MID$(Lyne$,37,8),ANY" ")
PBM_5 = 10^(VAL(GainDB$)/10##) 'Directivity
END FUNCTION 'PBM_5()
'-----
FUNCTION BOWTIE(R(),Nd%,p%,j&) 'FREE SPACE BOWTIE
LOCAL N%, i%, Nsegs%, NumFreq%, ElemNum%, NumRadPattAngles%, ExcitedSegment%
LOCAL Lyne$, FR1$, FileStatus$, FileID$
LOCAL A, B, C AS EXT 'coefficients for Bowtie Fitness function
LOCAL a_meters, SegLength, x1, x2, y1, y2, z1, z2 AS EXT
LOCAL Zo, FrequencyMHZ(), RadEfficiencyPCT(), MaxGainDBI(), MinGainDBI(), Rinohms(), Xinohms(), VSWR(), ForwardGainDBI() AS EXT
LOCAL Fitness, MinimumRadiationEfficiency, MaximumRadiationEfficiency, MinimumMaxGain, MaximumMaxGain, MinVSWR, MaxVSWR, MinRin, MaxRin, MinXin,
MaxXin, MaxFwdGain, MinFwdGain AS EXT
LOCAL StartFreqMHZ!, StopFreqMHZ!, FreqStepMHZ!
LOCAL ArmLengthMeters, AngleRadians, LoadResistance1ohms, LoadResistance2ohms AS EXT
LOCAL LoadedSegNum1%, LoadedSegNum2%
REDIM FrequencyMHZ(1 TO 1), RadEfficiencyPCT(1 TO 1), MaxGainDBI(1 TO 1), MinGainDBI(1 TO 1), Rinohms(1 TO 1), Xinohms(1 TO 1), VSWR(1 TO 1),
ForwardGainDBI(1 TO 1)
'DECISION SPACE BOUNDARY ARRAY:
'DECISION SPACE BOUNDARY ARRAY:
'-----
' Array Element #          Design Variable
'-----
' 1          Bowtie arm length (meters)
' 2          Bowtie HALF angle (degrees)
' 3          Loading segment number #1
' 4          Loading resistance #1 (ohms)
' 5          Zo
'-----
' IMPORTANT NOTE: SEGMENTATION IS FIXED AT 9 !!!! BE SURE Nsegs% = 9 BELOW, OR CHANGE IT HERE AND IN SUB GetFunctionRunParameters().
'-----
Nsegs% = 9
ArmLengthMeters = ROUND(R(p%,1,j&),3)
AngleRadians = ROUND(R(p%,2,j&)*Deg2Rad,3) 'remember, this is the HALF angle
LoadedSegNum1% = MAX(INT(R(p%,3,j&)),1)
LoadResistance1ohms = ROUND(R(p%,4,j&),2)
Zo = ROUND(R(p%,5,j&),1)
a_meters = 0.0005## 'meters
Zo = 300## 'feed system characteristic impedance, OHMS, for computing VSWR
NumRadPattAngles% = 19
IF BowtieSegmentLength$ = "FIXED" THEN SegLength = BowtieSegmentLengthwvlIn 'wavelengths, FIXED [SEE HEADER NOTE ON SEGMENTATION]
StartFreqMHZ! = 800! : StopFreqMHZ! = 12000! : FreqStepMHZ! = 100! : NumFreq% = 1 + (StopFreqMHZ!-StartFreqMHZ!)/FreqStepMHZ!
FR1$ = "FR 0,"+INT2STRING$(NumFreq%)+",0,0,"+FP2STRING2$(StartFreqMHZ!)+","FP2STRING2$(FreqStepMHZ!)
PROCESS SET PRIORITY %NORMAL_PRIORITY_CLASS 'NORMAL PRIORITY TO AVOID PROBLEMS WRITING/READING NEC FILES
PROCESS SET PRIORITY %REALTIME_PRIORITY_CLASS 'PREEMPTS ALL OTHER PROCESSES -> CAN CAUSE PROBLEMS...
N% = FREEFILE
OPEN "BOWTIE.NEC" FOR OUTPUT AS #N%
FileID$ = REMOVE$(DATE$+TIME$,ANY Alphabet$+" -:/")
PRINT #N%,"CM File: BOWTIE.NEC"
PRINT #N%,"CM R-LOADED BOWTIE IN FREE SPACE WITH"
PRINT #N%,"CM Zo AS AN OPTIMIZATION PARAMETER."
PRINT #N%,"CM Antenna in Y-Z plane."
PRINT #N%,"CM Run ID: "+RUNID$
PRINT #N%,"CM Fitness function:
PRINT #N%,"CM [Min(EFF)+5*Min(Gmax)]/[|Zo-MaxRin|*(MaxVSWR-MinVSWR)*(MaxXin-MinXin)]
PRINT #N%,"CM Arm Length = "+REMOVE$(STR$(ArmLengthMeters),ANY" ")+" meters"
PRINT #N%,"CM Bowtie HALF Angle = "+REMOVE$(STR$(ROUND(R(p%,2,j&),2)),ANY" ")+" degrees"
PRINT #N%,"CM Zo = "+REMOVE$(STR$(Zo),ANY" ")+" ohms"
PRINT #N%,"CM Rload = "+REMOVE$(STR$(ROUND(LoadResistance1ohms,2)),ANY" ")+" ohms"
PRINT #N%,"CM Loaded Seg # = "+REMOVE$(STR$(LoadedSegNum1%),ANY" ")+" / "+REMOVE$(STR$(Nsegs%),ANY" ")
PRINT #N%,"CM File ID "+FileID$
PRINT #N%,"CM Nd = "+STR$(Nd%)+", p = "+STR$(p%)+", j = "+STR$(j&)
PRINT #N%,"CM CE"
x1 = 0## : x2 = x1 : y1 = -0.01## : y2 = -y1 : z1 = 0## : z2 = z1 'feed wire coords (wvlIn)
PRINT #N%,"Gw1,3"+FP2STRING$(x1)+","FP2STRING$(y1)+","FP2STRING$(z1)+","FP2STRING$(x2)+","FP2STRING$(y2)+","FP2STRING$(z2)+","FP2STRING$(a_meters) 'feed wire, 3 segs
y1 = 0.01## : y2 = ROUND(y1+ArmLengthMeters*COS(AngleRadians),3) : z1 = 0## : z2 = ROUND(ArmLengthMeters*SIN(AngleRadians),3) 'upper right arm
PRINT #N%,"Gw2,"+INT2STRING$(Nsegs%)+","FP2STRING$(x1)+","FP2STRING$(y1)+","FP2STRING$(z1)+","FP2STRING$(x2)+","FP2STRING$(y2)+","FP2STRING$(z2)+","FP2STRING$(a_meters) 'feed wire, 3 segs
y1 = 0.01## : y2 = ROUND(y1+ArmLengthMeters*COS(AngleRadians),3) : z1 = 0## : z2 = -ROUND(ArmLengthMeters*SIN(AngleRadians),3) 'lower right arm
PRINT #N%,"Gw3,"+INT2STRING$(Nsegs%)+","FP2STRING$(x1)+","FP2STRING$(y1)+","FP2STRING$(z1)+","FP2STRING$(x2)+","FP2STRING$(y2)+","FP2STRING$(z2)+","FP2STRING$(a_meters) 'feed wire, 3 segs
y1 = ROUND(0.01##+ArmLengthMeters*COS(AngleRadians),3) : y2 = y1 : z1 = ROUND(ArmLengthMeters*SIN(AngleRadians),3) : z2 = -z1 'right arm vertical connecting wire

```

```

PRINT
#N%, "GW4, "+Int2String$(Nsegs%)+", "+FP2String$(x1)+", "+FP2String$(y1)+", "+FP2String$(z1)+", "+FP2String$(x2)+", "+FP2String$(y2)+", "+FP2String$(z2)+", "+FP2String$(a_meters) 'feed wire, 3 segs
    y1 = -0.01## : y2 = ROUND(y1-ArmLengthMeters*COS(AngleRadians),3) : z1 = 0## : z2 = ROUND(ArmLengthMeters*SIN(AngleRadians),3) 'upper left arm
PRINT
#N%, "GW5, "+Int2String$(Nsegs%)+", "+FP2String$(x1)+", "+FP2String$(y1)+", "+FP2String$(z1)+", "+FP2String$(x2)+", "+FP2String$(y2)+", "+FP2String$(z2)+", "+FP2String$(a_meters) 'feed wire, 3 segs
    y1 = -0.01## : y2 = ROUND(y1-ArmLengthMeters*COS(AngleRadians),3) : z1 = 0## : z2 = -ROUND(ArmLengthMeters*SIN(AngleRadians),3) 'lower left arm
PRINT
#N%, "GW6, "+Int2String$(Nsegs%)+", "+FP2String$(x1)+", "+FP2String$(y1)+", "+FP2String$(z1)+", "+FP2String$(x2)+", "+FP2String$(y2)+", "+FP2String$(z2)+", "+FP2String$(a_meters) 'feed wire, 3 segs
    y1 = -ROUND(0.01##+ArmLengthMeters*COS(AngleRadians),3) : y2 = y1 : z1 = ROUND(ArmLengthMeters*SIN(AngleRadians),3) : z2 = -z1 'left arm vertical
connecting wire
PRINT
#N%, "GW7, "+Int2String$(Nsegs%)+", "+FP2String$(x1)+", "+FP2String$(y1)+", "+FP2String$(z1)+", "+FP2String$(x2)+", "+FP2String$(y2)+", "+FP2String$(z2)+", "+FP2String$(a_meters) 'feed wire, 3 segs
    PRINT #N%, "GE"
'
----- LOAD RESISTOR #1 -----
IF LoadResistance10ohms < 0## THEN 'load bowtie only if loading resistance is not zero
PRINT #N%, "LD0,2, "+Int2String$(LoadedSegNum1%)+", "+Int2String$(LoadedSegNum1%)+", "+FP2String2$(ROUND(LoadResistance10ohms,2))+", 0.0." 'load upper right arm
PRINT #N%, "LD0,3, "+Int2String$(LoadedSegNum1%)+", "+Int2String$(LoadedSegNum1%)+", "+FP2String2$(ROUND(LoadResistance10ohms,2))+", 0.0." 'load upper left arm
PRINT #N%, "LD0,5, "+Int2String$(LoadedSegNum1%)+", "+Int2String$(LoadedSegNum1%)+", "+FP2String2$(ROUND(LoadResistance10ohms,2))+", 0.0." 'load lower right arm
PRINT #N%, "LD0,6, "+Int2String$(LoadedSegNum1%)+", "+Int2String$(LoadedSegNum1%)+", "+FP2String2$(ROUND(LoadResistance10ohms,2))+", 0.0." 'load lower left arm
END IF
'
----- LOAD RESISTOR #2 -----
IF LoadResistance20ohms < 0## THEN 'load bowtie only if loading resistance is not zero
PRINT #N%, "LD0,2, "+Int2String$(LoadedSegNum2%)+", "+Int2String$(LoadedSegNum2%)+", "+FP2String2$(ROUND(LoadResistance20ohms,2))+", 0.0." 'load upper right arm
PRINT #N%, "LD0,3, "+Int2String$(LoadedSegNum2%)+", "+Int2String$(LoadedSegNum2%)+", "+FP2String2$(ROUND(LoadResistance20ohms,2))+", 0.0." 'load upper left arm
PRINT #N%, "LD0,5, "+Int2String$(LoadedSegNum2%)+", "+Int2String$(LoadedSegNum2%)+", "+FP2String2$(ROUND(LoadResistance20ohms,2))+", 0.0." 'load lower right arm
PRINT #N%, "LD0,6, "+Int2String$(LoadedSegNum2%)+", "+Int2String$(LoadedSegNum2%)+", "+FP2String2$(ROUND(LoadResistance20ohms,2))+", 0.0." 'load lower left arm
'END IF
PRINT #N%, FR1$ ' frequency card
PRINT #N%, "EX 0,1,2,1,1,0." 'excite center segment in DRIVEN ELEMENT #2 with 1+j0 volts
PRINT #N%, "RP 0, "+Int2String$(NumRadPatAngles%)-1,1001,0.0, "+FP2String2$(ROUND(90##/(NumRadPatAngles%-1),2))+", 0,100000." 'vertical radiation pattern at Phi=0 (+x-axis)
PRINT #N%, "EN"
CLOSE #N%
'
SHELL "NEC2D_200_02-22-2011.EXE",0
SHELL "NEC4ID_4K_053011.EXE",0
CALL
GetNECdata("BOWTIE_OUT", NumFreqs$, NumRadPatAngles$, Zo, FrequencyMHz(), RadEfficiencyPCT(), MaxGainDBI(), MinGainDBI(), RinOhms(), XinOhms(), VSWR(), ForwardGainDbi(), FileStatus$, FileID$)
Fitness = -98765## 'default value
IF FileStatus$ = "OK" THEN
MinimumRadiationEfficiency = RadEfficiencyPCT(1) : MinimumMaxGain = MaxGainDBI(1) : MinVSWR = VSWR(1) : MaxVSWR = VSWR(1)
MinRin = RinOhms(1) : MaxRin = RinOhms(1) : MinXin = XinOhms(1) : MaxXin = XinOhms(1)
MinFwdGain = ForwardGainDbi(1) : MaxFwdGain = ForwardGainDbi(1)
FOR i% = 1 TO NumFreqs$
IF RadEfficiencyPCT(i%) <= MinimumRadiationEfficiency THEN MinimumRadiationEfficiency = RadEfficiencyPCT(i%)
IF MinimumRadiationEfficiency < 0## THEN EXIT FOR 'bad run -> use default fitness & exit
IF RadEfficiencyPCT(i%) >= MaximumRadiationEfficiency THEN MaximumRadiationEfficiency = RadEfficiencyPCT(i%)
IF MaxGainDBI(i%) <= MinimumMaxGain THEN MinimumMaxGain = MaxGainDBI(i%)
IF MaxGainDBI(i%) >= MaximumMaxGain THEN MaximumMaxGain = MaxGainDBI(i%)
IF VSWR(i%) <= MinVSWR THEN MinVSWR = VSWR(i%)
IF VSWR(i%) >= MaxVSWR THEN MaxVSWR = VSWR(i%)
IF RinOhms(i%) <= MinRin THEN MinRin = RinOhms(i%)
IF RinOhms(i%) >= MaxRin THEN MaxRin = RinOhms(i%)
IF XinOhms(i%) <= MinXin THEN MinXin = XinOhms(i%)
IF XinOhms(i%) >= MaxXin THEN MaxXin = XinOhms(i%)
IF ForwardGainDbi(i%) >= MaxFwdGain THEN MaxFwdGain = ForwardGainDbi(i%)
IF ForwardGainDbi(i%) <= MinFwdGain THEN MinFwdGain = ForwardGainDbi(i%)
NEXT i%
'
A = BowtieFitnessCoefficients(1) : B = BowtieFitnessCoefficients(2) : C = BowtieFitnessCoefficients(3) 'use this notation for consistency
'NOTE: Forward gain is in direction on +x-axis.
Fitness = (A*ForwardGainDbi-B*ABS(Zo-MaxRin)-C*(MAX(ABS(MaxXin),ABS(MinXin))))/(A+B+C) 'NOTE: THIS IS ONE OF AN INFINITY OF FITNESS FUNCTIONS.
'CHANGING THE FUNCTION CHANGES THE DECISION SPACE LANDSCAPE
'RESULTING IN COMPLETELY DIFFERENT ANTENNA DESIGNS.
IF MinimumRadiationEfficiency >= 0## THEN Fitness = (MinimumRadiationEfficiency+5##*MinimumMaxGain)/(ABS(Zo-MaxRin)*(MaxVSWR-MinVSWR)*(MaxXin-MinXin)) 'compute only if run is OK and min eff >= 0
END IF
N% = FREEFILE
OPEN "BOWTIE_NEC" FOR APPEND AS #N%
PRINT #N%, ""
PRINT #N%, "CM R-LOADED BOWTIE IN FREE SPACE WITH"
PRINT #N%, "CM Zo AS AN OPTIMIZATION PARAMETER."
PRINT #N%, "Run ID: "+RunID$
PRINT #N%, USING$( "Fitness" = ##"#####", Fitness)
PRINT #N%, "Fwd Gain (dbi) Min/Max" = "+STR$(MinFwdGain)"/"+STR$(MaxFwdGain)
PRINT #N%, "VSWR Min/Max" = "+STR$(ROUND(MinVSWR,2))+"/"+STR$(ROUND(MaxVSWR,2))+"/"+REMOVE$(STR$(Zo), ANY" ")
PRINT #N%, "Rin Min/Max" = "+STR$(ROUND(MinRin,2))+"/"+STR$(ROUND(MaxRin,2))
PRINT #N%, "Xin Min/Max" = "+STR$(ROUND(MinXin,2))+"/"+STR$(ROUND(MaxXin,2))
PRINT #N%, "Gmax(db) Min/Max" = "+STR$(ROUND(MinimumMaxGain,2))+"/"+STR$(ROUND(MaximumMaxGain,2))
PRINT #N%, "Eff(%) Min/Max" = "+STR$(ROUND(MinimumRadiationEfficiency,2))+"/"+STR$(ROUND(MaximumRadiationEfficiency,2))
PRINT #N%, ""
CLOSE #N%
N% = FREEFILE
OPEN "BOWTIE_OUT" FOR APPEND AS #N%
PRINT #N%, ""
PRINT #N%, "CM R-LOADED BOWTIE IN FREE SPACE WITH"
PRINT #N%, "CM Zo AS AN OPTIMIZATION PARAMETER."
PRINT #N%, "Run ID: "+RunID$
PRINT #N%, USING$( "Fitness" = ##"#####", Fitness)
PRINT #N%, "Fwd Gain (dbi) Min/Max" = "+STR$(MinFwdGain)"/"+STR$(MaxFwdGain)
PRINT #N%, "VSWR Min/Max" = "+STR$(ROUND(MinVSWR,2))+"/"+STR$(ROUND(MaxVSWR,2))+"/"+REMOVE$(STR$(Zo), ANY" ")

```





```

PROCESS SET PRIORITY %REALTIME_PRIORITY_CLASS 'PREEMPTS ALL OTHER PROCESSES -> CAN CAUSE PROBLEMS...
N% = FREEFILE
OPEN "YAGI.NEC" FOR OUTPUT AS #N%
FileID$ = REMOVE$(DATE$+TIME$,ANY Alphabet$+"-:/")
PRINT #N%,"CM File: YAGI.NEC"
PRINT #N%,"CM YAGI ARRAY IN FREE SPACE"
PRINT #N%,"CM Band center frequency, Fc = 299.8 MHz"
PRINT #N%,"CM Run ID: "+RunID$
PRINT #N%,"CM Fitness function:
PRINT #N%,"CM Gfwd(L)/5-2*VSWR(L)+Gfwd(M)-4*VSWR(M)+Gfwd(U)-2*VSWR(U)/5"
PRINT #N%,"CM where L,M,U are lower/mid/upper frequencies"
PRINT #N%,"CM MaxGfwd/[|Zo-MaxRin|^2*(MaxVSWR-MinVSWR)^2*(MaxXin-MinXin)]
PRINT #N%,"CM (A*MaxFwdGain-B*|Zo-MaxRin|-C*(MAX(|MaxXin|,|MinXin|)))
PRINT #N%,"CM -D*(MaxVSWR-MinVSWR)/(A+B+C+D)"
PRINT #N%,"CM where "+YagiCoefficients$
PRINT #N%,"CM Zo="+REMOVE$(STR$(Zo),ANY" ")+" ohms"
PRINT #N%,"CM File ID "+FileID$
PRINT #N%,"CM Nd="+STR$(Nd%)+", p="+STR$(p%)+", j="+STR$(j&)
PRINT #N%,"CE"

FOR ElemNum% = 1 TO NumYagiElements%
  BoomDistance = 0##
  FOR i% = 1 TO ElemNum% 'add up element spacings to get position along boom
    Spacing = ROUND(R(p%,i%,j&),3) 'element spacing from previous element, WAVELENGTHS (note Reflector spacing = 0 always)
    BoomDistance = BoomDistance + Spacing
  NEXT i%
  Length = R(p%,ElemNum%+NumYagiElements%,j&) 'element length, WAVELENGTHS
  Nsegs% = 9 'use same # segs each element unless seg LENGTH is FIXED, in which case use a different # segs in each element as follows
  IF YagiSegmentLength$ = "FIXED" THEN 'adjust # segments in each element and change element length to be an integer # of segments
    Nsegs% = INT(Length/SegLength)
    Nsegs% = 2*(Nsegs%/2)+1 'must be odd # to preserve symmetry about excitation at center
    Length = Nsegs%*SegLength 'round element length to an integer multiple of segment length to guaranty segment alignment as recommended in
NEC Manual
  END IF
  IF ElemNum% = 2 THEN ExcitedSegment% = Nsegs%\2+1
  x1 = ROUND(BoomDistance,3) : x2 = x1 'Yagi elements are parallel to Y-axis arrayed along +X-axis. Round spacings & length to nearest 0.001
  wavelength.
  y1 = ROUND(-Length/2##,3) : y2 = -y1
  PRINT
  #N%,"GW"+Int2String$(ElemNum%)+", "+Int2String$(Nsegs%)+", "+FP2String$(x1)+", "+FP2String$(y1)+",0., "+FP2String$(x2)+", "+FP2String$(y2)+",0., "+FP2String$(a_wv
  ln)
  NEXT ElemNum%
  PRINT #N%,"GE"
  PRINT #N%, FRI$ ' frequency card
  PRINT #N%, "EX 0,2,"+Int2String$(ExcitedSegment%)+",1,1,0." 'excite center segment in DRIVEN ELEMENT #2 with 1+j0 volts
  PRINT #N%, "RP 0,"+Int2String$(NumRadPatAngles%)+",1,1001,0,0,0,"+FP2String2$(ROUND(90##/(NumRadPatAngles%-1,2))+",0,100000." 'vertical
  radiation pattern at Phi=0 (+X-axis)
  PRINT #N%, "EN"
CLOSE #N%
SHELL "NEC2D_200_02-22-2011.EXE",0
SHELL "NEC41D_4K_053011.EXE",0
CALL
GetNECdata(NumFreqs%,NumRadPatAngles%,Zo, FrequencyMHZ(),RadEfficiencyPCT(),MaxGainDBI(),MinGainDBI(),RinOhms(),XinOhms(),VSWR(),ForwardGainDbi,FileStatus$
,FileID$)
CALL
GetNECdata("YAGI.OUT",NumFreqs%,NumRadPatAngles%,Zo, FrequencyMHZ(),RadEfficiencyPCT(),MaxGainDBI(),MinGainDBI(),RinOhms(),XinOhms(),VSWR(),ForwardGainDbi(
),FileStatus$,FileID$)
Fitness = -98765## 'default value
IF FileStatus$ = "OK" THEN
  MinimumRadiationEfficiency = RadEfficiencyPCT(1) : MinimumMaxGain = MaxGainDBI(1) : MinVSWR = VSWR(1) : MaxVSWR = VSWR(1)
  MinRin = RinOhms(1) : MaxRin = RinOhms(1) : MinXin = XinOhms(1) : MaxXin = XinOhms(1)
  MinFwdGain = ForwardGainDbi(1) : MaxFwdGain = ForwardGainDbi(1)
  FOR i% = 1 TO NumFreqs%
    IF RadEfficiencyPCT(i%) <= MinimumRadiationEfficiency THEN MinimumRadiationEfficiency = RadEfficiencyPCT(i%)
    IF RadEfficiencyPCT(i%) >= MaximumRadiationEfficiency THEN MaximumRadiationEfficiency = RadEfficiencyPCT(i%)
    IF MaxGainDBI(i%) <= MinimumMaxGain THEN MinimumMaxGain = MaxGainDBI(i%)
    IF MaxGainDBI(i%) >= MaximumMaxGain THEN MaximumMaxGain = MaxGainDBI(i%)
    IF VSWR(i%) <= MinVSWR THEN MinVSWR = VSWR(i%)
    IF VSWR(i%) >= MaxVSWR THEN MaxVSWR = VSWR(i%)
    IF RinOhms(i%) <= MinRin THEN MinRin = RinOhms(i%)
    IF RinOhms(i%) >= MaxRin THEN MaxRin = RinOhms(i%)
    IF XinOhms(i%) <= MinXin THEN MinXin = XinOhms(i%)
    IF XinOhms(i%) >= MaxXin THEN MaxXin = XinOhms(i%)
    IF ForwardGainDbi(i%) >= MaxFwdGain THEN MaxFwdGain = ForwardGainDbi(i%)
    IF ForwardGainDbi(i%) <= MinFwdGain THEN MinFwdGain = ForwardGainDbi(i%)
  NEXT i%
  A = YagiFitnessCoefficients(1) : B = YagiFitnessCoefficients(2) : C = YagiFitnessCoefficients(3) : D = YagiFitnessCoefficients(4) 'use this
  notation for consistency
  Fitness = (A*MaxFwdGain-B*ABS(Zo-MaxRin)-C*(MAX(ABS(MaxXin),ABS(MinXin)))-D*(MaxVSWR-MinVSWR))/(A+B+C+D) 'Yagi radiation efficiency = 100%
  because it isn't loaded.
  NOTE: THIS IS ONE OF AN INFINITY OF FITNESS FUNCTIONS. CHANGING THE FUNCTION CHANGES THE DECISION SPACE LANDSCAPE RESULTING IN COMPLETELY
  DIFFERENT ANTENNA DESIGNS.
  Fitness = MaxFwdGain/(ABS(Zo-MaxRin)*(MaxVSWR-MinVSWR)*(MaxXin-MinXin)) 'compute only if run is OK
  Fitness = ForwardGainDbi(1)/5##-2##*VSWR(1)+ForwardGainDbi(NumFreqs%\2+1)-4##*VSWR(NumFreqs%\2+1)+ForwardGainDbi(NumFreqs%)-2##*VSWR(NumFreqs%)/5##
END IF
N% = FREEFILE
OPEN "YAGI.NEC" FOR APPEND AS #N%
PRINT #N%,""
PRINT #N%,"YAGI ARRAY IN FREE SPACE"
PRINT #N%,"CM Band center frequency, Fc = 299.8 MHz"
PRINT #N%,"Run ID: "+RunID$
PRINT #N%,"USING$ ("Fitness =#.######",Fitness)
PRINT #N%,"Max Fwd Gain (dbi)="+STR$(MaxFwdGain)

```



```

PRINT #N%, "VSWR Min/Max      ="+STR$(ROUND(MinVSWR, 2))+"/"+STR$(ROUND(MaxVSWR, 2))+"/"+REMOVE$(STR$(Zo), ANY" ")
PRINT #N%, "Rin Min/Max      ="+STR$(ROUND(MinRin, 2))+"/"+STR$(ROUND(MaxRin, 2))
PRINT #N%, "Xin Min/Max      ="+STR$(ROUND(MinXin, 2))+"/"+STR$(ROUND(MaxXin, 2))
PRINT #N%, "Gmax(dBi) Min/Max ="+STR$(ROUND(MinimumMaxGain, 2))+"/"+STR$(ROUND(MaximumMaxGain, 2))
PRINT #N%, "Eff(%) Min/Max    ="+STR$(ROUND(MinimumRadiationEfficiency, 2))+"/"+STR$(ROUND(MaximumRadiationEfficiency, 2))
PRINT #N%, ""
CLOSE #N%

N% = FREEFILE
OPEN "YAGI.OUT" FOR APPEND AS #N%
PRINT #N%, ""
PRINT #N%, "YAGI ARRAY IN FREE SPACE"
PRINT #N%, "CM Band center frequency, Fc = 299.8 MHz"
PRINT #N%, "Run ID: "+RunID$
PRINT #N%, "USINGS ("Fitness      =# #####" , Fitness)
PRINT #N%, "Max Fwd Gain (dBi)      ="+STR$(MaxFwdGain)
PRINT #N%, "VSWR Min/Max              ="+STR$(ROUND(MinVSWR, 2))+"/"+STR$(ROUND(MaxVSWR, 2))+"/"+REMOVE$(STR$(Zo), ANY" ")
PRINT #N%, "Rin Min/Max                  ="+STR$(ROUND(MinRin, 2))+"/"+STR$(ROUND(MaxRin, 2))
PRINT #N%, "Xin Min/Max                  ="+STR$(ROUND(MinXin, 2))+"/"+STR$(ROUND(MaxXin, 2))
PRINT #N%, "Gmax(dBi) Min/Max          ="+STR$(ROUND(MinimumMaxGain, 2))+"/"+STR$(ROUND(MaximumMaxGain, 2))
PRINT #N%, "Eff(%) Min/Max              ="+STR$(ROUND(MinimumRadiationEfficiency, 2))+"/"+STR$(ROUND(MaximumRadiationEfficiency, 2))
PRINT #N%, ""
CLOSE #N%

'
'  - - ANGLES - -      - POWER GAINS -      - - - POLARIZATION - - -      - - - E(THETA) - - -      - - - E(PHI) - - -
' THETA  PHI  VERT.  HOR.  TOTAL  AXIAL  TILT  SENSE  MAGNITUDE  PHASE  MAGNITUDE  PHASE
' DEGREES DEGREES DB  DB  DB  RATIO  DEG.  DEGREE  VOLTS/M  DEGREE  VOLTS/M  DEGREE
' 90.00  0.00  3.91 -999.99  3.91  0.00000  0.00  LINEAR  1.29504E-04  5.37  0.00000E+00  -5.24
' 123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x123456789x
' 10 20 30 40 50 60 70 80 90 100 110 120

YAGI_ARRAY = Fitness
END FUNCTION 'YAGI_ARRAY()'
'-----
***** END PROGRAM 'CF0_R_ONLY_LOADED_BOWTIE_YAGI_07-10-2011.BAS' *****

```

# Appendix II

CM File: BESTBOWTIE.NEC  
 CM R-LOADED BOWTIE IN FREE SPACE WITH  
 CM Zo AS AN OPTIMIZATION PARAMETER.  
 CM Antenna in Y-Z plane.  
 CM Run ID: 07022011\_221747  
 CM Fitness function:  
 CM  $[Min(Eff)+5*Min(Gmax)]/[|Zo-MaxRin|*(MaxVSWR-MinVSWR)*(MaxXin-MinXin)]$   
 CM Arm Length = .051 meters  
 CM Bowtie HALF Angle = 39.4 degrees  
 CM Zo = 715 ohms  
 CM Rload = 166.93 ohms  
 CM Loaded Seg # = 6/9  
 CM File ID 07032011225840  
 CM Nd = 5, p = 1, j = 35  
 R-LOADED BOWTIE ANTENNA IN FREE SPACE: SUMMARY NEC DATA

F(MHz)	Rad Eff (%)	Max Gain (dBi)	Min Gain (dBi)	Fwd Gain (dBi)	Rin (ohms)	Xin (ohms)	VSWR//715
200.00	0.000	-13.22	-13.23	-13.22	52.28	-808.22	31.19
215.00	0.000	-12.62	-12.64	-12.62	52.79	-745.39	28.30
230.00	0.000	-12.07	-12.08	-12.07	53.33	-690.31	25.94
245.00	0.000	-11.55	-11.57	-11.55	53.92	-641.56	23.97
260.00	0.000	-11.07	-11.09	-11.07	54.54	-598.04	22.31
275.00	0.370	-10.62	-10.65	-10.62	55.20	-558.90	20.89
290.00	0.960	-10.20	-10.23	-10.20	55.91	-523.46	19.67
305.00	1.570	-9.80	-9.83	-9.80	56.66	-491.17	18.60
320.00	2.200	-9.42	-9.46	-9.42	57.45	-461.59	17.66
335.00	2.840	-9.07	-9.11	-9.07	58.28	-434.35	16.82
350.00	3.500	-8.73	-8.78	-8.73	59.16	-409.16	16.06
365.00	4.180	-8.42	-8.46	-8.42	60.08	-385.75	15.38
380.00	4.860	-8.11	-8.17	-8.11	61.05	-363.93	14.76
395.00	5.560	-7.83	-7.88	-7.83	62.06	-343.50	14.20
410.00	6.260	-7.55	-7.61	-7.55	63.13	-324.33	13.67
425.00	6.980	-7.29	-7.36	-7.29	64.24	-306.26	13.19
440.00	7.690	-7.04	-7.12	-7.04	65.40	-289.19	12.73
455.00	8.420	-6.81	-6.88	-6.81	66.61	-273.02	12.31
470.00	9.140	-6.58	-6.66	-6.58	67.88	-257.66	11.91
485.00	9.870	-6.36	-6.45	-6.36	69.19	-243.04	11.54
500.00	10.610	-6.15	-6.25	-6.15	70.57	-229.10	11.18
515.00	11.340	-5.96	-6.06	-5.96	71.99	-215.77	10.84
530.00	12.070	-5.77	-5.87	-5.77	73.47	-203.00	10.52
545.00	12.800	-5.58	-5.69	-5.58	75.02	-190.74	10.22
560.00	13.530	-5.41	-5.53	-5.41	76.62	-178.97	9.92
575.00	14.250	-5.24	-5.36	-5.24	78.28	-167.63	9.64
590.00	14.970	-5.08	-5.21	-5.08	80.00	-156.71	9.37
605.00	15.680	-4.92	-5.06	-4.92	81.79	-146.16	9.11
620.00	16.390	-4.77	-4.92	-4.77	83.64	-135.96	8.86
635.00	17.100	-4.63	-4.78	-4.63	85.56	-126.10	8.62
650.00	17.790	-4.49	-4.65	-4.49	87.54	-116.53	8.39
665.00	18.480	-4.35	-4.52	-4.35	89.60	-107.26	8.16
680.00	19.160	-4.22	-4.40	-4.22	91.73	-98.26	7.94
695.00	19.830	-4.10	-4.29	-4.10	93.93	-89.51	7.73
710.00	20.490	-3.98	-4.18	-3.98	96.20	-81.01	7.53
725.00	21.140	-3.86	-4.07	-3.86	98.55	-72.73	7.33
740.00	21.790	-3.75	-3.97	-3.75	100.98	-64.68	7.14
755.00	22.420	-3.64	-3.87	-3.64	103.49	-56.83	6.95
770.00	23.040	-3.54	-3.77	-3.54	106.08	-49.18	6.77
785.00	23.650	-3.44	-3.68	-3.44	108.76	-41.72	6.60
800.00	24.250	-3.34	-3.59	-3.34	111.51	-34.45	6.43
815.00	24.820	-3.24	-3.51	-3.24	114.34	-27.34	6.26
830.00	25.400	-3.15	-3.43	-3.15	117.27	-20.42	6.10
845.00	25.960	-3.06	-3.35	-3.06	120.29	-13.67	5.95
860.00	26.520	-2.97	-3.28	-2.97	123.40	-7.09	5.79
875.00	27.060	-2.89	-3.20	-2.89	126.60	-0.66	5.65
890.00	27.590	-2.81	-3.13	-2.81	129.90	5.60	5.50
905.00	28.100	-2.73	-3.07	-2.73	133.29	11.71	5.37
920.00	28.610	-2.65	-3.01	-2.65	136.78	17.66	5.23
935.00	29.100	-2.58	-2.94	-2.58	140.37	23.45	5.10
950.00	29.580	-2.51	-2.89	-2.51	144.05	29.09	4.97
965.00	30.050	-2.44	-2.83	-2.44	147.84	34.58	4.85
980.00	30.510	-2.37	-2.78	-2.37	151.72	39.90	4.73
995.00	30.950	-2.30	-2.72	-2.30	155.70	45.08	4.61
1010.00	31.380	-2.24	-2.67	-2.24	159.79	50.09	4.50
1025.00	31.800	-2.18	-2.63	-2.18	163.97	54.94	4.39
1040.00	32.210	-2.12	-2.58	-2.12	168.26	59.62	4.28
1055.00	32.610	-2.06	-2.54	-2.06	172.64	64.14	4.18
1070.00	32.990	-2.00	-2.50	-2.00	177.13	68.49	4.08
1085.00	33.360	-1.94	-2.46	-1.94	181.71	72.67	3.98
1100.00	33.720	-1.89	-2.42	-1.89	186.38	76.66	3.88
1115.00	34.070	-1.84	-2.38	-1.84	191.16	80.48	3.79
1130.00	34.410	-1.78	-2.35	-1.78	196.02	84.10	3.70
1145.00	34.730	-1.73	-2.31	-1.73	200.97	87.54	3.62
1160.00	35.050	-1.68	-2.28	-1.68	206.00	90.77	3.53
1175.00	35.350	-1.63	-2.25	-1.63	211.12	93.81	3.45
1190.00	35.640	-1.59	-2.22	-1.59	216.31	96.63	3.37
1205.00	35.920	-1.54	-2.20	-1.54	221.58	99.24	3.30
1220.00	36.190	-1.50	-2.17	-1.50	226.91	101.63	3.22
1235.00	36.450	-1.45	-2.15	-1.45	232.32	103.80	3.15
1250.00	36.690	-1.41	-2.13	-1.41	237.76	105.73	3.08
1265.00	36.930	-1.37	-2.10	-1.37	243.25	107.43	3.01
1280.00	37.150	-1.33	-2.08	-1.33	248.77	108.88	2.95
1295.00	37.360	-1.29	-2.07	-1.29	254.32	110.09	2.89
1310.00	37.570	-1.25	-2.05	-1.25	259.89	111.04	2.83
1325.00	37.760	-1.21	-2.03	-1.21	265.46	111.74	2.77
1340.00	37.940	-1.17	-2.02	-1.17	271.03	112.18	2.71
1355.00	38.110	-1.13	-2.00	-1.13	276.58	112.35	2.66
1370.00	38.270	-1.10	-1.99	-1.10	282.11	112.26	2.61
1385.00	38.410	-1.06	-1.98	-1.06	287.59	111.89	2.56
1400.00	38.550	-1.03	-1.97	-1.03	293.01	111.26	2.51
1415.00	38.680	-0.99	-1.96	-0.99	298.36	110.35	2.47
1430.00	38.800	-0.96	-1.95	-0.96	303.63	109.18	2.42
1445.00	38.910	-0.93	-1.95	-0.93	308.79	107.73	2.38
1460.00	39.000	-0.90	-1.94	-0.90	313.84	106.02	2.34
1475.00	39.090	-0.86	-1.94	-0.86	318.76	104.04	2.30
1490.00	39.170	-0.83	-1.94	-0.83	323.52	101.81	2.27
1505.00	39.230	-0.80	-1.93	-0.80	328.12	99.32	2.23
1520.00	39.290	-0.77	-1.93	-0.77	332.54	96.59	2.20
1535.00	39.340	-0.75	-1.93	-0.75	336.77	93.63	2.17
1550.00	39.380	-0.72	-1.94	-0.72	340.78	90.44	2.14
1565.00	39.400	-0.69	-1.94	-0.69	344.57	87.03	2.11
1580.00	39.420	-0.66	-1.94	-0.66	348.12	83.42	2.09
1595.00	39.430	-0.64	-1.95	-0.64	351.41	79.62	2.07
1610.00	39.420	-0.61	-1.95	-0.61	354.44	75.65	2.05
1625.00	39.410	-0.59	-1.96	-0.59	357.18	71.52	2.03
1640.00	39.390	-0.56	-1.97	-0.56	359.64	67.26	2.01
1655.00	39.360	-0.54	-1.98	-0.54	361.81	62.86	2.00
1670.00	39.320	-0.52	-1.99	-0.52	363.66	58.37	1.98
1685.00	39.270	-0.49	-2.00	-0.49	365.21	53.79	1.97
1700.00	39.210	-0.47	-2.01	-0.47	366.44	49.14	1.96
1715.00	39.140	-0.45	-2.03	-0.45	367.34	44.45	1.96
1730.00	39.060	-0.43	-2.04	-0.43	367.93	39.73	1.95
1745.00	38.970	-0.41	-2.06	-0.41	368.19	35.01	1.95
1760.00	38.870	-0.39	-2.08	-0.39	368.13	30.31	1.95
1775.00	38.760	-0.37	-2.09	-0.37	367.75	25.64	1.95

1790.00	38.640	-0.36	-2.11	-0.36	367.05	21.02	1.95
1805.00	38.510	-0.34	-2.14	-0.34	366.04	16.49	1.95
1820.00	38.380	-0.32	-2.16	-0.32	364.73	12.04	1.96
1835.00	38.230	-0.31	-2.18	-0.31	363.12	7.71	1.97
1850.00	38.080	-0.29	-2.21	-0.29	361.22	3.51	1.98
1865.00	37.910	-0.28	-2.23	-0.28	359.04	-0.54	1.99
1880.00	37.740	-0.26	-2.26	-0.26	356.60	-4.44	2.01
1895.00	37.560	-0.25	-2.29	-0.25	355.90	-8.16	2.02
1910.00	37.370	-0.24	-2.31	-0.24	350.97	-11.68	2.04
1925.00	37.170	-0.23	-2.34	-0.23	347.80	-15.01	2.06
1940.00	36.960	-0.22	-2.38	-0.22	344.42	-18.13	2.08
1955.00	36.740	-0.21	-2.41	-0.21	340.83	-21.02	2.10
1970.00	36.520	-0.21	-2.44	-0.21	337.06	-23.68	2.12
1985.00	36.290	-0.20	-2.48	-0.20	333.12	-26.11	2.15
2000.00	36.040	-0.20	-2.51	-0.20	329.02	-28.28	2.18
2015.00	35.790	-0.19	-2.55	-0.19	324.75	-30.17	2.21
2030.00	35.530	-0.19	-2.59	-0.19	320.35	-31.80	2.24
2045.00	35.260	-0.19	-2.62	-0.19	315.84	-33.18	2.27
2060.00	34.980	-0.19	-2.66	-0.19	311.24	-34.29	2.30
2075.00	34.700	-0.19	-2.70	-0.19	306.54	-35.14	2.34
2090.00	34.420	-0.20	-2.74	-0.20	301.78	-35.72	2.38
2105.00	34.130	-0.20	-2.78	-0.20	296.97	-36.03	2.42
2120.00	33.830	-0.21	-2.83	-0.21	292.11	-36.08	2.46
2135.00	33.540	-0.22	-2.87	-0.22	287.22	-35.86	2.50
2150.00	33.240	-0.23	-2.91	-0.23	282.31	-35.38	2.54
2165.00	32.950	-0.24	-2.95	-0.24	277.39	-34.64	2.58
2180.00	32.650	-0.26	-2.99	-0.26	272.48	-33.63	2.63
2195.00	32.340	-0.28	-3.03	-0.28	267.58	-32.36	2.68
2210.00	32.070	-0.30	-3.07	-0.30	262.70	-30.84	2.73
2225.00	31.780	-0.33	-3.11	-0.33	257.87	-29.06	2.78
2240.00	31.510	-0.35	-3.15	-0.35	253.07	-27.03	2.83
2255.00	31.240	-0.39	-3.19	-0.39	248.33	-24.75	2.88
2270.00	30.980	-0.42	-3.22	-0.42	243.65	-22.23	2.94
2285.00	30.740	-0.46	-3.25	-0.46	239.04	-19.46	2.99
2300.00	30.520	-0.50	-3.27	-0.50	234.51	-16.45	3.05
2315.00	30.310	-0.55	-3.30	-0.55	230.07	-13.21	3.11
2330.00	30.120	-0.61	-3.31	-0.61	225.72	-9.73	3.17
2345.00	29.970	-0.66	-3.33	-0.66	221.48	-6.02	3.23
2360.00	29.840	-0.73	-3.33	-0.73	217.35	-2.08	3.29
2375.00	29.750	-0.80	-3.33	-0.80	213.33	2.09	3.35
2390.00	29.690	-0.87	-3.32	-0.87	209.44	6.47	3.41
2405.00	29.680	-0.96	-3.31	-0.96	205.68	11.08	3.48
2420.00	29.720	-1.05	-3.29	-1.05	202.07	15.91	3.54
2435.00	29.810	-1.15	-3.28	-1.15	198.60	20.96	3.60
2450.00	29.960	-1.25	-3.27	-1.25	195.29	26.22	3.67
2465.00	30.170	-1.37	-3.27	-1.37	192.14	31.69	3.73
2480.00	30.460	-1.50	-3.29	-1.50	189.17	37.37	3.79
2495.00	30.820	-1.63	-3.31	-1.63	186.38	43.26	3.85
2510.00	31.270	-1.78	-3.34	-1.78	183.77	49.36	3.91
2525.00	31.810	-1.94	-3.39	-1.94	181.37	55.66	3.97
2540.00	32.440	-2.11	-3.44	-2.11	179.18	62.16	4.02
2555.00	33.180	-2.30	-3.51	-2.30	177.20	68.88	4.07
2570.00	34.030	-2.41	-3.59	-2.50	175.46	75.76	4.12
2585.00	34.980	-2.26	-3.69	-2.72	173.96	82.85	4.17
2600.00	36.060	-2.10	-3.80	-2.95	172.72	90.14	4.21
2615.00	37.260	-1.93	-3.93	-3.20	171.74	97.61	4.25
2630.00	38.570	-1.75	-4.08	-3.46	171.04	105.27	4.28
2645.00	40.020	-1.57	-4.25	-3.74	170.64	113.11	4.30
2660.00	41.590	-1.38	-4.44	-4.04	170.55	121.12	4.32
2675.00	43.280	-1.19	-4.65	-4.36	170.79	129.30	4.33
2690.00	45.080	-1.00	-4.89	-4.69	171.37	137.64	4.34
2705.00	47.010	-0.80	-5.15	-5.03	172.31	146.14	4.33
2720.00	49.030	-0.61	-5.45	-5.03	173.64	154.78	4.32
2735.00	51.150	-0.42	-5.77	-5.76	175.36	163.56	4.30
2750.00	53.360	-0.23	-6.13	-6.13	177.51	172.46	4.28
2765.00	55.640	-0.04	-6.49	-6.49	180.10	181.46	4.24
2780.00	57.980	0.14	-6.84	-6.84	183.16	190.55	4.20
2795.00	60.360	0.31	-7.17	-7.17	186.70	199.71	4.15
2810.00	62.770	0.48	-7.47	-7.47	190.72	208.92	4.09
2825.00	65.190	0.64	-7.72	-7.72	195.35	218.15	4.03
2840.00	67.600	0.79	-7.90	-7.90	200.50	227.38	3.95
2855.00	69.990	0.93	-8.02	-8.02	206.22	236.56	3.88
2870.00	72.330	1.07	-8.06	-8.06	212.55	245.67	3.79
2885.00	74.630	1.19	-8.02	-8.02	219.50	254.67	3.71
2900.00	76.850	1.31	-7.91	-7.91	227.10	263.50	3.62
2915.00	79.000	1.42	-7.73	-7.73	235.34	272.12	3.52
2930.00	81.050	1.52	-7.49	-7.49	244.26	280.48	3.43
2945.00	83.000	1.61	-7.21	-7.21	253.85	288.52	3.33
2960.00	84.840	1.69	-6.90	-6.90	264.13	296.17	3.23
2975.00	86.570	1.76	-6.57	-6.57	275.08	303.37	3.13
2990.00	88.180	1.82	-6.22	-6.22	286.70	310.04	3.03
3005.00	89.660	1.88	-5.87	-5.87	298.97	316.12	2.94
3020.00	91.030	1.93	-5.53	-5.53	311.86	321.51	2.84
3035.00	92.280	1.97	-5.19	-5.19	325.34	326.16	2.75
3050.00	93.400	2.01	-4.86	-4.86	339.36	329.97	2.65
3065.00	94.410	2.04	-4.54	-4.54	353.85	332.87	2.56
3080.00	95.300	2.06	-4.23	-4.23	368.74	334.80	2.48
3095.00	96.080	2.08	-3.94	-3.94	383.96	335.68	2.39
3110.00	96.760	2.09	-3.66	-3.66	399.40	335.46	2.31
3125.00	97.340	2.10	-3.39	-3.39	414.96	334.10	2.23
3140.00	97.810	2.10	-3.14	-3.14	430.52	331.55	2.16
3155.00	98.200	2.10	-2.90	-2.90	445.96	327.80	2.08
3170.00	98.510	2.09	-2.67	-2.67	461.15	322.85	2.02
3185.00	98.730	2.08	-2.46	-2.46	475.96	316.72	1.95
3200.00	98.880	2.07	-2.26	-2.26	490.26	309.43	1.89
3215.00	98.950	2.05	-2.06	-2.06	503.92	301.04	1.83
3230.00	98.970	2.03	-1.88	-1.88	516.82	291.62	1.77
3245.00	98.920	2.01	-1.71	-1.71	528.85	281.25	1.72
3260.00	98.800	1.99	-1.55	-1.55	539.91	270.01	1.67
3275.00	98.660	1.96	-1.39	-1.39	549.93	258.12	1.62
3290.00	98.450	1.93	-1.25	-1.25	558.84	245.59	1.58
3305.00	98.200	1.90	-1.11	-1.11	566.59	232.59	1.54
3320.00	97.910	1.87	-0.98	-0.98	573.15	219.26	1.50
3335.00	97.580	1.84	-0.86	-0.86	578.53	205.72	1.46
3350.00	97.220	1.80	-0.74	-0.74	582.72	192.12	1.43
3365.00	96.820	1.76	-0.63	-0.63	585.77	178.56	1.40
3380.00	96.400	1.73	-0.53	-0.53	587.70	165.17	1.38
3395.00	95.950	1.69	-0.43	-0.43	588.57	152.05	1.35
3410.00	95.470	1.65	-0.33	-0.33	588.45	139.30	1.32
3425.00	94.980	1.60	-0.25	-0.25	587.41	126.99	1.34
3440.00	94.460	1.56	-0.16	-0.16	585.52	115.20	1.31
3455.00	93.920	1.52	-0.08	-0.08	582.88	103.98	1.30
3470.00	93.370	1.48	-0.01	-0.01	579.56	93.38	1.29
3485.00	92.800	1.43	0.06	0.06	575.65	83.42	1.29
3500.00	92.220	1.39	0.12	0.12	571.23	74.13	1.29
3515.00	91.630	1.35	0.19	0.19	566.37	65.53	1.29
3530.00	91.020	1.30	0.24	0.24	561.15	57.61	1.30
3545.00	90.410	1.26	0.30	0.30	555.64	50.37	1.30
3560.00	89.790	1.22	0.35	0.35	549.92	43.80	1.31
3575.00	89.160	1.18	0.39	0.39	544.03	37.90	1.32
3590.00	88.530	1.15	0.43	0.43	538.04	32.64	1.34
3605.00	87.890	1.11	0.47	0.47	531.99	27.99	1.35
3620.00	87.250	1.08	0.51	0.51	525.83	23.94	1.36
3635.00	86.610	1.06	0.54	0.54	519.90	20.46	1.38
3650.00	85.970	1.03	0.57	0.57	513.95	17.52	1.39
3665.00	85.330	1.01	0.60	0.60	508.09	15.09	1.41
3680.00	84.690	0.99	0.62	0.62	502.36	13.14	1.42
3695.00	84.050	0.96	0.64	0.64	496.79	11.66	1.44
3710.00	83.410	0.95	0.65	0.65	491.39	10.60	1.46

3725.00	82.780	0.93	0.66	0.66	486.19	9.94	1.47
3740.00	82.150	0.91	0.67	0.67	481.20	9.65	1.49
3755.00	81.640	0.89	0.68	0.68	476.44	9.77	1.50
3770.00	80.920	0.87	0.68	0.68	471.91	10.10	1.52
3785.00	80.320	0.85	0.68	0.68	467.63	10.78	1.53
3800.00	79.730	0.84	0.68	0.68	463.60	11.73	1.54
3815.00	79.150	0.82	0.68	0.68	459.84	12.93	1.56
3830.00	78.580	0.80	0.67	0.67	456.34	14.36	1.57
3845.00	78.020	0.78	0.65	0.65	453.12	15.99	1.58
3860.00	77.480	0.76	0.64	0.64	450.18	17.81	1.59
3875.00	76.950	0.74	0.62	0.62	447.51	19.80	1.60
3890.00	76.440	0.73	0.60	0.60	445.13	21.93	1.61
3905.00	75.950	0.71	0.58	0.58	443.03	24.19	1.62
3920.00	75.470	0.70	0.55	0.55	441.21	26.56	1.62
3935.00	75.020	0.71	0.52	0.52	439.68	29.02	1.63
3950.00	74.180	0.72	0.49	0.49	438.43	31.55	1.64
3965.00	74.160	0.75	0.45	0.45	437.47	34.15	1.64
3980.00	73.760	0.77	0.41	0.41	436.79	36.78	1.64
3995.00	73.390	0.81	0.37	0.37	436.39	39.44	1.65
4010.00	73.040	0.84	0.33	0.33	436.27	42.11	1.65
4025.00	72.700	0.88	0.28	0.28	436.43	44.78	1.65
4040.00	72.400	0.92	0.23	0.23	436.87	47.42	1.65
4055.00	72.110	0.96	0.18	0.18	437.57	50.03	1.65
4070.00	71.850	1.01	0.13	0.13	438.54	52.59	1.64
4085.00	71.620	1.06	0.07	0.07	439.78	55.07	1.64
4100.00	71.410	1.12	0.01	0.01	441.28	57.48	1.64
4115.00	71.220	1.17	-0.05	-0.05	443.03	59.79	1.63
4130.00	71.050	1.23	-0.11	-0.11	445.04	61.99	1.63
4145.00	70.910	1.29	-0.18	-0.18	447.28	64.07	1.62
4160.00	70.790	1.36	-0.24	-0.24	449.76	66.00	1.61
4175.00	70.700	1.42	-0.31	-0.31	452.48	67.77	1.60
4190.00	70.630	1.49	-0.38	-0.38	455.41	69.38	1.59
4205.00	70.580	1.55	-0.46	-0.46	458.55	70.80	1.58
4220.00	70.550	1.62	-0.53	-0.53	461.89	72.02	1.57
4235.00	70.550	1.69	-0.60	-0.60	465.43	73.03	1.56
4250.00	70.560	1.76	-0.68	-0.68	469.14	73.81	1.55
4265.00	70.600	1.83	-0.76	-0.76	473.02	74.35	1.54
4280.00	70.650	1.90	-0.84	-0.84	477.06	74.64	1.53
4295.00	70.720	1.97	-0.91	-0.91	481.23	74.66	1.51
4310.00	70.810	2.04	-0.99	-0.99	485.52	74.41	1.50
4325.00	70.920	2.11	-1.07	-1.07	489.92	73.87	1.49
4340.00	71.040	2.19	-1.15	-1.15	494.41	73.02	1.47
4355.00	71.180	2.26	-1.24	-1.24	498.96	71.87	1.46
4370.00	71.340	2.33	-1.32	-1.32	503.57	70.40	1.45
4385.00	71.500	2.40	-1.40	-1.40	508.20	68.61	1.43
4400.00	71.680	2.46	-1.48	-1.48	512.85	66.49	1.42
4415.00	71.870	2.53	-1.56	-1.56	517.48	64.04	1.40
4430.00	72.070	2.60	-1.64	-1.64	522.07	61.24	1.39
4445.00	72.280	2.67	-1.72	-1.72	526.60	58.11	1.38
4460.00	72.500	2.73	-1.80	-1.80	531.04	54.64	1.36
4475.00	72.730	2.80	-1.88	-1.88	535.38	50.83	1.35
4490.00	72.960	2.86	-1.96	-1.96	539.58	46.69	1.34
4505.00	73.210	2.92	-2.03	-2.03	543.62	42.22	1.33
4520.00	73.450	2.98	-2.11	-2.11	547.48	37.44	1.31
4535.00	73.710	3.04	-2.18	-2.18	551.14	32.34	1.30
4550.00	73.960	3.10	-2.26	-2.26	554.56	26.95	1.29
4565.00	74.220	3.16	-2.33	-2.33	557.73	21.27	1.28
4580.00	74.490	3.22	-2.40	-2.40	560.62	15.33	1.28
4595.00	74.750	3.27	-2.47	-2.47	563.22	9.13	1.27
4610.00	75.020	3.33	-2.54	-2.54	565.50	2.70	1.26
4625.00	75.290	3.38	-2.61	-2.61	567.44	-3.93	1.26
4640.00	75.560	3.43	-2.68	-2.68	569.04	-10.76	1.26
4655.00	75.830	3.48	-2.74	-2.74	570.27	-17.74	1.26
4670.00	76.100	3.53	-2.81	-2.81	571.12	-24.88	1.26
4685.00	76.370	3.58	-2.87	-2.87	571.59	-32.12	1.26
4700.00	76.640	3.63	-2.93	-2.93	571.66	-39.45	1.26
4715.00	76.910	3.68	-2.99	-2.99	571.33	-46.84	1.27
4730.00	77.170	3.72	-3.05	-3.05	570.60	-54.26	1.27
4745.00	77.440	3.77	-3.10	-3.10	569.45	-61.69	1.28
4760.00	77.700	3.81	-3.16	-3.16	567.90	-69.09	1.29
4775.00	77.960	3.85	-3.22	-3.22	565.95	-76.44	1.30
4790.00	78.220	3.89	-3.27	-3.27	563.60	-83.72	1.31
4805.00	78.470	3.93	-3.32	-3.32	560.85	-90.89	1.33
4820.00	78.720	3.97	-3.37	-3.37	557.72	-97.94	1.34
4835.00	78.960	4.01	-3.43	-3.43	554.22	-104.83	1.35
4850.00	79.210	4.04	-3.48	-3.48	550.37	-111.53	1.37
4865.00	79.450	4.08	-3.53	-3.53	546.16	-118.08	1.39
4880.00	79.680	4.12	-3.57	-3.57	541.63	-124.38	1.41
4895.00	79.910	4.15	-3.62	-3.62	536.78	-130.46	1.43
4910.00	80.140	4.18	-3.67	-3.67	531.63	-136.29	1.45
4925.00	80.360	4.21	-3.72	-3.72	526.21	-141.85	1.47
4940.00	80.580	4.24	-3.77	-3.77	520.52	-147.14	1.49
4955.00	80.800	4.27	-3.81	-3.81	514.60	-152.13	1.51
4970.00	81.010	4.30	-3.86	-3.86	508.45	-156.83	1.53
4985.00	81.210	4.33	-3.91	-3.91	502.10	-161.22	1.56
5000.00	81.410	4.36	-3.95	-3.95	495.57	-165.29	1.58
5015.00	81.610	4.38	-4.00	-4.00	488.88	-169.05	1.60
5030.00	81.800	4.41	-4.05	-4.05	482.04	-172.48	1.63
5045.00	81.990	4.43	-4.10	-4.10	475.08	-175.58	1.66
5060.00	82.170	4.46	-4.15	-4.15	468.01	-178.36	1.68
5075.00	82.350	4.48	-4.20	-4.20	460.85	-180.81	1.71
5090.00	82.520	4.50	-4.25	-4.25	453.62	-182.93	1.74
5105.00	82.690	4.52	-4.30	-4.30	446.34	-184.72	1.77
5120.00	82.850	4.54	-4.36	-4.36	439.02	-186.20	1.80
5135.00	83.010	4.56	-4.41	-4.41	431.68	-187.35	1.83
5150.00	83.160	4.57	-4.47	-4.47	424.32	-188.19	1.86
5165.00	83.310	4.59	-4.53	-4.53	416.98	-188.72	1.89
5180.00	83.460	4.60	-4.59	-4.59	409.64	-188.94	1.92
5195.00	83.600	4.61	-4.65	-4.65	402.34	-188.86	1.95
5210.00	83.730	4.63	-4.72	-4.72	395.09	-188.49	1.98
5225.00	83.860	4.64	-4.79	-4.79	387.88	-187.83	2.02
5240.00	83.990	4.65	-4.86	-4.86	380.74	-186.89	2.05
5255.00	84.110	4.66	-4.93	-4.93	373.67	-185.68	2.09
5270.00	84.230	4.67	-5.01	-5.01	366.68	-184.19	2.12
5285.00	84.340	4.68	-5.09	-5.09	359.78	-182.45	2.16
5300.00	84.440	4.68	-5.17	-5.17	352.97	-180.45	2.19
5315.00	84.550	4.69	-5.26	-5.26	346.27	-178.21	2.23
5330.00	84.640	4.70	-5.35	-5.35	339.68	-175.72	2.27
5345.00	84.740	4.70	-5.44	-5.44	333.21	-173.00	2.30
5360.00	84.820	4.71	-5.54	-5.54	326.86	-170.05	2.34
5375.00	84.910	4.71	-5.65	-5.65	320.63	-166.88	2.38
5390.00	84.980	4.71	-5.76	-5.76	314.54	-163.50	2.42
5405.00	85.060	4.71	-5.87	-5.87	308.58	-159.90	2.46
5420.00	85.130	4.71	-5.99	-5.99	302.77	-156.10	2.50
5435.00	85.190	4.71	-6.11	-6.11	297.10	-152.11	2.54
5450.00	85.250	4.70	-6.24	-6.24	291.58	-147.92	2.58
5465.00	85.300	4.70	-6.38	-6.38	286.21	-143.54	2.62
5480.00	85.350	4.69	-6.52	-6.52	281.00	-138.98	2.66
5495.00	85.400	4.68	-6.67	-6.67	275.94	-134.25	2.70
5510.00	85.440	4.67	-6.82	-6.82	271.05	-129.34	2.74
5525.00	85.470	4.66	-6.98	-6.98	266.32	-124.26	2.78
5540.00	85.500	4.64	-7.15	-7.15	261.76	-119.02	2.82
5555.00	85.520	4.62	-7.32	-7.32	257.37	-113.61	2.86
5570.00	85.540	4.59	-7.50	-7.50	253.16	-108.05	2.90
5585.00	85.560	4.57	-7.68	-7.68	249.12	-102.33	2.94
5600.00	85.570	4.55	-7.86	-7.86	245.26	-96.47	2.98
5615.00	85.570	4.52	-8.05	-8.05	241.59	-90.45	3.01
5630.00	85.570	4.48	-8.25	-8.25	238.10	-84.29	3.05
5645.00	85.560	4.44	-8.44	-8.44	234.80	-77.99	3.09

5660.00	85.550	4.40	-8.63	-8.63	231.70	-71.55	3.12
5675.00	85.530	4.35	-8.81	-8.81	228.79	-64.98	3.15
5690.00	85.510	4.30	-8.99	-8.99	226.09	-58.27	3.19
5705.00	85.490	4.24	-9.16	-9.16	223.59	-51.43	3.22
5720.00	85.460	4.17	-9.31	-9.31	221.31	-44.46	3.24
5735.00	85.420	4.10	-9.45	-9.45	219.24	-37.37	3.27
5750.00	85.380	4.03	-9.56	-9.56	217.38	-30.15	3.30
5765.00	85.330	3.95	-9.64	-9.64	215.76	-22.81	3.32
5780.00	85.290	3.87	-9.69	-9.69	214.37	-15.34	3.34
5795.00	85.230	3.78	-9.70	-9.70	213.22	-7.78	3.35
5810.00	85.170	3.68	-9.67	-9.67	212.31	-0.09	3.37
5825.00	85.110	3.57	-9.59	-9.59	211.65	7.70	3.38
5840.00	85.050	3.46	-9.53	-9.48	211.25	15.61	3.39
5855.00	84.980	3.33	-9.46	-9.32	211.12	23.62	3.39
5870.00	84.910	3.20	-9.34	-9.13	211.26	31.72	3.39
5885.00	84.830	3.05	-9.25	-8.90	211.69	39.93	3.39
5900.00	84.760	2.90	-9.40	-8.64	212.41	48.22	3.38
5915.00	84.680	2.74	-9.41	-8.35	213.43	56.60	3.37
5930.00	84.600	2.56	-9.37	-8.04	214.77	65.06	3.36
5945.00	84.510	2.37	-9.30	-7.72	216.43	73.60	3.34
5960.00	84.430	2.19	-9.19	-7.38	218.43	82.20	3.32
5975.00	84.340	1.99	-9.41	-7.04	220.77	90.86	3.30
5990.00	84.250	1.78	-9.61	-6.69	223.48	99.57	3.27
6005.00	84.170	1.56	-9.78	-6.35	226.55	108.32	3.24
6020.00	84.080	1.32	-9.90	-6.01	230.01	117.11	3.20
6035.00	83.990	1.08	-9.97	-5.67	233.88	125.91	3.16
6050.00	83.900	0.81	-10.00	-5.34	238.15	134.71	3.12
6065.00	83.810	0.54	-9.97	-5.02	242.85	143.50	3.08
6080.00	83.730	0.25	-9.97	-4.70	247.99	152.27	3.03
6095.00	83.640	-0.06	-10.41	-4.40	253.59	160.99	2.98
6110.00	83.550	-0.38	-10.83	-4.11	259.66	169.64	2.93
6125.00	83.470	-0.72	-11.23	-3.82	266.21	178.21	2.88
6140.00	83.380	-1.08	-11.59	-3.55	273.26	186.66	2.82
6155.00	83.300	-1.46	-11.90	-3.29	280.83	194.97	2.77
6170.00	83.210	-1.85	-12.14	-3.04	288.92	203.11	2.71
6185.00	83.130	-2.27	-12.30	-2.80	297.54	211.05	2.65
6200.00	83.040	-2.57	-12.37	-2.57	306.70	218.76	2.59
6215.00	82.960	-2.35	-12.37	-2.35	316.42	226.18	2.53
6230.00	82.880	-2.14	-12.96	-2.14	326.70	233.47	2.47
6245.00	82.790	-1.95	-13.80	-1.95	337.54	240.06	2.42
6260.00	82.710	-1.76	-14.66	-1.76	348.94	246.41	2.36
6275.00	82.620	-1.58	-15.52	-1.58	360.90	252.31	2.30
6290.00	82.540	-1.40	-16.35	-1.40	373.40	257.70	2.24
6305.00	82.450	-1.24	-17.08	-1.24	386.45	262.54	2.18
6320.00	82.370	-1.09	-17.65	-1.09	400.01	266.77	2.13
6335.00	82.280	-0.94	-17.98	-0.94	414.07	270.33	2.07
6350.00	82.190	-0.80	-18.03	-0.80	428.59	273.16	2.01
6365.00	82.100	-0.67	-17.80	-0.67	443.54	275.21	1.96
6380.00	82.000	-0.54	-19.38	-0.54	458.88	276.42	1.91
6395.00	81.910	-0.42	-21.62	-0.42	474.55	276.74	1.86
6410.00	81.820	-0.31	-24.54	-0.31	490.49	276.11	1.81
6425.00	81.710	-0.20	-28.76	-0.20	506.64	274.49	1.76
6440.00	81.600	-0.10	-35.79	-0.10	522.92	271.83	1.71
6455.00	81.500	0.00	-35.99	0.00	539.25	268.10	1.67
6470.00	81.390	0.09	-29.10	0.09	555.53	263.27	1.62
6485.00	81.270	0.17	-25.04	0.17	571.68	257.32	1.58
6500.00	81.160	0.25	-27.53	0.25	587.58	250.24	1.54
6515.00	81.040	0.33	-34.00	0.33	603.15	242.03	1.50
6530.00	80.910	0.40	-31.28	0.40	618.27	232.71	1.46
6545.00	80.780	0.47	-25.68	0.47	632.83	222.31	1.42
6560.00	80.650	0.54	-22.08	0.54	646.73	210.86	1.38
6575.00	80.510	0.60	-19.97	0.60	659.87	198.43	1.35
6590.00	80.370	0.65	-18.58	0.65	672.16	185.07	1.31
6605.00	80.230	0.71	-17.25	0.71	683.50	170.87	1.28
6620.00	80.080	0.76	-16.03	0.76	693.81	155.91	1.25
6635.00	79.920	0.81	-14.95	0.81	703.04	140.30	1.22
6650.00	79.760	0.85	-14.07	0.85	711.11	124.13	1.19
6665.00	79.590	0.89	-13.29	0.89	718.00	107.53	1.16
6680.00	79.420	0.93	-12.57	0.93	723.68	90.60	1.13
6695.00	79.240	0.96	-11.91	0.96	728.12	73.47	1.11
6710.00	79.060	1.00	-11.30	1.00	731.33	56.25	1.08
6725.00	78.870	1.03	-10.73	1.03	733.33	39.06	1.06
6740.00	78.680	1.05	-10.21	1.05	734.13	21.99	1.04
6755.00	78.480	1.08	-9.72	1.08	733.79	5.17	1.03
6770.00	78.280	1.10	-9.26	1.10	732.04	-11.32	1.03
6785.00	78.060	1.16	-8.85	1.12	729.85	-27.40	1.04
6800.00	77.850	1.29	-8.49	1.14	726.38	-42.98	1.06
6815.00	77.630	1.41	-8.14	1.15	722.00	-58.00	1.08
6830.00	77.400	1.53	-7.82	1.16	716.78	-72.39	1.11
6845.00	77.160	1.64	-7.52	1.17	710.81	-86.12	1.13
6860.00	76.920	1.75	-7.23	1.18	704.15	-99.15	1.15
6875.00	76.680	1.86	-6.96	1.19	696.89	-111.44	1.17
6890.00	76.420	1.97	-6.70	1.19	689.11	-122.98	1.20
6905.00	76.170	2.07	-6.45	1.19	680.87	-133.75	1.22
6920.00	75.900	2.16	-6.21	1.19	672.25	-143.76	1.24
6935.00	75.630	2.26	-5.98	1.19	663.32	-153.00	1.26
6950.00	75.360	2.35	-5.77	1.19	654.15	-161.49	1.29
6965.00	75.080	2.43	-5.56	1.17	644.79	-169.22	1.31
6980.00	74.790	2.52	-5.36	1.16	635.30	-176.24	1.33
6995.00	74.500	2.60	-5.17	1.15	625.72	-182.54	1.35
7010.00	74.200	2.67	-5.03	1.13	616.12	-188.15	1.38
7025.00	73.900	2.75	-4.89	1.11	606.53	-193.10	1.40
7040.00	73.590	2.82	-4.76	1.09	596.98	-197.42	1.42
7055.00	73.280	2.89	-4.63	1.07	587.52	-201.13	1.44
7070.00	72.960	2.95	-4.51	1.04	578.18	-204.26	1.46
7085.00	72.640	3.02	-4.39	1.01	568.98	-206.83	1.48
7100.00	72.310	3.08	-4.28	0.98	559.95	-208.88	1.50
7115.00	71.980	3.13	-4.17	0.94	551.11	-210.43	1.52
7130.00	71.650	3.19	-4.06	0.91	542.44	-211.57	1.54
7145.00	71.320	3.24	-3.96	0.86	534.07	-212.16	1.56
7160.00	70.980	3.29	-3.87	0.81	525.89	-212.39	1.58
7175.00	70.640	3.33	-3.77	0.76	517.97	-212.22	1.60
7190.00	70.300	3.37	-3.69	0.71	510.32	-211.69	1.62
7205.00	69.960	3.42	-3.62	0.65	502.93	-210.81	1.64
7220.00	69.620	3.45	-3.58	0.59	495.82	-209.62	1.66
7235.00	69.280	3.49	-3.55	0.53	489.00	-208.13	1.67
7250.00	68.940	3.52	-3.52	0.46	482.46	-206.36	1.69
7265.00	68.600	3.55	-3.49	0.38	476.22	-204.33	1.70
7280.00	68.260	3.57	-3.47	0.31	470.29	-202.06	1.72
7295.00	67.930	3.60	-3.45	0.22	464.65	-199.58	1.73
7310.00	67.610	3.62	-3.43	0.13	459.32	-196.90	1.74
7325.00	67.280	3.63	-3.42	0.04	454.29	-194.03	1.76
7340.00	66.970	3.65	-3.40	-0.06	449.58	-190.99	1.77
7355.00	66.660	3.66	-3.39	-0.16	445.17	-187.80	1.78
7370.00	66.360	3.66	-3.38	-0.27	441.08	-184.48	1.79
7385.00	66.080	3.67	-3.38	-0.39	437.30	-181.04	1.79
7400.00	65.800	3.67	-3.40	-0.51	433.84	-177.50	1.80
7415.00	65.530	3.67	-3.46	-0.64	430.69	-173.86	1.81
7430.00	65.280	3.66	-3.53	-0.78	427.86	-170.15	1.81
7445.00	65.040	3.66	-3.59	-0.92	425.34	-166.38	1.82
7460.00	64.820	3.64	-3.66	-1.07	423.14	-162.57	1.82
7475.00	64.610	3.63	-3.74	-1.23	421.27	-158.72	1.82
7490.00	64.420	3.60	-3.82	-1.40	419.71	-154.87	1.82
7505.00	64.250	3.59	-3.89	-1.57	418.47	-151.01	1.82
7520.00	64.100	3.57	-3.98	-1.76	417.55	-147.17	1.82
7535.00	63.970	3.54	-4.06	-1.95	416.95	-143.36	1.82
7550.00	63.870	3.51	-4.15	-2.16	416.67	-139.60	1.81
7565.00	63.790	3.48	-4.23	-2.37	416.70	-135.90	1.81
7580.00	63.730	3.44	-4.36	-2.60	417.05	-132.29	1.80

7595.00	63.690	3.40	-4.54	-2.84	417.72	-128.78	1.79
7610.00	63.690	3.36	-4.72	-3.08	418.69	-125.39	1.79
7625.00	63.700	3.32	-4.91	-3.32	419.97	-123.14	1.78
7640.00	63.750	3.27	-5.10	-3.56	421.55	-119.05	1.77
7655.00	63.820	3.22	-5.29	-3.90	423.43	-116.14	1.76
7670.00	63.920	3.17	-5.49	-4.20	425.59	-113.42	1.74
7685.00	64.050	3.11	-5.69	-4.51	428.04	-110.93	1.73
7700.00	64.210	3.06	-5.89	-4.84	430.75	-108.68	1.72
7715.00	64.390	3.00	-6.08	-5.18	433.77	-106.70	1.71
7730.00	64.600	2.95	-6.33	-5.54	436.93	-105.00	1.69
7745.00	64.840	2.89	-6.65	-5.91	440.37	-103.62	1.68
7760.00	65.100	2.83	-6.96	-6.30	444.01	-102.56	1.66
7775.00	65.390	2.77	-7.29	-6.70	447.84	-101.86	1.65
7790.00	65.700	2.71	-7.61	-7.12	451.84	-101.53	1.63
7805.00	66.030	2.65	-7.93	-7.56	455.96	-101.59	1.62
7820.00	66.390	2.59	-8.25	-8.00	460.20	-102.06	1.61
7835.00	66.770	2.54	-8.61	-8.47	464.51	-102.96	1.59
7850.00	67.170	2.48	-9.04	-8.94	468.86	-104.29	1.58
7865.00	67.590	2.43	-9.47	-9.41	473.22	-106.08	1.57
7880.00	68.020	2.38	-9.90	-9.89	477.54	-108.32	1.56
7895.00	68.470	2.33	-10.37	-10.37	481.79	-111.02	1.55
7910.00	68.930	2.28	-10.83	-10.83	485.92	-114.18	1.54
7925.00	69.410	2.24	-11.26	-11.26	489.89	-117.80	1.53
7940.00	69.890	2.20	-11.66	-11.66	493.66	-121.87	1.53
7955.00	70.390	2.17	-12.01	-12.01	497.19	-126.37	1.52
7970.00	70.890	2.14	-12.29	-12.29	500.43	-131.28	1.52
7985.00	71.400	2.10	-12.50	-12.50	503.44	-136.54	1.52
8000.00	71.910	2.09	-12.62	-12.62	505.88	-142.24	1.52
8015.00	72.420	2.07	-12.64	-12.64	508.01	-148.24	1.52
8030.00	72.940	2.06	-12.58	-12.58	509.72	-154.52	1.53
8045.00	73.450	2.06	-12.44	-12.44	510.95	-161.05	1.53
8060.00	73.970	2.05	-12.22	-12.22	511.70	-167.79	1.54
8075.00	74.480	2.06	-11.95	-11.95	511.94	-174.68	1.55
8090.00	74.980	2.07	-11.63	-11.63	511.67	-181.68	1.56
8105.00	75.480	2.08	-11.29	-11.29	510.87	-188.74	1.58
8120.00	75.970	2.10	-10.93	-10.93	509.54	-195.82	1.59
8135.00	76.460	2.12	-10.56	-10.56	507.70	-202.84	1.61
8150.00	76.930	2.15	-10.19	-10.19	505.34	-209.78	1.63
8165.00	77.400	2.18	-9.82	-9.82	502.48	-216.59	1.65
8180.00	77.850	2.21	-9.46	-9.46	499.15	-223.22	1.67
8195.00	78.300	2.25	-9.11	-9.11	495.37	-229.63	1.70
8210.00	78.730	2.29	-8.77	-8.77	491.16	-235.79	1.72
8225.00	79.140	2.34	-8.44	-8.44	486.56	-241.66	1.74
8240.00	79.550	2.39	-8.13	-8.13	481.60	-247.22	1.77
8255.00	79.940	2.44	-7.83	-7.83	476.32	-252.45	1.80
8270.00	80.310	2.49	-7.55	-7.55	470.75	-257.32	1.83
8285.00	80.670	2.55	-7.27	-7.27	464.92	-261.82	1.86
8300.00	81.010	2.60	-7.02	-7.02	458.88	-265.94	1.88
8315.00	81.340	2.66	-6.77	-6.77	452.65	-269.68	1.92
8330.00	81.650	2.72	-6.54	-6.54	446.28	-273.04	1.95
8345.00	81.950	2.78	-6.32	-6.32	439.80	-276.00	1.98
8360.00	82.230	2.84	-6.11	-6.11	433.64	-278.58	2.01
8375.00	82.490	2.91	-5.92	-5.92	426.62	-280.78	2.04
8390.00	82.740	2.97	-5.73	-5.73	419.98	-282.62	2.07
8405.00	82.970	3.03	-5.56	-5.56	413.35	-284.10	2.11
8420.00	83.190	3.09	-5.39	-5.39	406.74	-285.23	2.14
8435.00	83.380	3.16	-5.24	-5.24	400.17	-286.03	2.17
8450.00	83.560	3.22	-5.09	-5.09	393.68	-286.51	2.20
8465.00	83.730	3.28	-4.95	-4.95	387.26	-286.68	2.24
8480.00	83.870	3.34	-4.82	-4.82	380.95	-286.57	2.27
8495.00	84.010	3.40	-4.71	-4.71	374.75	-286.19	2.30
8510.00	84.120	3.46	-4.59	-4.59	368.68	-285.54	2.34
8525.00	84.220	3.52	-4.49	-4.49	362.74	-284.66	2.37
8540.00	84.300	3.58	-4.39	-4.39	356.94	-283.55	2.40
8555.00	84.370	3.63	-4.31	-4.31	351.29	-282.22	2.43
8570.00	84.420	3.68	-4.22	-4.22	345.80	-280.70	2.46
8585.00	84.460	3.74	-4.15	-4.15	340.47	-279.00	2.50
8600.00	84.480	3.79	-4.08	-4.08	335.30	-277.13	2.53
8615.00	84.490	3.84	-4.02	-4.02	330.20	-275.11	2.56
8630.00	84.480	3.88	-3.97	-3.97	325.46	-272.94	2.59
8645.00	84.460	3.93	-3.92	-3.92	320.80	-270.64	2.61
8660.00	84.430	3.97	-3.88	-3.88	316.31	-268.23	2.64
8675.00	84.380	4.02	-3.84	-3.84	311.98	-265.70	2.67
8690.00	84.320	4.06	-3.81	-3.81	307.83	-263.08	2.70
8705.00	84.250	4.09	-3.79	-3.79	303.84	-260.38	2.72
8720.00	84.160	4.13	-3.77	-3.77	300.02	-257.59	2.75
8735.00	84.060	4.17	-3.76	-3.76	296.37	-254.74	2.77
8750.00	83.950	4.20	-3.75	-3.75	292.87	-251.82	2.80
8765.00	83.830	4.23	-3.75	-3.75	289.54	-248.85	2.82
8780.00	83.700	4.25	-3.75	-3.75	286.36	-245.84	2.84
8795.00	83.560	4.28	-3.76	-3.76	283.34	-242.79	2.86
8810.00	83.410	4.30	-3.77	-3.77	280.48	-239.70	2.88
8825.00	83.240	4.32	-3.80	-3.80	277.76	-236.60	2.90
8840.00	83.070	4.34	-3.82	-3.82	275.19	-233.47	2.92
8855.00	82.890	4.36	-3.85	-3.85	272.72	-230.33	2.93
8870.00	82.710	4.37	-3.89	-3.89	270.47	-227.18	2.95
8885.00	82.510	4.38	-3.93	-3.93	268.32	-224.03	2.96
8900.00	82.310	4.39	-3.97	-3.97	266.31	-220.87	2.98
8915.00	82.100	4.40	-4.03	-4.03	264.43	-217.73	2.99
8930.00	81.880	4.41	-4.08	-4.08	262.67	-214.59	3.00
8945.00	81.660	4.41	-4.14	-4.14	261.04	-211.47	3.01
8960.00	81.440	4.41	-4.21	-4.21	259.54	-208.37	3.02
8975.00	81.200	4.41	-4.28	-4.28	258.15	-205.29	3.03
8990.00	80.970	4.40	-4.36	-4.36	256.88	-202.23	3.04
9005.00	80.730	4.40	-4.44	-4.44	255.72	-199.20	3.04
9020.00	80.480	4.39	-4.53	-4.53	254.68	-196.20	3.05
9035.00	80.240	4.38	-4.62	-4.62	253.74	-193.24	3.05
9050.00	79.980	4.36	-4.72	-4.72	252.90	-190.32	3.06
9065.00	79.730	4.35	-4.83	-4.83	252.16	-187.44	3.06
9080.00	79.480	4.33	-4.93	-4.93	251.53	-184.60	3.06
9095.00	79.220	4.31	-5.05	-5.05	250.99	-181.81	3.06
9110.00	78.960	4.28	-5.17	-5.17	250.54	-179.06	3.06
9125.00	78.700	4.26	-5.29	-5.29	250.18	-176.37	3.05
9140.00	78.440	4.23	-5.42	-5.42	249.90	-173.73	3.05
9155.00	78.180	4.20	-5.56	-5.56	249.71	-171.15	3.05
9170.00	77.920	4.17	-5.70	-5.70	249.60	-168.62	3.04
9185.00	77.660	4.14	-5.84	-5.84	249.57	-166.16	3.04
9200.00	77.410	4.10	-5.99	-5.99	249.61	-163.75	3.03
9215.00	77.150	4.07	-6.15	-6.15	249.72	-161.41	3.03
9230.00	76.890	4.03	-6.31	-6.31	249.89	-159.14	3.02
9245.00	76.640	3.98	-6.48	-6.48	250.13	-156.94	3.01
9260.00	76.380	3.94	-6.65	-6.65	250.43	-154.80	3.01
9275.00	76.130	3.89	-6.83	-6.83	250.78	-152.74	3.00
9290.00	75.880	3.85	-7.02	-7.02	251.19	-150.74	2.99
9305.00	75.640	3.80	-7.21	-7.21	251.65	-148.83	2.98
9320.00	75.390	3.74	-7.40	-7.40	252.15	-146.98	2.97
9335.00	75.150	3.69	-7.60	-7.60	252.70	-145.22	2.96
9350.00	74.920	3.63	-7.81	-7.81	253.28	-143.53	2.95
9365.00	74.680	3.58	-8.02	-8.02	253.90	-141.92	2.94
9380.00	74.450	3.52	-8.24	-8.24	254.55	-140.39	2.93
9395.00	74.220	3.45	-8.46	-8.46	255.23	-138.93	2.92
9410.00	73.990	3.39	-8.69	-8.69	255.92	-137.56	2.91
9425.00	73.760	3.33	-8.93	-8.93	256.64	-136.27	2.90
9440.00	73.530	3.26	-9.16	-9.16	257.37	-135.06	2.89
9455.00	73.340	3.19	-9.41	-9.41	258.12	-133.92	2.88
9470.00	73.130	3.12	-9.65	-9.65	258.86	-132.87	2.87
9485.00	72.920	3.05	-9.90	-9.90	259.61	-131.90	2.86
9500.00	72.710	2.98	-10.16	-10.16	260.36	-131.00	2.85
9515.00	72.510	2.90	-10.41	-10.41	261.10	-130.18	2.84

9530.00	72.320	2.83	-10.67	-10.67	261.83	-129.44	2.83
9545.00	72.120	2.75	-10.92	-10.92	262.55	-128.78	2.82
9560.00	71.930	2.67	-11.18	-11.18	263.25	-128.18	2.82
9575.00	71.750	2.59	-11.43	-11.43	263.92	-127.66	2.81
9590.00	71.560	2.50	-11.68	-11.68	264.58	-127.20	2.80
9605.00	71.390	2.42	-11.93	-11.93	265.20	-126.82	2.79
9620.00	71.210	2.34	-12.17	-12.17	265.78	-126.49	2.79
9635.00	71.040	2.25	-12.39	-12.39	266.33	-126.23	2.78
9650.00	70.870	2.16	-12.61	-12.61	266.84	-126.02	2.78
9665.00	70.700	2.07	-12.81	-12.81	267.31	-125.88	2.77
9680.00	70.540	1.98	-13.00	-13.00	267.73	-125.78	2.77
9695.00	70.380	1.89	-13.16	-13.16	268.10	-125.73	2.76
9710.00	70.230	1.80	-13.30	-13.30	268.42	-125.72	2.76
9725.00	70.070	1.71	-13.42	-13.42	268.68	-125.76	2.76
9740.00	69.920	1.61	-13.52	-13.52	268.89	-125.82	2.75
9755.00	69.780	1.52	-13.58	-13.58	269.05	-125.93	2.75
9770.00	69.630	1.42	-13.62	-13.62	269.14	-126.06	2.75
9785.00	69.490	1.32	-13.62	-13.62	269.18	-126.21	2.75
9800.00	69.350	1.23	-13.60	-13.60	269.15	-126.38	2.75
9815.00	69.220	1.13	-13.55	-13.55	269.06	-126.57	2.75
9830.00	69.090	1.03	-13.48	-13.48	268.91	-126.77	2.76
9845.00	68.960	0.93	-13.37	-13.37	268.70	-126.97	2.76
9860.00	68.830	0.83	-13.25	-13.25	268.43	-127.17	2.76
9875.00	68.700	0.72	-13.11	-13.11	268.10	-127.38	2.76
9890.00	68.580	0.62	-12.95	-12.95	267.70	-127.57	2.77
9905.00	68.460	0.52	-12.77	-12.77	267.25	-127.75	2.77
9920.00	68.340	0.41	-12.58	-12.58	266.74	-127.92	2.78
9935.00	68.230	0.38	-12.39	-12.39	266.18	-128.06	2.79
9950.00	68.120	0.40	-12.18	-12.18	265.56	-128.18	2.79
9965.00	68.010	0.42	-11.97	-11.97	264.89	-128.28	2.80
9980.00	67.900	0.43	-11.75	-11.75	264.17	-128.35	2.81
9995.00	67.790	0.45	-11.53	-11.53	263.40	-128.38	2.82
10010.00	67.690	0.46	-11.31	-11.31	262.59	-128.37	2.82
10025.00	67.590	0.48	-11.09	-11.09	261.74	-128.33	2.83
10040.00	67.490	0.49	-10.86	-10.86	260.85	-128.24	2.84
10055.00	67.390	0.50	-10.64	-10.64	259.92	-128.11	2.85
10070.00	67.300	0.51	-10.43	-10.43	258.96	-127.93	2.86
10085.00	67.200	0.52	-10.21	-10.21	257.98	-127.70	2.87
10100.00	67.110	0.53	-10.00	-10.00	256.96	-127.43	2.88
10115.00	67.030	0.53	-9.79	-9.79	255.93	-127.10	2.89
10130.00	66.940	0.54	-9.58	-9.58	254.88	-126.71	2.91
10145.00	66.860	0.54	-9.38	-9.38	253.81	-126.28	2.92
10160.00	66.780	0.54	-9.18	-9.18	252.73	-125.78	2.93
10175.00	66.700	0.54	-8.99	-8.99	251.64	-125.23	2.94
10190.00	66.630	0.54	-8.80	-8.80	250.54	-124.53	2.95
10205.00	66.560	0.54	-8.61	-8.61	249.45	-123.96	2.96
10220.00	66.490	0.53	-8.43	-8.43	248.35	-123.24	2.98
10235.00	66.420	0.53	-8.25	-8.25	247.26	-122.46	2.99
10250.00	66.360	0.52	-8.08	-8.08	246.18	-121.63	3.00
10265.00	66.300	0.51	-7.91	-7.91	245.11	-120.74	3.01
10280.00	66.240	0.51	-7.74	-7.74	244.06	-119.79	3.02
10295.00	66.190	0.51	-7.58	-7.58	243.02	-118.78	3.03
10310.00	66.140	0.51	-7.42	-7.42	242.01	-117.72	3.04
10325.00	66.100	0.51	-7.27	-7.27	241.01	-116.61	3.06
10340.00	66.050	0.50	-7.12	-7.12	240.05	-115.44	3.07
10355.00	66.020	0.50	-7.00	-6.97	239.11	-114.23	3.08
10370.00	65.980	0.49	-7.21	-7.21	238.21	-113.06	3.09
10385.00	65.950	0.48	-7.43	-7.43	237.34	-111.84	3.09
10400.00	65.930	0.47	-7.65	-7.65	236.50	-110.27	3.10
10415.00	65.900	0.46	-7.88	-7.88	235.71	-108.86	3.11
10430.00	65.890	0.44	-8.11	-8.11	234.96	-107.39	3.12
10445.00	65.880	0.43	-8.36	-8.36	234.25	-105.89	3.13
10460.00	65.870	0.41	-8.61	-8.61	233.59	-104.34	3.13
10475.00	65.870	0.39	-8.88	-8.88	232.98	-102.75	3.14
10490.00	65.870	0.37	-9.15	-9.15	232.42	-101.13	3.14
10505.00	65.880	0.35	-9.44	-9.44	231.92	-99.46	3.15
10520.00	65.890	0.33	-9.73	-9.73	231.46	-97.76	3.15
10535.00	65.910	0.30	-10.04	-10.04	231.07	-96.02	3.16
10550.00	65.930	0.27	-10.36	-10.36	230.73	-94.26	3.16
10565.00	65.960	0.24	-10.70	-10.70	230.46	-92.46	3.16
10580.00	66.000	0.21	-11.05	-11.05	230.25	-90.63	3.16
10595.00	66.040	0.18	-11.42	-11.42	230.10	-88.78	3.16
10610.00	66.090	0.15	-11.80	-11.80	230.02	-86.90	3.16
10625.00	66.150	0.11	-12.21	-12.21	230.01	-85.00	3.16
10640.00	66.210	0.07	-12.63	-12.63	230.07	-83.08	3.15
10655.00	66.270	0.03	-13.08	-13.08	230.20	-81.14	3.15
10670.00	66.350	-0.01	-13.56	-13.56	230.40	-79.18	3.15
10685.00	66.430	-0.05	-14.06	-14.06	230.68	-77.21	3.14
10700.00	66.520	-0.09	-14.60	-14.60	231.04	-75.23	3.13
10715.00	66.610	-0.14	-15.17	-15.17	231.47	-73.24	3.13
10730.00	66.720	-0.19	-15.78	-15.78	231.99	-71.25	3.12
10745.00	66.830	-0.24	-16.43	-16.43	232.59	-69.24	3.11
10760.00	66.940	-0.29	-17.12	-17.12	233.27	-67.24	3.10
10775.00	67.070	-0.35	-17.87	-17.87	234.04	-65.24	3.08
10790.00	67.200	-0.40	-18.67	-18.67	234.90	-63.24	3.07
10805.00	67.330	-0.46	-19.53	-19.53	235.85	-61.25	3.06
10820.00	67.480	-0.52	-20.52	-20.52	236.89	-59.27	3.04
10835.00	67.630	-0.58	-21.86	-21.86	238.02	-57.30	3.03
10850.00	67.790	-0.65	-23.46	-23.46	239.24	-55.35	3.01
10865.00	67.960	-0.71	-25.42	-25.42	240.57	-53.42	2.99
10880.00	68.130	-0.78	-27.95	-27.95	241.99	-51.51	2.97
10895.00	68.320	-0.85	-31.45	-31.45	243.51	-49.63	2.95
10910.00	68.510	-0.92	-36.66	-36.66	245.14	-47.79	2.93
10925.00	68.700	-1.00	-39.56	-39.56	246.87	-45.97	2.91
10940.00	68.910	-1.07	-33.91	-33.91	248.70	-44.20	2.89
10955.00	69.120	-1.15	-29.55	-29.55	250.64	-42.47	2.86
10970.00	69.330	-1.23	-26.52	-26.52	252.69	-40.80	2.84
10985.00	69.560	-1.31	-24.24	-24.24	254.85	-39.17	2.82
11000.00	69.790	-1.40	-23.62	-23.62	257.13	-37.61	2.79
11015.00	70.030	-1.48	-23.14	-23.14	259.51	-36.12	2.76
11030.00	70.270	-1.57	-23.89	-23.89	262.01	-34.69	2.74
11045.00	70.530	-1.66	-25.43	-25.43	264.63	-33.35	2.71
11060.00	70.780	-1.75	-27.29	-27.29	267.36	-32.09	2.68
11075.00	71.050	-1.85	-29.66	-29.66	270.21	-30.93	2.65
11090.00	71.320	-1.95	-32.91	-32.91	273.18	-29.87	2.62
11105.00	71.600	-2.05	-38.11	-38.11	276.26	-28.92	2.59
11120.00	71.880	-2.15	-50.84	-50.84	279.46	-28.08	2.56
11135.00	72.170	-2.25	-41.51	-41.51	282.79	-27.38	2.53
11150.00	72.470	-2.29	-34.70	-34.70	286.22	-26.81	2.50
11165.00	72.770	-2.23	-30.91	-30.91	289.78	-26.39	2.47
11180.00	73.080	-2.17	-28.28	-28.28	293.44	-26.12	2.44
11195.00	73.390	-2.11	-26.27	-26.27	297.22	-26.03	2.41
11210.00	73.710	-2.06	-24.65	-24.65	301.10	-26.11	2.38
11225.00	74.030	-2.00	-23.29	-23.29	305.09	-26.39	2.35
11240.00	74.360	-1.94	-22.12	-22.12	309.17	-26.87	2.32
11255.00	74.700	-1.89	-21.09	-21.09	313.35	-27.57	2.29
11270.00	75.040	-1.83	-20.17	-20.17	317.61	-28.50	2.26
11285.00	75.380	-1.78	-19.60	-19.60	321.95	-29.68	2.23
11300.00	75.730	-1.72	-19.73	-19.73	326.36	-31.12	2.20
11315.00	76.080	-1.66	-19.81	-19.81	330.82	-32.84	2.17
11330.00	76.440	-1.61	-19.84	-19.84	335.33	-34.84	2.14
11345.00	76.810	-1.55	-19.83	-19.83	339.86	-37.15	2.11
11360.00	77.170	-1.50	-19.77	-19.77	344.41	-39.78	2.08
11375.00	77.550	-1.44	-19.67	-19.67	348.95	-42.74	2.06
11390.00	77.920	-1.38	-19.54	-19.54	353.46	-46.04	2.03
11405.00	78.300	-1.33	-19.36	-19.36	357.92	-49.71	2.01
11420.00	78.690	-1.27	-19.17	-19.17	362.30	-53.75	1.99
11435.00	79.080	-1.22	-18.94	-18.94	366.58	-58.17	1.97
11450.00	79.480	-1.16	-18.70	-18.70	370.72	-62.98	1.95

11465.00	79.880	-1.10	-18.45	-1.10	374.69	-68.18	1.93
11480.00	80.280	-1.04	-18.18	-1.04	378.46	-73.79	1.92
11495.00	80.690	-0.99	-17.91	-0.99	381.99	-79.79	1.90
11510.00	81.100	-0.93	-17.64	-0.93	385.24	-86.20	1.89
11525.00	81.520	-0.87	-17.36	-0.87	388.16	-92.99	1.89
11540.00	81.940	-0.81	-17.09	-0.81	390.72	-100.16	1.88
11555.00	82.360	-0.75	-16.81	-0.75	392.87	-107.70	1.88
11570.00	82.790	-0.69	-16.55	-0.69	394.56	-115.57	1.88
11585.00	83.220	-0.63	-16.28	-0.63	395.76	-123.76	1.88
11600.00	83.660	-0.57	-16.02	-0.57	396.42	-132.22	1.89
11615.00	84.100	-0.51	-15.77	-0.51	396.50	-140.92	1.90
11630.00	84.550	-0.45	-15.52	-0.45	395.96	-149.81	1.92
11645.00	85.000	-0.39	-15.32	-0.39	394.77	-158.84	1.94
11660.00	85.450	-0.33	-16.06	-0.33	392.90	-167.96	1.96
11675.00	85.910	-0.26	-16.88	-0.26	390.33	-177.09	1.99
11690.00	86.370	-0.20	-17.81	-0.20	387.05	-186.17	2.02
11705.00	86.840	-0.14	-18.88	-0.14	383.05	-195.14	2.05
11720.00	87.310	-0.07	-20.12	-0.07	378.34	-203.91	2.10
11735.00	87.780	-0.01	-21.61	-0.01	372.91	-212.42	2.14
11750.00	88.250	0.05	-23.45	0.05	366.80	-220.60	2.19
11765.00	88.720	0.12	-25.84	0.12	360.04	-228.38	2.25
11780.00	89.200	0.18	-29.24	0.18	352.66	-235.68	2.31
11795.00	89.670	0.25	-35.08	0.25	344.72	-242.45	2.37
11810.00	90.150	0.31	-57.98	0.31	336.26	-248.64	2.44
11825.00	90.620	0.38	-35.15	0.38	327.35	-254.20	2.52
11840.00	91.090	0.44	-28.99	0.44	318.06	-259.08	2.60
11855.00	91.560	0.51	-25.35	0.51	308.45	-263.26	2.69
11870.00	92.020	0.57	-22.74	0.57	298.60	-266.73	2.79
11885.00	92.470	0.63	-20.89	0.63	288.57	-269.46	2.89
11900.00	92.910	0.69	-22.17	0.69	278.46	-271.45	2.99
11915.00	93.340	0.75	-23.67	0.75	268.31	-272.72	3.11
11930.00	93.760	0.81	-25.45	0.81	258.21	-273.28	3.22
11945.00	94.160	0.87	-27.61	0.87	248.21	-273.14	3.35
11960.00	94.540	0.93	-30.26	0.93	238.38	-272.34	3.48
11975.00	94.890	0.98	-33.20	0.98	228.76	-270.91	3.62
11990.00	95.220	1.03	-34.73	1.03	219.41	-268.89	3.76
12005.00	95.510	1.08	-32.92	1.08	210.36	-266.32	3.91
12020.00	95.770	1.13	-30.03	1.13	201.65	-263.25	4.06
12035.00	95.990	1.17	-27.51	1.17	193.31	-259.71	4.22
12050.00	96.160	1.20	-25.47	1.20	185.37	-255.75	4.38
12065.00	96.290	1.24	-23.80	1.24	177.83	-251.42	4.55
12080.00	96.370	1.26	-22.41	1.26	170.72	-246.76	4.71
12095.00	96.380	1.29	-21.22	1.29	164.04	-241.82	4.88
12110.00	96.340	1.30	-20.20	1.30	157.80	-236.64	5.05
12125.00	96.240	1.31	-20.87	1.31	151.99	-231.26	5.22
12140.00	96.070	1.32	-21.91	1.32	146.61	-225.71	5.38
12155.00	95.830	1.31	-23.09	1.31	141.66	-220.03	5.54
12170.00	95.520	1.30	-24.44	1.30	137.13	-214.25	5.70
12185.00	95.150	1.28	-25.96	1.28	133.01	-208.41	5.85
12200.00	94.710	1.26	-27.65	1.26	129.29	-202.53	5.99
12215.00	94.210	1.23	-29.30	1.23	125.95	-196.64	6.12
12230.00	93.640	1.18	-30.45	1.18	122.98	-190.76	6.24
12245.00	93.020	1.14	-30.42	1.14	120.36	-184.92	6.35
12260.00	92.340	1.08	-29.25	1.08	118.09	-179.12	6.44
12275.00	91.630	1.02	-27.60	1.02	116.14	-173.40	6.53
12290.00	90.870	0.95	-25.94	0.95	114.49	-167.77	6.60
12305.00	90.080	0.87	-24.43	0.87	113.24	-162.24	6.65
12320.00	89.260	0.79	-23.73	0.79	112.06	-156.82	6.69
12335.00	88.430	0.70	-23.13	0.70	111.24	-151.52	6.72
12350.00	87.590	0.61	-22.50	0.61	110.66	-146.35	6.74
12365.00	86.750	0.51	-21.86	0.51	110.31	-141.33	6.74
12380.00	85.910	0.41	-21.25	0.41	110.17	-136.45	6.73
12395.00	85.080	0.31	-20.66	0.31	110.22	-131.73	6.71
12410.00	84.270	0.21	-20.11	0.21	110.46	-127.17	6.68
12425.00	83.470	0.10	-19.59	0.10	110.86	-122.77	6.64
12440.00	82.700	0.00	-19.13	0.00	111.42	-118.54	6.60
12455.00	81.950	-0.11	-19.44	-0.11	112.11	-114.48	6.55
12470.00	81.240	-0.22	-19.69	-0.22	112.93	-110.59	6.49
12485.00	80.550	-0.32	-19.88	-0.32	113.86	-106.87	6.42
12500.00	79.900	-0.43	-20.01	-0.43	114.89	-103.32	6.36
12515.00	79.280	-0.53	-20.07	-0.53	116.00	-99.94	6.29
12530.00	78.690	-0.63	-20.06	-0.63	117.20	-96.73	6.22
12545.00	78.130	-0.72	-20.00	-0.72	118.45	-93.70	6.14
12560.00	77.610	-0.82	-20.22	-0.82	119.76	-90.83	6.07
12575.00	77.120	-0.91	-21.24	-0.91	121.10	-88.12	6.00
12590.00	76.660	-1.00	-22.28	-1.00	122.48	-85.57	5.92
12605.00	76.230	-1.08	-23.27	-1.08	123.89	-83.19	5.85
12620.00	75.830	-1.16	-24.15	-1.16	125.30	-80.95	5.78
12635.00	75.460	-1.24	-24.81	-1.24	126.72	-78.87	5.71
12650.00	75.110	-1.31	-25.14	-1.31	128.13	-76.93	5.65
12665.00	74.790	-1.38	-25.11	-1.38	129.53	-75.14	5.58
12680.00	74.490	-1.45	-25.18	-1.45	130.91	-73.48	5.52
12695.00	74.210	-1.51	-28.14	-1.51	132.26	-71.95	5.46
12710.00	73.950	-1.57	-32.46	-1.57	133.57	-70.54	5.41
12725.00	73.720	-1.63	-40.74	-1.63	134.84	-69.25	5.35
12740.00	73.500	-1.68	-43.71	-1.68	136.07	-68.07	5.30
12755.00	73.300	-1.73	-33.97	-1.73	137.25	-67.00	5.26
12770.00	73.120	-1.77	-29.51	-1.77	138.36	-66.02	5.21
12785.00	72.950	-1.82	-27.04	-1.82	139.42	-65.14	5.17
12800.00	72.790	-1.86	-28.33	-1.86	140.41	-64.35	5.14
12815.00	72.650	-1.90	-28.19	-1.90	141.34	-63.63	5.10
12830.00	72.530	-1.94	-26.84	-1.94	142.19	-62.98	5.07
12845.00	72.410	-1.97	-25.10	-1.97	142.97	-62.40	5.04
12860.00	72.310	-2.00	-24.28	-2.00	143.68	-61.88	5.02
12875.00	72.210	-2.03	-24.87	-2.03	144.30	-61.41	4.99
12890.00	72.130	-2.06	-25.47	-2.06	144.85	-60.98	4.97
12905.00	72.060	-2.09	-26.04	-2.09	145.33	-60.59	4.96
12920.00	71.990	-2.11	-26.58	-2.11	145.72	-60.23	4.94
12935.00	71.940	-2.14	-27.06	-2.14	146.04	-59.90	4.93
12950.00	71.890	-2.16	-27.80	-2.16	146.28	-59.58	4.92
12965.00	71.850	-2.18	-28.65	-2.18	146.44	-59.28	4.92
12980.00	71.820	-2.20	-29.25	-2.20	146.52	-58.99	4.91
12995.00	71.800	-2.22	-29.47	-2.22	146.54	-58.69	4.91
13010.00	71.790	-2.24	-29.30	-2.24	146.48	-58.39	4.92
13025.00	71.780	-2.26	-28.82	-2.26	146.36	-58.09	4.92
13040.00	71.780	-2.27	-28.13	-2.27	146.16	-57.77	4.93
13055.00	71.780	-2.29	-27.36	-2.29	145.90	-57.43	4.93
13070.00	71.800	-2.31	-26.56	-2.31	145.58	-57.07	4.94
13085.00	71.820	-2.32	-25.84	-2.32	145.21	-56.68	4.96
13100.00	71.840	-2.34	-25.34	-2.34	144.78	-56.27	4.97
13115.00	71.880	-2.35	-24.84	-2.35	144.29	-55.82	4.99
13130.00	71.920	-2.37	-24.35	-2.37	143.76	-55.33	5.00
13145.00	71.960	-2.39	-23.87	-2.39	143.19	-54.81	5.02
13160.00	72.020	-2.40	-23.40	-2.40	142.57	-54.24	5.05
13175.00	72.080	-2.42	-22.95	-2.42	141.92	-53.63	5.07
13190.00	72.150	-2.43	-22.52	-2.43	141.23	-52.97	5.09
13205.00	72.220	-2.45	-22.11	-2.45	140.52	-52.26	5.12
13220.00	72.300	-2.47	-21.71	-2.47	139.77	-51.51	5.14
13235.00	72.390	-2.49	-21.33	-2.49	139.01	-50.70	5.17
13250.00	72.480	-2.51	-20.97	-2.51	138.23	-49.85	5.20
13265.00	72.590	-2.52	-20.63	-2.52	137.43	-48.94	5.23
13280.00	72.700	-2.54	-20.29	-2.54	136.62	-47.98	5.26
13295.00	72.810	-2.57	-19.98	-2.57	135.80	-46.96	5.29
13310.00	72.940	-2.59	-19.67	-2.59	134.98	-45.90	5.32
13325.00	73.070	-2.61	-19.38	-2.61	134.16	-44.78	5.35
13340.00	73.210	-2.63	-19.10	-2.63	133.34	-43.60	5.38
13355.00	73.360	-2.66	-19.37	-2.66	132.53	-42.38	5.41
13370.00	73.510	-2.68	-19.80	-2.68	131.73	-41.10	5.45
13385.00	73.680	-2.71	-20.27	-2.71	130.94	-39.77	5.48



13400.00	73.850	-2.74	-20.77	-2.74	130.16	-38.39	5.51
13415.00	74.030	-2.77	-21.33	-2.77	129.40	-36.96	5.54
13430.00	74.210	-2.80	-21.93	-2.80	128.66	-35.48	5.57
13445.00	74.400	-2.83	-22.59	-2.83	127.94	-33.95	5.60
13460.00	74.610	-2.87	-23.32	-2.87	127.26	-32.38	5.63
13475.00	74.820	-2.90	-24.12	-2.90	126.60	-30.76	5.66
13490.00	75.030	-2.94	-25.03	-2.94	125.96	-29.10	5.69
13505.00	75.260	-2.98	-26.05	-2.98	125.37	-27.40	5.71
13520.00	75.490	-3.02	-27.22	-3.02	124.80	-25.65	5.74
13535.00	75.720	-3.06	-28.57	-3.06	124.28	-23.87	5.76
13550.00	75.970	-3.11	-30.16	-3.11	123.79	-22.05	5.78
13565.00	76.220	-3.15	-32.03	-3.15	123.35	-20.19	5.80
13580.00	76.480	-3.20	-34.22	-3.20	122.94	-18.30	5.82
13595.00	76.740	-3.25	-36.49	-3.25	122.58	-16.37	5.84
13610.00	77.010	-3.30	-37.75	-3.30	122.27	-14.42	5.85
13625.00	77.290	-3.35	-36.76	-3.35	122.00	-12.44	5.86
13640.00	77.570	-3.41	-34.48	-3.41	121.79	-10.43	5.87
13655.00	77.850	-3.46	-32.17	-3.46	121.62	-8.40	5.88
13670.00	78.140	-3.52	-30.16	-3.52	121.51	-6.34	5.88
13685.00	78.430	-3.58	-28.45	-3.58	121.45	-4.26	5.89
13700.00	78.730	-3.65	-26.99	-3.65	121.44	-2.16	5.89
13715.00	79.030	-3.71	-25.71	-3.71	121.48	-0.05	5.89
13730.00	79.330	-3.78	-24.59	-3.78	121.59	2.08	5.88
13745.00	79.630	-3.85	-24.30	-3.85	121.75	4.22	5.87
13760.00	79.930	-3.92	-24.11	-3.92	121.96	6.37	5.86
13775.00	80.240	-3.99	-23.84	-3.99	122.24	8.53	5.85
13790.00	80.540	-4.06	-23.51	-4.06	122.58	10.69	5.83
13805.00	80.840	-4.14	-23.64	-4.14	122.97	12.87	5.82
13820.00	81.150	-4.22	-24.25	-4.22	123.43	15.04	5.80
13835.00	81.450	-4.30	-24.92	-4.30	123.94	17.21	5.77
13850.00	81.750	-4.38	-25.65	-4.38	124.52	19.38	5.75
13865.00	82.040	-4.46	-26.46	-4.46	125.16	21.55	5.72
13880.00	82.330	-4.55	-27.34	-4.55	125.87	23.71	5.69
13895.00	82.620	-4.63	-28.29	-4.63	126.63	25.86	5.65
13910.00	82.910	-4.72	-29.31	-4.72	127.46	27.99	5.62
13925.00	83.190	-4.81	-30.34	-4.81	128.36	30.12	5.58
13940.00	83.460	-4.90	-31.31	-4.90	129.31	32.23	5.54
13955.00	83.730	-4.99	-32.05	-4.99	130.33	34.32	5.50
13970.00	83.990	-5.09	-32.37	-5.09	131.42	36.39	5.46
13985.00	84.250	-5.18	-32.14	-5.18	132.56	38.43	5.41
14000.00	84.500	-5.28	-31.41	-5.28	133.77	40.45	5.36
14015.00	84.740	-5.37	-30.38	-5.37	135.04	42.45	5.31
14030.00	84.970	-5.47	-29.22	-5.47	136.38	44.41	5.26
14045.00	85.200	-5.57	-28.06	-5.57	137.78	46.33	5.21
14060.00	85.420	-5.67	-26.94	-5.67	139.24	48.24	5.16
14075.00	85.630	-5.77	-25.89	-5.77	140.76	50.08	5.11
14090.00	85.830	-5.79	-24.92	-5.87	142.34	51.89	5.05
14105.00	86.020	-5.69	-24.02	-5.97	143.98	53.66	5.00
14120.00	86.210	-5.59	-23.18	-6.07	145.68	55.38	4.94
14135.00	86.380	-5.50	-22.40	-6.17	147.44	57.05	4.88
14150.00	86.540	-5.41	-21.68	-6.27	149.26	58.67	4.82
14165.00	86.700	-5.33	-21.00	-6.37	151.13	60.23	4.77
14180.00	86.850	-5.25	-20.36	-6.47	153.06	61.74	4.71
14195.00	86.980	-5.17	-19.77	-6.57	155.04	63.19	4.65
14210.00	87.110	-5.10	-19.20	-6.67	157.07	64.57	4.59
14225.00	87.230	-5.03	-18.67	-6.77	159.15	65.88	4.53
14240.00	87.340	-4.96	-18.45	-6.87	161.28	67.13	4.47
14255.00	87.440	-4.90	-18.34	-6.97	163.46	68.31	4.42
14270.00	87.530	-4.84	-18.20	-7.07	165.68	69.41	4.36
14285.00	87.610	-4.78	-18.04	-7.16	167.94	70.43	4.30
14300.00	87.680	-4.73	-17.86	-7.26	170.24	71.38	4.24
14315.00	87.740	-4.68	-17.87	-7.35	172.57	72.24	4.19
14330.00	87.790	-4.63	-18.18	-7.45	174.94	73.02	4.13
14345.00	87.840	-4.58	-18.50	-7.54	177.35	73.71	4.08
14360.00	87.870	-4.54	-18.82	-7.63	179.78	74.30	4.02
14375.00	87.900	-4.50	-19.14	-7.71	182.23	74.81	3.97
14390.00	87.910	-4.46	-19.46	-7.80	184.70	75.22	3.92
14405.00	87.920	-4.42	-19.78	-7.88	187.19	75.53	3.87
14420.00	87.920	-4.39	-20.09	-7.96	189.70	75.75	3.81
14435.00	87.910	-4.35	-20.40	-8.04	192.21	75.86	3.77
14450.00	87.890	-4.32	-20.69	-8.11	194.72	75.87	3.72
14465.00	87.870	-4.29	-20.98	-8.19	197.24	75.77	3.67
14480.00	87.840	-4.27	-21.25	-8.25	199.75	75.57	3.62
14495.00	87.790	-4.24	-21.50	-8.32	202.25	75.26	3.58
14510.00	87.740	-4.21	-21.74	-8.38	204.74	74.84	3.53
14525.00	87.690	-4.20	-21.95	-8.44	207.20	74.31	3.49
14540.00	87.620	-4.18	-22.14	-8.50	209.64	73.67	3.45
14555.00	87.550	-4.16	-22.29	-8.55	212.06	72.93	3.41
14570.00	87.470	-4.14	-22.42	-8.59	214.43	72.07	3.37
14585.00	87.380	-4.12	-22.52	-8.64	216.76	71.10	3.33
14600.00	87.280	-4.11	-22.58	-8.67	219.04	70.02	3.30
14615.00	87.180	-4.09	-22.61	-8.71	221.26	68.84	3.26
14630.00	87.070	-4.08	-22.61	-8.74	223.43	67.55	3.23
14645.00	86.950	-4.07	-22.58	-8.76	225.52	66.15	3.20
14660.00	86.830	-4.06	-22.53	-8.78	227.55	64.65	3.17
14675.00	86.700	-4.05	-22.44	-8.79	229.49	63.06	3.14
14690.00	86.560	-4.04	-22.33	-8.80	231.35	61.36	3.12
14705.00	86.410	-4.04	-22.21	-8.80	233.12	59.58	3.09
14720.00	86.260	-4.03	-22.06	-8.80	234.79	57.70	3.07
14735.00	86.100	-4.02	-21.90	-8.79	236.36	55.74	3.05
14750.00	85.930	-4.02	-21.73	-8.78	237.82	53.70	3.03
14765.00	85.760	-4.02	-21.55	-8.76	239.16	51.59	3.01
14780.00	85.580	-4.02	-21.35	-8.74	240.39	49.41	2.99
14795.00	85.390	-4.01	-21.16	-8.71	241.49	47.17	2.98
14810.00	85.190	-4.01	-20.96	-8.67	242.46	44.87	2.96
14825.00	84.990	-4.01	-20.75	-8.63	243.31	42.52	2.95
14840.00	84.780	-4.02	-20.55	-8.59	244.01	40.13	2.94
14855.00	84.570	-4.02	-20.34	-8.54	244.58	37.70	2.93
14870.00	84.350	-4.03	-20.13	-8.49	245.00	35.25	2.93
14885.00	84.120	-4.03	-19.93	-8.42	245.28	32.79	2.92
14900.00	83.880	-4.03	-19.72	-8.35	245.42	30.31	2.92
14915.00	83.640	-4.04	-19.52	-8.28	245.41	27.83	2.92
14930.00	83.390	-4.04	-19.32	-8.20	245.25	25.36	2.92
14945.00	83.140	-4.05	-19.12	-8.12	244.95	22.91	2.92
14960.00	82.870	-4.06	-18.92	-8.04	244.50	20.48	2.93
14975.00	82.600	-4.07	-18.72	-7.95	243.91	18.08	2.93
14990.00	82.330	-4.08	-18.53	-7.86	243.17	15.73	2.94
15005.00	82.050	-4.09	-18.34	-7.76	242.29	13.43	2.95
15020.00	81.770	-4.10	-18.15	-7.66	241.28	11.19	2.96
15035.00	81.470	-4.09	-17.97	-7.56	240.14	9.02	2.98
15050.00	81.170	-4.09	-17.79	-7.45	238.87	6.93	2.99
15065.00	80.870	-3.96	-17.61	-7.34	237.47	4.91	3.01
15080.00	80.560	-3.89	-17.43	-7.23	235.96	2.99	3.03
15095.00	80.240	-3.82	-17.42	-7.12	234.34	1.16	3.05
15110.00	79.920	-3.75	-17.64	-7.00	232.61	-0.56	3.07
15125.00	79.600	-3.67	-17.88	-6.89	230.78	-2.17	3.10
15140.00	79.270	-3.59	-18.12	-6.77	228.86	-3.67	3.12
15155.00	78.930	-3.52	-18.38	-6.65	226.86	-5.05	3.15
15170.00	78.590	-3.44	-18.65	-6.52	224.79	-6.30	3.18
15185.00	78.250	-3.37	-18.93	-6.40	222.65	-7.43	3.21
15200.00	77.910	-3.29	-19.23	-6.28	220.44	-8.43	3.24

# Appendix III

CM File: BESTBOWTIE.NEC  
 CM R-LOADED BOWTIE IN FREE SPACE WITH  
 CM Zo AS AN OPTIMIZATION PARAMETER.  
 CM Antenna in Y-Z plane.  
 CM Run ID: 07022011\_221747  
 CM Fitness function:  
 CM [Min(Eff)+5\*Min(Gmax)]/[|Zo-Maxrin|\*(MaxVSWR-MinVSWR)\*(MaxXin-MinXin)]  
 CM Arm Length = .051 meters  
 CM Bowtie HALF Angle = 39.4 degrees  
 CM Zo = 715 ohms  
 CM Rload = 166.93 ohms  
 CM NOTE: LOADING HAS BEEN REMOVED FOR FS AVG GAIN CALC  
 CM Loaded Seg # = 6/9  
 CM File ID 07032011225840  
 CM Nd = 5, p = 1, j = 35

FREE SPACE BOWTIE \*\*\*WITHOUT LOADING\*\*\*: SUMMARY NEC DATA

F(MHz)	Rad Eff (%)	Fwd Gain (dbi)	Max Gain (dbi)	Min Gain (dbi)	Rin (ohms)	Xin (ohms)	VSWR//715	Avg Pwr Gain**
200.00	100.00	1.96	1.96	1.95	1.59	-804.88	1019.18	1.044
215.00	100.00	1.96	1.96	1.95	1.84	-741.76	805.42	1.044
230.00	100.00	1.97	1.97	1.95	2.12	-686.38	649.43	1.044
245.00	100.00	1.97	1.97	1.95	2.41	-637.33	532.82	1.044
260.00	100.00	1.97	1.97	1.95	2.72	-593.50	443.79	1.044
275.00	100.00	1.97	1.97	1.95	3.06	-554.03	374.56	1.044
290.00	100.00	1.98	1.98	1.95	3.41	-518.25	319.81	1.044
305.00	100.00	1.98	1.98	1.95	3.79	-485.62	275.88	1.044
320.00	100.00	1.98	1.98	1.95	4.19	-455.67	240.16	1.044
335.00	100.00	1.99	1.99	1.95	4.61	-428.06	210.76	1.044
350.00	100.00	1.99	1.99	1.95	5.05	-402.47	186.32	1.044
365.00	100.00	1.99	1.99	1.95	5.52	-378.66	165.78	1.044
380.00	100.00	2.00	2.00	1.94	6.02	-356.41	148.38	1.044
395.00	100.00	2.00	2.00	1.94	6.53	-335.54	133.52	1.044
410.00	100.00	2.01	2.01	1.94	7.08	-315.91	120.72	1.044
425.00	100.00	2.01	2.01	1.94	7.65	-297.36	109.64	1.044
440.00	100.00	2.02	2.02	1.94	8.25	-279.78	99.97	1.044
455.00	100.00	2.02	2.02	1.94	8.87	-263.08	91.49	1.044
470.00	100.00	2.03	2.03	1.94	9.53	-247.18	84.01	1.044
485.00	100.00	2.03	2.03	1.94	10.21	-231.98	77.38	1.044
500.00	100.00	2.04	2.04	1.94	10.93	-217.43	71.48	1.044
515.00	100.00	2.04	2.04	1.94	11.68	-203.47	66.20	1.044
530.00	100.00	2.05	2.05	1.94	12.46	-190.04	61.46	1.044
545.00	100.00	2.05	2.05	1.94	13.27	-177.09	57.19	1.045
560.00	100.00	2.06	2.06	1.94	14.12	-164.59	53.33	1.045
575.00	100.00	2.07	2.07	1.94	15.00	-152.49	49.83	1.045
590.00	100.00	2.07	2.07	1.94	15.92	-140.76	46.64	1.045
605.00	100.00	2.08	2.08	1.94	16.89	-129.36	43.73	1.045
620.00	100.00	2.09	2.09	1.94	17.89	-118.28	41.07	1.045
635.00	100.00	2.09	2.09	1.94	18.93	-107.49	38.62	1.045
650.00	100.00	2.10	2.10	1.94	20.02	-96.95	36.37	1.045
665.00	100.00	2.11	2.11	1.94	21.15	-86.65	34.30	1.045
680.00	100.00	2.12	2.12	1.94	22.33	-76.57	32.39	1.045
695.00	100.00	2.13	2.13	1.93	23.56	-66.69	30.62	1.045
710.00	100.00	2.13	2.13	1.93	24.84	-56.99	28.97	1.045
725.00	100.00	2.14	2.14	1.93	26.17	-47.46	27.44	1.045
740.00	100.00	2.15	2.15	1.93	27.55	-38.08	26.02	1.045
755.00	100.00	2.16	2.16	1.93	29.00	-28.85	24.70	1.045
770.00	100.00	2.17	2.17	1.93	30.50	-19.74	23.46	1.045
785.00	100.00	2.18	2.18	1.93	32.07	-10.74	22.30	1.045
800.00	100.00	2.19	2.19	1.93	33.70	-1.85	21.22	1.045
815.00	100.00	2.20	2.20	1.93	35.39	6.96	20.20	1.045
830.00	100.00	2.21	2.21	1.93	37.16	15.67	19.25	1.045
845.00	100.00	2.22	2.22	1.93	39.01	24.30	18.35	1.045
860.00	100.00	2.23	2.23	1.92	40.93	32.87	17.50	1.045
875.00	100.00	2.25	2.25	1.92	42.94	41.39	16.71	1.045
890.00	100.00	2.26	2.26	1.92	45.03	49.85	15.96	1.045
905.00	100.00	2.27	2.27	1.92	47.21	58.27	15.25	1.045
920.00	100.00	2.28	2.28	1.92	49.48	66.66	14.58	1.045
935.00	100.00	2.29	2.29	1.92	51.85	75.02	13.94	1.046
950.00	100.00	2.31	2.31	1.92	54.33	83.35	13.34	1.046
965.00	100.00	2.32	2.32	1.92	56.92	91.67	12.77	1.046
980.00	100.00	2.33	2.33	1.91	59.62	99.99	12.23	1.046
995.00	100.00	2.35	2.35	1.91	62.44	108.30	11.72	1.046
1010.00	100.00	2.36	2.36	1.91	65.39	116.61	11.23	1.046
1025.00	100.00	2.38	2.38	1.91	68.47	124.93	10.76	1.046
1040.00	100.00	2.39	2.39	1.91	71.69	133.27	10.32	1.046
1055.00	100.00	2.41	2.41	1.91	75.06	141.62	9.90	1.046
1070.00	100.00	2.42	2.42	1.90	78.59	149.99	9.50	1.046
1085.00	100.00	2.44	2.44	1.90	82.29	158.40	9.12	1.046
1100.00	100.00	2.45	2.45	1.90	86.16	166.83	8.76	1.046
1115.00	100.00	2.47	2.47	1.90	90.21	175.30	8.41	1.046
1130.00	100.00	2.49	2.49	1.89	94.47	183.81	8.08	1.046
1145.00	100.00	2.51	2.51	1.89	98.93	192.37	7.76	1.046
1160.00	100.00	2.52	2.52	1.89	103.61	200.97	7.46	1.046
1175.00	100.00	2.54	2.54	1.89	108.52	209.62	7.17	1.047
1190.00	100.00	2.56	2.56	1.88	113.69	218.32	6.89	1.047
1205.00	100.00	2.58	2.58	1.88	119.12	227.08	6.62	1.047
1220.00	100.00	2.60	2.60	1.88	124.82	235.89	6.37	1.047
1235.00	100.00	2.62	2.62	1.88	130.85	244.77	6.12	1.047
1250.00	100.00	2.64	2.64	1.87	137.17	253.70	5.89	1.047
1265.00	100.00	2.66	2.66	1.87	143.84	262.68	5.67	1.047
1280.00	100.00	2.68	2.68	1.87	150.86	271.72	5.45	1.047
1295.00	100.00	2.71	2.71	1.86	158.28	280.81	5.24	1.047
1310.00	100.00	2.73	2.73	1.86	166.10	289.95	5.05	1.047
1325.00	100.00	2.75	2.75	1.85	174.36	299.13	4.86	1.047
1340.00	100.00	2.78	2.78	1.85	183.09	308.35	4.67	1.047
1355.00	100.00	2.80	2.80	1.85	192.32	317.60	4.50	1.048
1370.00	100.00	2.82	2.82	1.84	202.09	326.87	4.33	1.048
1385.00	100.00	2.85	2.85	1.84	212.44	336.14	4.17	1.048
1400.00	100.00	2.88	2.88	1.83	223.40	345.39	4.01	1.048
1415.00	100.00	2.90	2.90	1.83	235.01	354.62	3.86	1.048
1430.00	100.00	2.93	2.93	1.82	247.33	363.78	3.72	1.048
1445.00	100.00	2.96	2.96	1.82	260.40	372.85	3.58	1.048
1460.00	100.00	2.99	2.99	1.81	274.28	381.80	3.44	1.048
1475.00	100.00	3.02	3.02	1.81	289.03	390.59	3.31	1.049
1490.00	100.00	3.05	3.05	1.80	304.69	399.15	3.19	1.049
1505.00	100.00	3.08	3.08	1.79	321.34	407.44	3.07	1.049
1520.00	100.00	3.11	3.11	1.79	339.04	415.38	2.96	1.049
1535.00	100.00	3.14	3.14	1.78	357.85	422.90	2.85	1.049
1550.00	100.00	3.17	3.17	1.77	377.85	429.88	2.74	1.049
1565.00	100.00	3.21	3.21	1.77	399.10	436.23	2.64	1.049
1580.00	100.00	3.24	3.24	1.76	421.66	441.80	2.54	1.050
1595.00	100.00	3.28	3.28	1.75	445.60	446.45	2.44	1.050
1610.00	100.00	3.31	3.31	1.74	470.97	450.00	2.35	1.050
1625.00	100.00	3.35	3.35	1.73	497.82	452.24	2.27	1.050
1640.00	100.00	3.39	3.39	1.72	526.17	452.95	2.18	1.050
1655.00	100.00	3.43	3.43	1.71	556.02	451.86	2.10	1.051
1670.00	100.00	3.47	3.47	1.70	587.35	448.67	2.02	1.051
1685.00	100.00	3.51	3.51	1.69	620.08	443.06	1.95	1.051
1700.00	100.00	3.56	3.56	1.68	654.10	434.68	1.88	1.051
1715.00	100.00	3.60	3.60	1.67	689.22	423.14	1.81	1.051
1730.00	100.00	3.64	3.64	1.66	725.17	408.05	1.75	1.052
1745.00	100.00	3.69	3.69	1.65	761.60	389.02	1.69	1.052

1760.00	100.00	3.74	3.74	1.63	798.05	365.65	1.63	1.052
1775.00	100.00	3.79	3.79	1.62	833.93	337.62	1.58	1.053
1790.00	100.00	3.84	3.84	1.60	868.54	304.66	1.54	1.053
1805.00	100.00	3.89	3.89	1.59	901.06	266.62	1.50	1.053
1820.00	100.00	3.94	3.94	1.57	930.58	223.50	1.46	1.053
1835.00	100.00	4.00	4.00	1.56	956.12	175.51	1.43	1.054
1850.00	100.00	4.06	4.06	1.54	976.68	123.08	1.41	1.054
1865.00	100.00	4.12	4.12	1.52	991.29	66.89	1.40	1.054
1880.00	100.00	4.18	4.18	1.50	999.13	7.87	1.40	1.055
1895.00	100.00	4.24	4.24	1.48	999.55	-52.82	1.41	1.055
1910.00	100.00	4.30	4.30	1.45	992.20	-113.88	1.42	1.056
1925.00	100.00	4.37	4.37	1.43	977.00	-173.91	1.45	1.056
1940.00	100.00	4.44	4.44	1.40	954.25	-231.50	1.49	1.057
1955.00	100.00	4.51	4.51	1.38	924.54	-285.38	1.54	1.057
1970.00	100.00	4.58	4.58	1.35	888.73	-334.45	1.60	1.058
1985.00	100.00	4.66	4.66	1.32	847.89	-377.88	1.66	1.058
2000.00	100.00	4.74	4.74	1.29	803.19	-415.11	1.74	1.059
2015.00	100.00	4.82	4.82	1.25	755.82	-445.79	1.82	1.059
2030.00	100.00	4.91	4.91	1.21	706.95	-470.04	1.92	1.060
2045.00	100.00	5.00	5.00	1.17	657.60	-488.10	2.02	1.061
2060.00	100.00	5.09	5.09	1.13	608.67	-500.35	2.13	1.062
2075.00	100.00	5.19	5.19	1.08	560.87	-507.29	2.26	1.063
2090.00	100.00	5.29	5.29	1.03	514.78	-509.49	2.40	1.064
2105.00	100.00	5.39	5.39	0.98	470.79	-507.54	2.55	1.065
2120.00	100.00	5.50	5.50	0.92	429.20	-502.02	2.72	1.066
2135.00	100.00	5.61	5.61	0.86	390.16	-493.48	2.91	1.067
2150.00	100.00	5.73	5.73	0.79	353.74	-482.42	3.12	1.069
2165.00	100.00	5.85	5.85	0.71	319.95	-469.31	3.35	1.070
2180.00	100.00	5.98	5.98	0.62	288.73	-454.54	3.60	1.071
2195.00	100.00	6.11	6.11	0.53	260.01	-438.46	3.89	1.073
2210.00	100.00	6.25	6.25	0.42	233.65	-421.36	4.21	1.075
2225.00	100.00	6.39	6.39	0.30	209.55	-403.50	4.57	1.076
2240.00	100.00	6.54	6.54	0.17	187.58	-385.08	4.98	1.078
2255.00	100.00	6.70	6.70	0.02	167.53	-366.28	5.44	1.080
2270.00	100.00	6.86	6.86	-0.14	149.34	-347.24	5.96	1.083
2285.00	100.00	7.03	7.03	-0.34	132.86	-328.06	6.55	1.085
2300.00	100.00	7.21	7.21	-0.56	117.96	-308.86	7.22	1.088
2315.00	100.00	7.39	7.39	-0.81	104.52	-289.69	7.98	1.091
2330.00	100.00	7.58	7.58	-1.11	92.44	-270.62	8.86	1.094
2345.00	100.00	7.77	7.77	-1.45	81.61	-251.69	9.86	1.097
2360.00	100.00	7.97	7.97	-1.86	71.95	-232.93	11.00	1.101
2375.00	100.00	8.16	8.16	-2.35	63.38	-214.38	12.30	1.105
2390.00	100.00	8.35	8.35	-2.93	55.80	-196.04	13.78	1.109
2405.00	100.00	8.53	8.53	-3.64	49.17	-177.92	15.45	1.113
2420.00	100.00	8.70	8.70	-4.50	43.42	-160.05	17.30	1.118
2435.00	100.00	8.85	8.85	-5.54	38.48	-142.42	19.32	1.122
2450.00	100.00	8.96	8.96	-6.77	34.32	-125.03	21.47	1.125
2465.00	100.00	9.02	9.02	-8.12	30.89	-107.88	23.67	1.128
2480.00	100.00	9.01	9.01	-9.28	28.16	-90.97	25.80	1.130
2495.00	100.00	8.93	8.93	-9.95	26.08	-74.30	27.71	1.130
2510.00	100.00	8.75	8.75	-10.62	24.63	-57.86	29.21	1.128
2525.00	100.00	8.46	8.46	-11.63	23.79	-41.65	30.16	1.124
2540.00	100.00	8.05	8.05	-13.21	23.53	-25.66	30.43	1.119
2555.00	100.00	7.52	7.52	-15.02	23.83	-9.89	30.01	1.111
2570.00	100.00	6.88	6.88	-15.59	24.68	5.66	28.97	1.103
2585.00	100.00	6.13	6.13	-20.71	26.06	21.00	27.46	1.095
2600.00	100.00	5.29	5.29	-19.50	27.97	36.13	25.63	1.086
2615.00	100.00	4.37	4.37	-31.38	30.39	51.05	23.65	1.079
2630.00	100.00	3.38	3.38	-20.97	33.32	65.77	21.64	1.072
2645.00	100.00	2.33	2.33	-25.03	36.75	80.28	19.70	1.066
2660.00	100.00	1.23	1.23	-18.31	40.69	94.58	17.88	1.061
2675.00	100.00	0.09	1.45	-19.34	45.12	108.66	16.21	1.057
2690.00	100.00	-1.10	1.65	-19.63	50.06	122.53	14.71	1.054
2705.00	100.00	-2.33	1.80	-16.35	55.49	136.18	13.35	1.051
2720.00	100.00	-3.60	1.92	-14.71	61.43	149.59	12.15	1.049
2735.00	100.00	-4.90	2.02	-14.49	67.88	162.76	11.08	1.047
2750.00	100.00	-6.22	2.09	-13.57	74.84	175.68	10.14	1.045
2765.00	100.00	-7.53	2.15	-13.26	82.31	188.34	9.30	1.044
2780.00	100.00	-8.76	2.20	-12.61	90.30	200.71	8.55	1.043
2795.00	100.00	-9.88	2.24	-12.37	98.81	212.78	7.89	1.043
2810.00	100.00	-10.73	2.27	-11.95	107.85	224.53	7.30	1.042
2825.00	100.00	-11.23	2.29	-11.65	117.41	235.94	6.77	1.042
2840.00	100.00	-11.35	2.31	-11.39	127.51	246.98	6.30	1.042
2855.00	100.00	-11.13	2.32	-11.13	138.14	257.63	5.87	1.042
2870.00	100.00	-10.70	2.32	-10.70	149.31	267.82	5.49	1.042
2885.00	100.00	-10.14	2.32	-10.14	161.00	277.62	5.14	1.042
2900.00	100.00	-9.53	2.33	-9.53	173.22	286.89	4.83	1.042
2915.00	100.00	-8.93	2.33	-8.93	185.96	295.63	4.54	1.042
2930.00	100.00	-8.35	2.33	-8.35	199.21	303.81	4.28	1.042
2945.00	100.00	-7.81	2.32	-7.81	212.96	311.38	4.04	1.042
2960.00	100.00	-7.30	2.32	-7.30	227.18	318.30	3.83	1.042
2975.00	100.00	-6.83	2.31	-6.83	241.86	324.52	3.63	1.042
2990.00	100.00	-6.40	2.30	-6.40	256.97	330.00	3.44	1.043
3005.00	100.00	-6.01	2.29	-6.01	272.48	334.69	3.27	1.043
3020.00	100.00	-5.64	2.28	-5.64	288.35	338.56	3.12	1.043
3035.00	100.00	-5.30	2.27	-5.30	304.54	341.55	2.97	1.043
3050.00	100.00	-4.99	2.26	-4.99	321.00	343.62	2.84	1.044
3065.00	100.00	-4.69	2.25	-4.69	337.67	344.73	2.71	1.044
3080.00	100.00	-4.42	2.23	-4.42	354.49	344.84	2.60	1.044
3095.00	100.00	-4.17	2.22	-4.17	371.40	343.93	2.49	1.045
3110.00	100.00	-3.93	2.20	-3.93	388.32	341.96	2.39	1.045
3125.00	100.00	-3.71	2.19	-3.71	405.16	338.90	2.29	1.045
3140.00	100.00	-3.50	2.17	-3.50	421.86	334.76	2.20	1.046
3155.00	100.00	-3.30	2.16	-3.30	438.34	329.52	2.12	1.046
3170.00	100.00	-3.12	2.14	-3.12	454.43	323.18	2.04	1.046
3185.00	100.00	-2.94	2.12	-2.94	470.12	315.76	1.97	1.047
3200.00	100.00	-2.78	2.10	-2.78	485.29	307.28	1.90	1.047
3215.00	100.00	-2.62	2.09	-2.62	499.84	297.78	1.83	1.047
3230.00	100.00	-2.47	2.07	-2.47	513.68	287.29	1.77	1.048
3245.00	100.00	-2.33	2.05	-2.33	526.73	275.87	1.71	1.048
3260.00	100.00	-2.19	2.03	-2.19	538.89	263.60	1.66	1.048
3275.00	100.00	-2.06	2.01	-2.06	550.10	250.54	1.61	1.049
3290.00	100.00	-1.94	1.99	-1.94	560.28	236.78	1.56	1.049
3305.00	100.00	-1.82	1.96	-1.82	569.38	222.42	1.51	1.049
3320.00	100.00	-1.71	1.94	-1.71	577.34	207.54	1.47	1.050
3335.00	100.00	-1.60	1.92	-1.60	584.13	192.26	1.43	1.050
3350.00	100.00	-1.49	1.89	-1.49	589.73	176.68	1.39	1.050
3365.00	100.00	-1.39	1.87	-1.39	594.12	160.92	1.36	1.051
3380.00	100.00	-1.30	1.85	-1.30	597.29	145.06	1.33	1.051
3395.00	100.00	-1.20	1.82	-1.20	599.27	129.24	1.30	1.051
3410.00	100.00	-1.11	1.79	-1.11	600.07	113.54	1.28	1.052
3425.00	100.00	-1.03	1.79	-1.03	599.72	98.07	1.26	1.052
3440.00	100.00	-0.95	1.74	-0.95	598.26	82.92	1.24	1.053
3455.00	100.00	-0.87	1.71	-0.87	595.76	68.17	1.23	1.053
3470.00	100.00	-0.79	1.68	-0.79	592.25	53.90	1.23	1.053
3485.00	100.00	-0.72	1.65	-0.72	587.81	40.19	1.23	1.054
3500.00	100.00	-0.64	1.62	-0.64	582.50	27.09	1.23	1.054
3515.00	100.00	-0.58	1.58	-0.58	576.40	14.65	1.24	1.054
3530.00	100.00	-0.51	1.55	-0.51	569.57	2.93	1.26	1.055
3545.00	100.00	-0.45	1.52	-0.45	562.10	-8.06	1.27	1.055
3560.00	100.00	-0.39	1.48	-0.39	554.04	-18.27	1.29	1.056
3575.00	100.00	-0.33	1.44	-0.33	545.49	-27.69	1.32	1.056
3590.00	100.00	-0.27	1.41	-0.27	536.51	-36.31	1.34	1.056
3605.00	100.00	-0.22	1.37	-0.22	527.17	-44.13	1.37	1.057
3620.00	100.00	-0.17	1.33	-0.17	517.53	-51.13	1.40	1.057
3635.00	100.00	-0.12	1.29	-0.12	507.66	-57.33	1.43	1.058
3650.00	100.00	-0.08	1.25	-0.08	497.62	-62.74	1.46	1.058
3665.00	100.00	-0.03	1.21	-0.03	487.46	-67.37	1.49	1.058
3680.00	100.00	0.01	1.17	0.01	477.23	-71.		

3695.00	100.00	0.04	1.13	0.04	466.99	-74.35	1.56	1.059
3710.00	100.00	0.08	1.09	0.08	456.78	-76.74	1.60	1.060
3725.00	100.00	0.11	1.03	0.11	446.63	-78.44	1.63	1.060
3740.00	100.00	0.14	1.02	0.14	436.60	-79.46	1.67	1.060
3755.00	100.00	0.16	0.98	0.16	426.70	-79.82	1.71	1.061
3770.00	100.00	0.18	0.94	0.18	416.97	-79.56	1.75	1.061
3785.00	100.00	0.20	0.90	0.20	407.45	-78.70	1.79	1.061
3800.00	100.00	0.21	0.86	0.21	398.15	-77.27	1.83	1.062
3815.00	100.00	0.22	0.82	0.22	389.10	-75.28	1.87	1.062
3830.00	100.00	0.23	0.78	0.23	380.32	-73.77	1.91	1.063
3845.00	100.00	0.23	0.74	0.23	371.82	-69.76	1.95	1.063
3860.00	100.00	0.22	0.70	0.22	363.64	-66.28	1.99	1.063
3875.00	100.00	0.22	0.65	0.22	355.77	-62.34	2.03	1.063
3890.00	100.00	0.20	0.61	0.20	348.24	-57.97	2.07	1.064
3905.00	100.00	0.18	0.58	0.18	341.05	-53.19	2.11	1.064
3920.00	100.00	0.15	0.56	0.15	334.23	-48.03	2.15	1.064
3935.00	100.00	0.12	0.54	0.12	327.78	-42.50	2.19	1.064
3950.00	100.00	0.08	0.53	0.08	321.71	-36.63	2.23	1.065
3965.00	100.00	0.04	0.53	0.04	316.03	-30.43	2.27	1.065
3980.00	100.00	-0.02	0.53	-0.02	310.75	-23.92	2.30	1.065
3995.00	100.00	-0.08	0.54	-0.08	305.89	-17.13	2.34	1.065
4010.00	100.00	-0.15	0.56	-0.15	301.44	-10.06	2.37	1.065
4025.00	100.00	-0.23	0.59	-0.24	297.43	-2.74	2.40	1.065
4040.00	100.00	-0.32	0.62	-0.33	293.85	4.81	2.43	1.065
4055.00	100.00	-0.42	0.67	-0.44	290.72	12.57	2.46	1.065
4070.00	100.00	-0.53	0.72	-0.56	288.05	20.54	2.48	1.065
4085.00	100.00	-0.65	0.79	-0.69	285.84	28.68	2.51	1.065
4100.00	100.00	-0.78	0.86	-0.83	284.11	36.99	2.52	1.065
4115.00	100.00	-0.93	0.94	-0.97	282.86	45.44	2.54	1.064
4130.00	100.00	-1.08	1.04	-1.13	282.11	54.01	2.55	1.064
4145.00	100.00	-1.25	1.14	-1.30	281.86	62.69	2.56	1.064
4160.00	100.00	-1.43	1.24	-1.49	282.12	71.45	2.56	1.063
4175.00	100.00	-1.63	1.36	-1.69	282.90	80.27	2.57	1.063
4190.00	100.00	-1.84	1.47	-1.89	284.22	89.13	2.56	1.063
4205.00	100.00	-2.06	1.60	-2.11	286.08	98.00	2.55	1.062
4220.00	100.00	-2.30	1.73	-2.35	288.49	106.86	2.54	1.062
4235.00	100.00	-2.55	1.86	-2.59	291.47	115.68	2.53	1.061
4250.00	100.00	-2.81	1.99	-2.85	295.01	124.43	2.51	1.061
4265.00	100.00	-3.09	2.12	-3.13	299.13	133.09	2.49	1.060
4280.00	100.00	-3.39	2.26	-3.42	303.83	141.61	2.46	1.060
4295.00	100.00	-3.70	2.39	-3.72	309.12	149.98	2.44	1.059
4310.00	100.00	-4.02	2.52	-4.03	315.00	158.14	2.41	1.059
4325.00	100.00	-4.36	2.65	-4.37	321.48	166.06	2.37	1.058
4340.00	100.00	-4.71	2.78	-4.72	328.55	173.71	2.34	1.057
4355.00	100.00	-5.08	2.91	-5.08	336.21	181.03	2.30	1.057
4370.00	100.00	-5.46	3.03	-5.46	344.45	187.99	2.26	1.056
4385.00	100.00	-5.85	3.15	-5.85	353.28	194.54	2.22	1.056
4400.00	100.00	-6.26	3.26	-6.26	362.67	200.63	2.17	1.055
4415.00	100.00	-6.67	3.37	-6.67	372.60	206.21	2.13	1.055
4430.00	100.00	-7.10	3.48	-7.10	383.06	211.24	2.09	1.054
4445.00	100.00	-7.53	3.58	-7.53	394.02	215.66	2.04	1.054
4460.00	100.00	-7.98	3.67	-7.98	405.45	219.43	2.00	1.054
4475.00	100.00	-8.42	3.77	-8.42	417.31	222.49	1.95	1.053
4490.00	100.00	-8.87	3.86	-8.87	429.56	224.79	1.90	1.053
4505.00	100.00	-9.32	3.94	-9.32	442.15	226.30	1.86	1.053
4520.00	100.00	-9.76	4.02	-9.76	455.02	226.96	1.82	1.052
4535.00	100.00	-10.19	4.10	-10.19	468.11	226.74	1.77	1.052
4550.00	100.00	-10.61	4.17	-10.61	481.35	225.60	1.73	1.052
4565.00	100.00	-11.01	4.24	-11.01	494.68	223.52	1.69	1.052
4580.00	100.00	-11.39	4.31	-11.39	508.01	220.46	1.64	1.052
4595.00	100.00	-11.73	4.37	-11.73	521.27	216.43	1.60	1.052
4610.00	100.00	-12.04	4.43	-12.04	534.36	211.40	1.56	1.051
4625.00	100.00	-12.30	4.49	-12.30	547.30	205.39	1.52	1.051
4640.00	100.00	-12.52	4.54	-12.52	559.70	198.40	1.49	1.051
4655.00	100.00	-12.68	4.59	-12.68	571.76	190.46	1.45	1.051
4670.00	100.00	-12.80	4.64	-12.80	583.32	181.60	1.41	1.051
4685.00	100.00	-12.87	4.69	-12.87	594.26	171.86	1.38	1.051
4700.00	100.00	-12.89	4.73	-12.89	604.53	161.30	1.34	1.051
4715.00	100.00	-12.87	4.78	-12.87	614.04	149.97	1.31	1.051
4730.00	100.00	-12.81	4.82	-12.81	622.72	137.94	1.28	1.052
4745.00	100.00	-12.72	4.86	-12.72	630.51	125.30	1.25	1.052
4760.00	100.00	-12.60	4.89	-12.60	637.36	112.12	1.22	1.052
4775.00	100.00	-12.47	4.93	-12.47	643.24	98.50	1.20	1.052
4790.00	100.00	-12.31	4.96	-12.31	648.10	84.52	1.17	1.052
4805.00	100.00	-12.15	4.99	-12.15	651.94	70.28	1.15	1.052
4820.00	100.00	-11.98	5.02	-11.98	654.74	55.87	1.13	1.052
4835.00	100.00	-11.80	5.05	-11.80	656.50	41.40	1.11	1.053
4850.00	100.00	-11.63	5.08	-11.63	657.23	26.94	1.10	1.053
4865.00	100.00	-11.45	5.10	-11.45	656.96	12.58	1.09	1.053
4880.00	100.00	-11.28	5.13	-11.28	655.71	-1.58	1.09	1.053
4895.00	100.00	-11.11	5.15	-11.11	653.52	-15.49	1.10	1.054
4910.00	100.00	-10.95	5.18	-10.95	650.44	-29.05	1.11	1.054
4925.00	100.00	-10.79	5.20	-10.79	646.51	-42.22	1.13	1.054
4940.00	100.00	-10.64	5.22	-10.64	641.79	-54.94	1.14	1.055
4955.00	100.00	-10.49	5.24	-10.49	636.33	-67.15	1.17	1.055
4970.00	100.00	-10.36	5.26	-10.36	630.19	-78.81	1.19	1.055
4985.00	100.00	-10.23	5.28	-10.23	623.43	-89.90	1.21	1.056
5000.00	100.00	-10.10	5.29	-10.10	616.11	-100.38	1.24	1.056
5015.00	100.00	-9.99	5.31	-9.99	608.30	-110.23	1.26	1.056
5030.00	100.00	-9.88	5.32	-9.88	600.04	-119.44	1.29	1.057
5045.00	100.00	-9.78	5.34	-9.78	591.41	-128.00	1.31	1.057
5060.00	100.00	-9.68	5.35	-9.68	582.45	-135.91	1.34	1.057
5075.00	100.00	-9.60	5.36	-9.60	573.21	-143.16	1.37	1.058
5090.00	100.00	-9.52	5.38	-9.52	563.74	-149.76	1.40	1.058
5105.00	100.00	-9.44	5.39	-9.44	554.10	-155.72	1.42	1.059
5120.00	100.00	-9.38	5.40	-9.38	544.32	-161.04	1.45	1.059
5135.00	100.00	-9.32	5.41	-9.32	534.45	-165.76	1.48	1.059
5150.00	100.00	-9.27	5.42	-9.27	524.52	-169.86	1.51	1.060
5165.00	100.00	-9.23	5.42	-9.22	514.57	-173.39	1.54	1.060
5180.00	100.00	-9.18	5.43	-9.18	504.62	-176.35	1.57	1.061
5195.00	100.00	-9.15	5.43	-9.15	494.71	-178.76	1.60	1.061
5210.00	100.00	-9.12	5.44	-9.12	484.86	-180.64	1.64	1.062
5225.00	100.00	-9.10	5.44	-9.10	475.10	-182.02	1.67	1.062
5240.00	100.00	-9.08	5.44	-9.08	465.44	-182.90	1.70	1.063
5255.00	100.00	-9.07	5.45	-9.07	455.90	-183.32	1.73	1.063
5270.00	100.00	-9.06	5.45	-9.06	446.50	-183.30	1.76	1.064
5285.00	100.00	-9.06	5.44	-9.06	437.26	-182.84	1.80	1.064
5300.00	100.00	-9.06	5.44	-9.06	428.18	-181.97	1.83	1.065
5315.00	100.00	-9.07	5.44	-9.07	419.27	-180.72	1.86	1.065
5330.00	100.00	-9.08	5.43	-9.08	410.56	-179.08	1.90	1.066
5345.00	100.00	-9.10	5.43	-9.10	402.03	-177.10	1.93	1.066
5360.00	100.00	-9.12	5.42	-9.12	393.71	-174.77	1.97	1.067
5375.00	100.00	-9.14	5.41	-9.14	385.60	-172.11	2.00	1.067
5390.00	100.00	-9.17	5.40	-9.17	377.69	-169.15	2.04	1.068
5405.00	100.00	-9.20	5.39	-9.20	370.01	-165.89	2.07	1.068
5420.00	100.00	-9.23	5.37	-9.23	362.54	-162.35	2.11	1.069
5435.00	100.00	-9.26	5.36	-9.26	355.30	-158.53	2.14	1.069
5450.00	100.00	-9.28	5.35	-9.28	348.28	-154.46	2.18	1.070
5465.00	100.00	-9.31	5.33	-9.31	341.49	-150.14	2.21	1.070
5480.00	100.00	-9.34	5.31	-9.34	334.94	-145.58	2.25	1.071
5495.00	100.00	-9.36	5.29	-9.36	328.61	-140.79	2.28	1.071
5510.00	100.00	-9.38	5.27	-9.38	322.52	-135.79	2.32	1.072
5525.00	100.00	-9.39	5.25	-9.39	316.66	-130.57	2.35	1.072
5540.00	100.00	-9.39	5.22	-9.39	311.03	-125.15	2.38	1.072
5555.00	100.00	-9.38	5.20	-9.38	305.65	-119.54	2.42	1.073
5570.00	100.00	-9.36	5.17	-9.36	300.50	-113.73	2.45	1.073
5585.00	100.00	-9.33	5.13	-9.33	295.60	-107.74	2.48	1.074
5600.00	100.00	-9.28	5.09	-9.29	290.93	-101.58	2.52	1.074
5615.00	100.00	-9.22	5.06	-9				

5630.00	100.00	-9.14	5.02	-9.25	282.34	-88.74	2.58	1.075
5645.00	100.00	-9.04	4.98	-9.21	278.41	-82.08	2.61	1.075
5660.00	100.00	-8.93	4.93	-9.14	274.74	-75.26	2.64	1.076
5675.00	100.00	-8.79	4.88	-9.16	271.31	-68.29	2.66	1.076
5690.00	100.00	-8.63	4.82	-9.22	268.14	-61.16	2.69	1.076
5705.00	100.00	-8.46	4.76	-9.27	265.24	-53.89	2.71	1.076
5720.00	100.00	-8.26	4.69	-9.30	262.59	-46.48	2.74	1.077
5735.00	100.00	-8.05	4.62	-9.31	260.22	-38.92	2.76	1.077
5750.00	100.00	-7.82	4.54	-9.29	258.11	-31.23	2.78	1.077
5765.00	100.00	-7.57	4.46	-9.25	256.29	-23.40	2.79	1.077
5780.00	100.00	-7.31	4.38	-9.18	254.75	-15.45	2.81	1.077
5795.00	100.00	-7.04	4.29	-9.24	253.50	-7.36	2.82	1.077
5810.00	100.00	-6.76	4.19	-9.44	252.54	0.85	2.83	1.077
5825.00	100.00	-6.47	4.09	-9.63	251.90	9.18	2.84	1.077
5840.00	100.00	-6.17	3.97	-9.80	251.56	17.63	2.84	1.077
5855.00	100.00	-5.87	3.85	-9.94	251.55	26.19	2.85	1.077
5870.00	100.00	-5.57	3.72	-10.06	251.87	34.87	2.85	1.076
5885.00	100.00	-5.26	3.58	-10.14	252.54	43.65	2.84	1.076
5900.00	100.00	-4.95	3.44	-10.18	253.55	52.54	2.84	1.076
5915.00	100.00	-4.65	3.28	-10.18	254.93	61.52	2.83	1.076
5930.00	100.00	-4.34	3.12	-10.13	256.70	70.59	2.82	1.075
5945.00	100.00	-4.05	2.95	-10.03	258.85	79.75	2.80	1.075
5960.00	100.00	-3.75	2.77	-10.35	261.41	88.98	2.78	1.074
5975.00	100.00	-3.46	2.59	-10.78	264.40	98.28	2.76	1.074
5990.00	100.00	-3.18	2.39	-11.21	267.82	107.63	2.74	1.073
6005.00	100.00	-2.90	2.18	-11.63	271.70	117.03	2.71	1.073
6020.00	100.00	-2.63	1.96	-12.01	276.06	126.47	2.68	1.071
6035.00	100.00	-2.36	1.73	-12.34	280.91	135.92	2.65	1.071
6050.00	100.00	-2.11	1.49	-12.61	286.27	145.37	2.62	1.071
6065.00	100.00	-1.86	1.23	-12.80	292.17	154.81	2.58	1.070
6080.00	100.00	-1.62	0.96	-12.89	298.62	164.21	2.55	1.069
6095.00	100.00	-1.38	0.68	-12.88	305.65	173.56	2.51	1.068
6110.00	100.00	-1.13	0.38	-12.77	313.28	182.81	2.46	1.068
6125.00	100.00	-0.94	0.07	-12.57	321.52	191.94	2.42	1.067
6140.00	100.00	-0.73	-0.26	-13.12	330.42	200.93	2.38	1.066
6155.00	100.00	-0.53	-0.53	-14.01	339.98	209.73	2.33	1.065
6170.00	100.00	-0.34	-0.34	-14.96	350.22	218.30	2.28	1.065
6185.00	100.00	-0.15	-0.15	-15.93	361.17	226.60	2.24	1.064
6200.00	100.00	0.03	0.03	-16.89	372.84	234.58	2.19	1.063
6215.00	100.00	0.20	0.20	-17.77	385.26	242.17	2.14	1.062
6230.00	100.00	0.36	0.36	-18.46	398.42	249.33	2.09	1.062
6245.00	100.00	0.52	0.52	-18.83	412.35	255.99	2.04	1.061
6260.00	100.00	0.67	0.67	-18.81	427.05	262.07	2.00	1.060
6275.00	100.00	0.81	0.81	-18.41	442.50	267.50	1.95	1.060
6290.00	100.00	0.95	0.73	-17.72	458.72	272.19	1.90	1.059
6305.00	100.00	1.08	1.08	-16.91	475.68	276.05	1.85	1.058
6320.00	100.00	1.21	1.21	-18.31	493.35	279.04	1.81	1.058
6335.00	100.00	1.33	1.33	-20.33	511.71	281.00	1.76	1.057
6350.00	100.00	1.44	1.44	-22.89	530.70	281.87	1.72	1.057
6365.00	100.00	1.55	1.55	-26.39	550.26	281.53	1.67	1.056
6380.00	100.00	1.66	1.66	-31.63	570.32	279.90	1.63	1.056
6395.00	100.00	1.76	1.76	-38.87	590.80	276.88	1.59	1.056
6410.00	100.00	1.86	1.86	-30.21	611.58	272.37	1.55	1.055
6425.00	100.00	1.95	1.95	-25.67	632.54	266.30	1.51	1.055
6440.00	100.00	2.04	2.04	-22.62	653.54	258.59	1.47	1.055
6455.00	100.00	2.12	2.12	-22.00	674.45	249.19	1.44	1.054
6470.00	100.00	2.20	2.20	-24.60	695.07	238.05	1.40	1.054
6485.00	100.00	2.28	2.28	-27.33	715.25	225.44	1.37	1.054
6500.00	100.00	2.36	2.36	-28.60	734.78	210.48	1.34	1.054
6515.00	100.00	2.43	2.43	-27.00	753.47	194.07	1.31	1.054
6530.00	100.00	2.50	2.50	-24.41	771.13	175.98	1.28	1.054
6545.00	100.00	2.56	2.56	-27.44	787.56	156.29	1.26	1.054
6560.00	100.00	2.63	2.63	-32.20	802.57	135.11	1.24	1.054
6575.00	100.00	2.69	2.69	-34.59	815.98	112.57	1.22	1.054
6590.00	100.00	2.75	2.75	-31.42	827.65	88.83	1.20	1.054
6605.00	100.00	2.80	2.80	-26.26	837.44	64.09	1.20	1.054
6620.00	100.00	2.86	2.86	-22.83	845.23	38.55	1.19	1.054
6635.00	100.00	2.91	2.91	-20.36	850.95	12.43	1.19	1.054
6650.00	100.00	2.96	2.96	-16.46	854.56	-14.05	1.20	1.054
6665.00	100.00	3.01	3.01	-16.92	856.03	-40.66	1.21	1.054
6680.00	100.00	3.05	3.05	-15.63	855.39	-67.15	1.22	1.055
6695.00	100.00	3.10	3.10	-14.53	852.69	-93.33	1.24	1.055
6710.00	100.00	3.14	3.14	-13.56	848.00	-118.97	1.26	1.055
6725.00	100.00	3.19	3.19	-12.71	841.43	-143.89	1.28	1.056
6740.00	100.00	3.23	3.23	-11.94	833.10	-167.92	1.30	1.056
6755.00	100.00	3.27	3.27	-11.25	823.14	-190.92	1.33	1.056
6770.00	100.00	3.31	3.31	-10.62	811.72	-212.76	1.36	1.057
6785.00	100.00	3.34	3.34	-10.05	798.98	-233.34	1.39	1.057
6800.00	100.00	3.38	3.38	-9.55	785.10	-252.59	1.42	1.058
6815.00	100.00	3.42	3.42	-9.10	770.23	-270.47	1.45	1.058
6830.00	100.00	3.45	3.45	-8.69	754.53	-286.93	1.48	1.059
6845.00	100.00	3.48	3.48	-8.30	738.16	-301.97	1.51	1.059
6860.00	100.00	3.52	3.52	-7.93	721.25	-315.60	1.55	1.060
6875.00	100.00	3.55	3.55	-7.58	703.95	-327.84	1.58	1.061
6890.00	100.00	3.58	3.58	-7.25	686.38	-338.71	1.62	1.061
6905.00	100.00	3.61	3.61	-6.94	668.64	-348.27	1.65	1.062
6920.00	100.00	3.64	3.64	-6.64	650.84	-356.56	1.69	1.063
6935.00	100.00	3.66	3.66	-6.36	633.08	-363.63	1.73	1.063
6950.00	100.00	3.69	3.74	-6.09	615.42	-369.55	1.77	1.064
6965.00	100.00	3.72	3.85	-5.84	597.94	-374.38	1.81	1.065
6980.00	100.00	3.74	3.96	-5.59	580.68	-378.18	1.85	1.066
6995.00	100.00	3.77	4.07	-5.36	563.71	-381.01	1.89	1.067
7010.00	100.00	3.79	4.17	-5.13	547.07	-382.94	1.93	1.067
7025.00	100.00	3.81	4.28	-4.92	530.78	-384.01	1.97	1.068
7040.00	100.00	3.83	4.38	-4.71	514.87	-384.30	2.01	1.069
7055.00	100.00	3.85	4.48	-4.51	499.36	-383.86	2.06	1.070
7070.00	100.00	3.87	4.58	-4.32	484.28	-382.74	2.10	1.071
7085.00	100.00	3.89	4.67	-4.13	469.63	-380.99	2.15	1.072
7100.00	100.00	3.91	4.77	-3.95	455.42	-378.65	2.19	1.073
7115.00	100.00	3.93	4.86	-3.78	441.65	-375.77	2.24	1.075
7130.00	100.00	3.94	4.95	-3.61	428.33	-372.39	2.28	1.076
7145.00	100.00	3.95	5.04	-3.45	415.45	-368.55	2.33	1.077
7160.00	100.00	3.97	5.13	-3.30	403.02	-364.28	2.38	1.078
7175.00	100.00	3.98	5.21	-3.15	391.03	-359.61	2.43	1.079
7190.00	100.00	3.99	5.29	-3.00	379.48	-354.58	2.47	1.081
7205.00	100.00	3.99	5.37	-2.86	368.35	-349.20	2.52	1.082
7220.00	100.00	4.00	5.45	-2.73	357.66	-343.50	2.57	1.083
7235.00	100.00	4.00	5.52	-2.62	347.38	-337.52	2.62	1.085
7250.00	100.00	4.00	5.60	-2.51	337.51	-331.25	2.67	1.088
7265.00	100.00	4.00	5.67	-2.41	328.06	-324.73	2.72	1.088
7280.00	100.00	4.00	5.73	-2.32	319.00	-317.97	2.77	1.089
7295.00	100.00	3.99	5.80	-2.23	310.34	-310.99	2.82	1.091
7310.00	100.00	3.98	5.86	-2.14	302.06	-303.79	2.87	1.092
7325.00	100.00	3.97	5.92	-2.06	294.17	-296.39	2.92	1.094
7340.00	100.00	3.95	5.97	-1.98	286.66	-288.80	2.96	1.095
7355.00	100.00	3.93	6.03	-1.90	279.52	-281.03	3.01	1.097
7370.00	100.00	3.90	6.07	-1.83	272.76	-273.09	3.06	1.099
7385.00	100.00	3.87	6.12	-1.77	266.37	-264.98	3.10	1.100
7400.00	100.00	3.84	6.15	-1.71	260.34	-256.72	3.15	1.102
7415.00	100.00	3.79	6.19	-1.66	254.68	-248.31	3.19	1.104
7430.00	100.00	3.75	6.21	-1.61	249.39	-239.75	3.23	1.105
7445.00	100.00	3.69	6.24	-1.56	244.46	-231.05	3.27	1.107
7460.00	100.00	3.63	6.25	-1.53	239.91	-222.22	3.30	1.109
7475.00	100.00	3.56	6.26	-1.50	235.73	-213.26	3.33	1.110
7490.00	100.00	3.48	6.26	-1.47	231.92	-204.17	3.36	1.112
7505.00	100.00	3.40	6.26	-1.45	228.50	-194.97	3.39	1.114
7520.00	100.00	3.30	6.25	-1.44	225.46	-185.65	3.41	1.115
7535.00	100.00	3.20	6.23	-1.44	222.82	-176.22	3.42	1.116
7550.00	100.00	3.0						

7565.00	100.00	2.95	6.16	-1.50	218.77	-157.06	3.44	1.119
7580.00	100.00	2.81	6.11	-1.54	217.37	-147.35	3.44	1.120
7595.00	100.00	2.65	6.05	-1.60	216.41	-137.55	3.44	1.121
7610.00	100.00	2.49	5.98	-1.66	215.91	-127.69	3.43	1.122
7625.00	100.00	2.30	5.89	-1.73	215.87	-117.76	3.41	1.122
7640.00	100.00	2.10	5.80	-1.81	216.31	-107.79	3.39	1.123
7655.00	100.00	1.89	5.69	-1.90	217.24	-97.79	3.36	1.123
7670.00	100.00	1.65	5.57	-2.00	218.70	-87.77	3.32	1.124
7685.00	100.00	1.40	5.43	-2.10	220.68	-77.76	3.28	1.123
7700.00	100.00	1.13	5.29	-2.25	223.22	-67.78	3.23	1.123
7715.00	100.00	0.84	5.13	-2.42	226.33	-57.86	3.18	1.123
7730.00	100.00	0.53	4.95	-2.59	230.04	-48.02	3.12	1.122
7745.00	100.00	0.20	4.76	-2.77	234.35	-38.30	3.06	1.122
7760.00	100.00	-0.15	4.56	-2.96	239.28	-28.74	2.99	1.121
7775.00	100.00	-0.52	4.34	-3.15	244.86	-19.37	2.92	1.119
7790.00	100.00	-0.91	4.11	-3.40	251.10	-10.25	2.85	1.118
7805.00	100.00	-1.33	3.87	-3.67	258.00	-1.44	2.77	1.117
7820.00	100.00	-1.77	3.62	-3.94	265.57	7.03	2.69	1.115
7835.00	100.00	-2.23	3.35	-4.21	273.81	15.08	2.61	1.114
7850.00	100.00	-2.70	3.08	-4.48	282.73	22.64	2.53	1.112
7865.00	100.00	-3.20	2.80	-4.76	292.30	29.65	2.45	1.110
7880.00	100.00	-3.72	2.50	-5.13	302.51	36.04	2.37	1.108
7895.00	100.00	-4.26	2.21	-5.49	313.32	41.72	2.29	1.106
7910.00	100.00	-4.80	1.90	-5.83	324.71	46.61	2.21	1.104
7925.00	100.00	-5.36	1.60	-6.16	336.60	50.65	2.14	1.103
7940.00	100.00	-5.92	1.29	-6.50	348.95	53.76	2.06	1.101
7955.00	100.00	-6.47	0.99	-6.82	361.67	55.86	1.99	1.099
7970.00	100.00	-7.01	0.69	-7.10	374.67	56.90	1.92	1.097
7985.00	100.00	-7.53	0.39	-7.64	387.85	56.81	1.86	1.095
8000.00	100.00	-8.00	0.11	-8.04	401.10	55.56	1.80	1.093
8015.00	100.00	-8.41	-0.16	-8.41	414.29	53.11	1.74	1.092
8030.00	100.00	-8.76	-0.42	-8.76	427.28	49.47	1.69	1.090
8045.00	100.00	-9.02	-0.65	-9.02	439.96	44.62	1.64	1.088
8060.00	100.00	-9.18	-0.87	-9.18	452.16	38.61	1.59	1.087
8075.00	100.00	-9.26	-1.06	-9.26	463.78	31.48	1.55	1.085
8090.00	100.00	-9.23	-1.23	-9.23	474.66	23.29	1.51	1.084
8105.00	100.00	-9.13	-1.37	-9.13	484.69	14.15	1.48	1.083
8120.00	100.00	-8.96	-1.48	-8.96	493.78	4.14	1.45	1.082
8135.00	100.00	-8.73	-1.57	-8.73	501.82	-6.60	1.42	1.080
8150.00	100.00	-8.47	-1.62	-8.47	508.76	-17.96	1.41	1.079
8165.00	100.00	-8.18	-1.65	-8.18	514.54	-29.78	1.39	1.078
8180.00	100.00	-7.87	-1.65	-7.87	519.13	-41.92	1.39	1.077
8195.00	100.00	-7.55	-1.63	-7.55	522.53	-54.26	1.39	1.077
8210.00	100.00	-7.24	-1.59	-7.24	524.76	-66.64	1.39	1.076
8225.00	100.00	-6.92	-1.53	-6.92	525.83	-78.93	1.39	1.075
8240.00	100.00	-6.62	-1.45	-6.77	525.82	-91.03	1.41	1.075
8255.00	100.00	-6.32	-1.36	-6.80	524.76	-102.81	1.42	1.074
8270.00	100.00	-6.04	-1.25	-6.82	522.75	-114.19	1.44	1.073
8285.00	100.00	-5.76	-1.14	-6.84	519.85	-125.09	1.46	1.073
8300.00	100.00	-5.50	-1.02	-6.85	516.16	-135.44	1.48	1.073
8315.00	100.00	-5.25	-0.89	-6.86	511.77	-145.18	1.51	1.072
8330.00	100.00	-5.01	-0.75	-6.87	506.76	-154.29	1.53	1.072
8345.00	100.00	-4.79	-0.62	-6.87	501.22	-162.73	1.56	1.072
8360.00	100.00	-4.57	-0.48	-6.87	495.23	-170.50	1.59	1.072
8375.00	100.00	-4.37	-0.34	-6.86	488.88	-177.58	1.62	1.071
8390.00	100.00	-4.18	-0.20	-6.86	482.24	-183.99	1.65	1.071
8405.00	100.00	-4.00	-0.06	-6.86	475.37	-189.73	1.68	1.071
8420.00	100.00	-3.83	0.08	-6.85	468.35	-194.82	1.71	1.071
8435.00	100.00	-3.66	0.21	-6.85	461.23	-199.28	1.74	1.071
8450.00	100.00	-3.51	0.35	-6.84	454.06	-203.14	1.77	1.071
8465.00	100.00	-3.36	0.48	-6.84	446.88	-206.42	1.80	1.071
8480.00	100.00	-3.23	0.61	-6.84	439.74	-209.15	1.84	1.071
8495.00	100.00	-3.10	0.73	-6.84	432.67	-211.36	1.87	1.071
8510.00	100.00	-2.98	0.83	-6.84	425.70	-213.08	1.90	1.071
8525.00	100.00	-2.86	0.97	-6.84	418.86	-214.35	1.93	1.072
8540.00	100.00	-2.76	1.08	-6.84	412.17	-215.18	1.96	1.072
8555.00	100.00	-2.66	1.19	-6.84	405.64	-215.62	1.99	1.072
8570.00	100.00	-2.56	1.30	-6.85	399.29	-215.69	2.02	1.072
8585.00	100.00	-2.48	1.40	-6.86	393.14	-215.41	2.04	1.072
8600.00	100.00	-2.39	1.50	-6.87	387.20	-214.81	2.07	1.073
8615.00	100.00	-2.32	1.59	-6.89	381.46	-213.91	2.10	1.073
8630.00	100.00	-2.25	1.68	-6.90	375.95	-212.75	2.13	1.073
8645.00	100.00	-2.19	1.77	-6.92	370.66	-211.33	2.15	1.073
8660.00	100.00	-2.13	1.85	-6.94	365.59	-209.69	2.18	1.074
8675.00	100.00	-2.07	1.93	-6.96	360.76	-207.83	2.20	1.074
8690.00	100.00	-2.03	2.01	-6.99	356.16	-205.79	2.22	1.074
8705.00	100.00	-1.98	2.08	-7.01	351.78	-203.57	2.24	1.074
8720.00	100.00	-1.95	2.14	-7.04	347.65	-201.19	2.26	1.075
8735.00	100.00	-1.91	2.21	-7.07	343.74	-198.67	2.28	1.075
8750.00	100.00	-1.88	2.27	-7.10	340.06	-196.03	2.30	1.075
8765.00	100.00	-1.86	2.32	-7.14	336.61	-193.26	2.32	1.075
8780.00	100.00	-1.84	2.37	-7.17	333.39	-190.40	2.33	1.076
8795.00	100.00	-1.83	2.42	-7.21	330.40	-187.45	2.35	1.076
8810.00	100.00	-1.82	2.46	-7.25	327.63	-184.42	2.36	1.076
8825.00	100.00	-1.82	2.50	-7.29	325.08	-181.32	2.37	1.076
8840.00	100.00	-1.82	2.54	-7.33	322.76	-178.16	2.38	1.077
8855.00	100.00	-1.82	2.57	-7.37	320.65	-174.96	2.39	1.077
8870.00	100.00	-1.83	2.60	-7.41	318.76	-171.72	2.40	1.077
8885.00	100.00	-1.84	2.63	-7.45	317.08	-168.45	2.41	1.077
8900.00	100.00	-1.86	2.65	-7.49	315.62	-165.16	2.41	1.077
8915.00	100.00	-1.89	2.66	-7.54	314.37	-161.86	2.42	1.078
8930.00	100.00	-1.91	2.68	-7.63	313.33	-158.56	2.42	1.078
8945.00	100.00	-1.95	2.69	-7.73	312.50	-155.26	2.42	1.078
8960.00	100.00	-1.98	2.69	-7.83	311.87	-151.98	2.42	1.078
8975.00	100.00	-2.02	2.69	-7.93	311.45	-148.72	2.42	1.078
8990.00	100.00	-2.07	2.69	-8.04	311.23	-145.49	2.41	1.078
9005.00	100.00	-2.12	2.68	-8.15	311.21	-142.30	2.41	1.078
9020.00	100.00	-2.17	2.67	-8.27	311.39	-139.16	2.40	1.078
9035.00	100.00	-2.23	2.63	-8.39	311.77	-136.07	2.39	1.078
9050.00	100.00	-2.30	2.64	-8.51	312.34	-133.05	2.39	1.078
9065.00	100.00	-2.36	2.62	-8.63	313.11	-130.10	2.38	1.078
9080.00	100.00	-2.44	2.60	-8.76	314.07	-127.24	2.37	1.078
9095.00	100.00	-2.51	2.57	-8.89	315.22	-124.46	2.35	1.078
9110.00	100.00	-2.60	2.54	-9.01	316.55	-121.79	2.34	1.078
9125.00	100.00	-2.68	2.50	-9.14	318.06	-119.22	2.33	1.078
9140.00	100.00	-2.77	2.46	-9.27	319.76	-116.78	2.31	1.078
9155.00	100.00	-2.87	2.41	-9.40	321.63	-114.47	2.29	1.078
9170.00	100.00	-2.97	2.37	-9.52	323.68	-112.30	2.28	1.077
9185.00	100.00	-3.07	2.31	-9.65	325.88	-110.28	2.26	1.077
9200.00	100.00	-3.18	2.26	-9.77	328.26	-108.43	2.24	1.077
9215.00	100.00	-3.30	2.20	-9.88	330.78	-106.75	2.22	1.077
9230.00	100.00	-3.41	2.14	-9.99	333.46	-105.25	2.20	1.077
9245.00	100.00	-3.54	2.07	-10.10	336.27	-103.95	2.18	1.076
9260.00	100.00	-3.66	2.00	-10.19	339.22	-102.86	2.16	1.076
9275.00	100.00	-3.80	1.93	-10.28	342.29	-101.99	2.14	1.076
9290.00	100.00	-3.93	1.85	-10.37	345.47	-101.35	2.12	1.076
9305.00	100.00	-4.07	1.75	-10.44	348.76	-100.95	2.10	1.075
9320.00	100.00	-4.22	1.68	-10.50	352.12	-100.81	2.08	1.075
9335.00	100.00	-4.37	1.59	-10.55	355.57	-100.93	2.06	1.075
9350.00	100.00	-4.52	1.50	-10.59	359.07	-101.32	2.04	1.074
9365.00	100.00	-4.68	1.40	-10.76	362.61	-102.00	2.03	1.074
9380.00	100.00	-4.84	1.30	-11.05	366.17	-102.97	2.01	1.074
9395.00	100.00	-5.01	1.20	-11.35	369.74	-104.24	1.99	1.073
9410.00	100.00	-5.18	1.09	-11.66	373.29	-105.81	1.97	1.073
9425.00	100.00	-5.36	0.98	-11.98	376.80	-107.70	1.96	1.073
9440.00	100.00	-5.54	0.87	-12.31	380.25	-109.89	1.94	1.072
9455.00	100.00	-5.72	0.75	-12.65	383.62	-112.41	1.93	1.072
9470.00	100.00	-5.91	0.63	-13.00	386.87	-115.24	1.92	1.072
9485.00	100.00	-6.10	0.50	-13.36	389.99	-118.38	1.90	

9500.00	100.00	-6.29	0.38	-13.73	392.95	-121.83	1.89	1.071
9515.00	100.00	-6.49	0.24	-14.10	395.72	-125.58	1.89	1.071
9530.00	100.00	-6.59	0.11	-14.25	398.27	-129.61	1.88	1.070
9545.00	100.00	-6.90	-0.03	-14.87	400.59	-133.93	1.87	1.070
9560.00	100.00	-7.11	-0.17	-15.26	402.64	-138.51	1.87	1.070
9575.00	100.00	-7.31	-0.29	-15.66	404.40	-143.33	1.87	1.070
9590.00	100.00	-7.53	-0.18	-16.05	405.85	-148.37	1.87	1.069
9605.00	100.00	-7.74	-0.08	-16.43	406.96	-153.62	1.87	1.069
9620.00	100.00	-7.96	0.02	-16.80	407.73	-159.03	1.88	1.069
9635.00	100.00	-8.17	0.12	-17.16	408.12	-164.60	1.89	1.069
9650.00	100.00	-8.39	0.22	-17.50	408.14	-170.28	1.89	1.068
9665.00	100.00	-8.61	0.32	-17.80	407.76	-176.05	1.91	1.068
9680.00	100.00	-8.83	0.42	-18.07	406.98	-181.87	1.92	1.068
9695.00	100.00	-9.04	0.51	-18.30	405.79	-187.71	1.93	1.068
9710.00	100.00	-9.26	0.61	-18.47	404.20	-193.54	1.95	1.068
9725.00	100.00	-9.47	0.70	-18.59	402.20	-199.33	1.97	1.068
9740.00	100.00	-9.68	0.79	-18.65	399.81	-205.03	1.99	1.067
9755.00	100.00	-9.88	0.88	-18.65	397.02	-210.63	2.02	1.067
9770.00	100.00	-10.08	0.97	-18.59	393.85	-216.08	2.04	1.067
9785.00	100.00	-10.28	1.06	-18.47	390.32	-221.37	2.07	1.067
9800.00	100.00	-10.46	1.15	-18.31	386.44	-226.45	2.10	1.067
9815.00	100.00	-10.64	1.23	-18.11	382.24	-231.32	2.13	1.067
9830.00	100.00	-10.81	1.31	-17.87	377.73	-235.94	2.17	1.067
9845.00	100.00	-10.97	1.40	-18.35	372.93	-240.29	2.20	1.067
9860.00	100.00	-11.12	1.48	-19.04	367.88	-244.37	2.24	1.067
9875.00	100.00	-11.26	1.55	-19.77	362.60	-248.14	2.28	1.068
9890.00	100.00	-11.39	1.63	-20.52	357.10	-251.62	2.32	1.068
9905.00	100.00	-11.50	1.71	-21.28	351.43	-254.77	2.36	1.068
9920.00	100.00	-11.60	1.78	-22.04	345.60	-257.60	2.40	1.068
9935.00	100.00	-11.69	1.85	-22.76	339.65	-260.11	2.45	1.068
9950.00	100.00	-11.76	1.93	-23.39	333.59	-262.28	2.50	1.069
9965.00	100.00	-11.82	2.00	-23.88	327.45	-264.14	2.55	1.069
9980.00	100.00	-11.86	2.06	-24.17	321.25	-265.66	2.60	1.069
9995.00	100.00	-11.90	2.13	-24.22	315.02	-266.87	2.65	1.070
10010.00	100.00	-11.91	2.20	-24.01	308.78	-267.76	2.70	1.070
10025.00	100.00	-11.92	2.26	-23.59	302.54	-268.35	2.76	1.070
10040.00	100.00	-11.91	2.32	-23.01	296.32	-268.64	2.81	1.071
10055.00	100.00	-11.89	2.38	-22.34	290.15	-268.64	2.87	1.071
10070.00	100.00	-11.86	2.44	-21.62	284.03	-268.36	2.93	1.071
10085.00	100.00	-11.82	2.50	-20.88	277.98	-267.82	2.99	1.072
10100.00	100.00	-11.77	2.56	-20.16	272.01	-267.02	3.05	1.073
10115.00	100.00	-11.71	2.61	-19.46	266.13	-265.97	3.11	1.073
10130.00	100.00	-11.65	2.67	-18.79	260.36	-264.69	3.17	1.074
10145.00	100.00	-11.58	2.72	-18.15	254.70	-263.19	3.23	1.075
10160.00	100.00	-11.50	2.77	-17.54	249.15	-261.48	3.30	1.075
10175.00	100.00	-11.43	2.82	-16.96	243.73	-259.57	3.36	1.076
10190.00	100.00	-11.34	2.87	-16.62	238.44	-257.47	3.43	1.077
10205.00	100.00	-11.26	2.91	-16.59	233.28	-255.20	3.50	1.077
10220.00	100.00	-11.17	2.96	-16.51	228.26	-252.76	3.56	1.078
10235.00	100.00	-11.08	3.00	-16.55	223.38	-250.16	3.63	1.079
10250.00	100.00	-10.99	3.04	-17.01	218.64	-247.42	3.70	1.080
10265.00	100.00	-10.91	3.08	-17.46	214.04	-244.54	3.76	1.081
10280.00	100.00	-10.82	3.12	-17.90	209.59	-241.54	3.83	1.082
10295.00	100.00	-10.73	3.15	-18.32	205.29	-238.41	3.90	1.083
10310.00	100.00	-10.64	3.19	-18.70	201.14	-235.17	3.97	1.084
10325.00	100.00	-10.55	3.22	-19.04	197.12	-231.83	4.04	1.085
10340.00	100.00	-10.47	3.25	-19.33	193.26	-228.39	4.10	1.086
10355.00	100.00	-10.38	3.28	-20.03	189.54	-224.86	4.17	1.087
10370.00	100.00	-10.30	3.31	-20.86	185.96	-221.25	4.24	1.088
10385.00	100.00	-10.22	3.34	-21.72	182.53	-217.56	4.30	1.089
10400.00	100.00	-10.14	3.36	-22.61	179.24	-213.80	4.37	1.090
10415.00	100.00	-10.06	3.38	-23.49	176.09	-209.97	4.43	1.091
10430.00	100.00	-9.99	3.40	-24.34	173.08	-206.08	4.49	1.092
10445.00	100.00	-9.92	3.42	-25.10	170.21	-202.14	4.56	1.093
10460.00	100.00	-9.85	3.43	-25.68	167.47	-198.13	4.61	1.094
10475.00	100.00	-9.78	3.44	-26.02	164.87	-194.08	4.67	1.096
10490.00	100.00	-9.71	3.46	-26.08	162.40	-189.98	4.73	1.097
10505.00	100.00	-9.65	3.46	-25.84	160.07	-185.84	4.78	1.098
10520.00	100.00	-9.58	3.47	-25.38	157.87	-181.66	4.84	1.099
10535.00	100.00	-9.52	3.47	-24.77	155.79	-177.45	4.89	1.101
10550.00	100.00	-9.46	3.47	-24.09	153.85	-173.20	4.93	1.102
10565.00	100.00	-9.40	3.47	-23.38	152.03	-168.91	4.98	1.103
10580.00	100.00	-9.34	3.47	-22.68	150.35	-164.60	5.02	1.104
10595.00	100.00	-9.28	3.46	-22.00	148.78	-160.26	5.06	1.105
10610.00	100.00	-9.23	3.45	-21.37	147.35	-155.90	5.09	1.107
10625.00	100.00	-9.17	3.44	-20.77	146.04	-151.51	5.12	1.108
10640.00	100.00	-9.11	3.42	-20.21	144.85	-147.10	5.15	1.109
10655.00	100.00	-9.06	3.40	-19.69	143.79	-142.67	5.18	1.110
10670.00	100.00	-9.00	3.38	-19.21	142.85	-138.22	5.20	1.112
10685.00	100.00	-8.94	3.35	-18.77	142.04	-133.76	5.22	1.113
10700.00	100.00	-8.88	3.33	-18.36	141.36	-129.27	5.23	1.114
10715.00	100.00	-8.82	3.30	-17.97	140.79	-124.78	5.24	1.115
10730.00	100.00	-8.76	3.26	-17.62	140.36	-120.27	5.24	1.116
10745.00	100.00	-8.70	3.22	-17.29	140.05	-115.75	5.24	1.117
10760.00	100.00	-8.63	3.18	-16.98	139.87	-111.21	5.24	1.118
10775.00	100.00	-8.56	3.14	-16.70	139.82	-106.67	5.23	1.119
10790.00	100.00	-8.49	3.09	-16.44	139.89	-102.12	5.22	1.120
10805.00	100.00	-8.42	3.04	-16.20	140.10	-97.57	5.20	1.121
10820.00	100.00	-8.34	2.98	-15.98	140.44	-93.01	5.18	1.122
10835.00	100.00	-8.27	2.92	-15.77	140.92	-88.44	5.15	1.123
10850.00	100.00	-8.19	2.86	-15.59	141.54	-83.87	5.12	1.124
10865.00	100.00	-8.10	2.79	-15.41	142.29	-79.31	5.09	1.124
10880.00	100.00	-8.01	2.73	-15.25	143.19	-74.74	5.05	1.125
10895.00	100.00	-7.92	2.65	-15.11	144.24	-70.18	5.01	1.126
10910.00	100.00	-7.83	2.58	-14.97	145.43	-65.62	4.96	1.126
10925.00	100.00	-7.73	2.50	-14.85	146.77	-61.07	4.91	1.127
10940.00	100.00	-7.63	2.41	-14.75	148.27	-56.53	4.85	1.127
10955.00	100.00	-7.53	2.32	-14.65	149.94	-52.00	4.80	1.128
10970.00	100.00	-7.42	2.23	-14.56	151.76	-47.49	4.73	1.128
10985.00	100.00	-7.31	2.14	-14.48	153.75	-43.00	4.67	1.129
11000.00	100.00	-7.20	2.04	-14.41	155.92	-38.53	4.60	1.129
11015.00	100.00	-7.08	1.94	-14.35	158.26	-34.09	4.53	1.129
11030.00	100.00	-6.97	1.83	-14.30	160.79	-29.69	4.45	1.130
11045.00	100.00	-6.85	1.72	-14.26	163.51	-25.32	4.38	1.130
11060.00	100.00	-6.73	1.61	-14.22	166.42	-21.00	4.30	1.130
11075.00	100.00	-6.60	1.50	-14.19	169.54	-16.73	4.22	1.130
11090.00	100.00	-6.48	1.38	-14.17	172.86	-12.51	4.14	1.130
11105.00	100.00	-6.35	1.25	-14.15	176.40	-8.36	4.05	1.130
11120.00	100.00	-6.22	1.13	-14.13	180.16	-4.29	3.97	1.130
11135.00	100.00	-6.10	1.00	-14.13	184.14	-0.30	3.88	1.130
11150.00	100.00	-5.97	0.87	-14.12	188.36	3.59	3.80	1.130
11165.00	100.00	-5.84	0.73	-14.12	192.83	7.37	3.71	1.130
11180.00	100.00	-5.71	0.59	-14.12	197.54	11.03	3.62	1.130
11195.00	100.00	-5.57	0.45	-14.13	202.51	14.56	3.53	1.130
11210.00	100.00	-5.44	0.31	-14.14	207.74	17.92	3.44	1.129
11225.00	100.00	-5.31	0.16	-14.15	213.23	21.12	3.36	1.129
11240.00	100.00	-5.18	0.01	-14.16	219.00	24.13	3.27	1.129
11255.00	100.00	-5.05	-0.15	-14.18	225.06	26.92	3.18	1.129
11270.00	100.00	-4.92	-0.31	-14.19	231.39	29.47	3.10	1.128
11285.00	100.00	-4.79	-0.47	-14.21	238.01	31.76	3.01	1.128
11300.00	100.00	-4.66	-0.49	-14.22	244.91	33.76	2.93	1.128
11315.00	100.00	-4.53	-0.41	-14.24	252.10	35.44	2.84	1.128
11330.00	100.00	-4.40	-0.25	-14.25	259.58	36.76	2.76	1.127
11345.00	100.00	-4.27	-0.24	-14.26	267.33	37.69	2.68	1.127
11360.00	100.00	-4.14	-0.16	-14.28	275.34	38.19	2.61	1.127
11375.00	100.00	-4.02	-0.08	-14.29	283.61	38.22	2.53	1.127
11390.00	100.00	-3.8						

11435.00	100.00	-3.52	0.23	-14.30	318.77	32.79	2.25	1.126
11450.00	100.00	-3.40	0.30	-14.30	327.92	29.82	2.19	1.125
11465.00	100.00	-3.28	0.38	-14.30	337.12	26.11	2.12	1.125
11480.00	100.00	-3.16	0.45	-14.54	346.32	23.63	2.07	1.125
11495.00	100.00	-3.04	0.52	-14.60	355.43	16.34	2.01	1.125
11510.00	100.00	-2.92	0.60	-14.62	364.40	10.21	1.96	1.125
11525.00	100.00	-2.80	0.67	-14.60	373.12	3.21	1.92	1.125
11540.00	100.00	-2.68	0.74	-14.54	381.50	-4.68	1.87	1.125
11555.00	100.00	-2.57	0.81	-14.43	389.45	-13.45	1.84	1.125
11570.00	100.00	-2.45	0.88	-14.29	396.84	-23.09	1.80	1.125
11585.00	100.00	-2.34	0.95	-14.12	403.58	-33.58	1.78	1.125
11600.00	100.00	-2.23	1.02	-14.09	409.54	-44.87	1.76	1.125
11615.00	100.00	-2.12	1.09	-14.05	414.61	-56.91	1.74	1.125
11630.00	100.00	-2.01	1.15	-14.01	418.68	-69.60	1.73	1.125
11645.00	100.00	-1.90	1.22	-14.07	421.65	-82.85	1.73	1.125
11660.00	100.00	-1.79	1.28	-14.26	423.44	-96.53	1.74	1.125
11675.00	100.00	-1.68	1.35	-14.44	423.98	-110.52	1.75	1.126
11690.00	100.00	-1.57	1.41	-14.63	423.21	-124.67	1.77	1.126
11705.00	100.00	-1.47	1.48	-14.82	421.12	-138.81	1.79	1.126
11720.00	100.00	-1.36	1.54	-15.01	417.69	-152.79	1.83	1.127
11735.00	100.00	-1.26	1.60	-15.19	412.96	-166.45	1.87	1.127
11750.00	100.00	-1.16	1.66	-15.38	406.97	-179.62	1.91	1.128
11765.00	100.00	-1.06	1.72	-15.57	399.80	-192.17	1.97	1.129
11780.00	100.00	-0.96	1.78	-15.76	391.53	-203.96	2.03	1.129
11795.00	100.00	-0.86	1.83	-15.95	382.29	-214.88	2.10	1.130
11810.00	100.00	-0.76	1.89	-16.13	372.19	-224.84	2.17	1.131
11825.00	100.00	-0.67	1.94	-16.31	361.37	-233.76	2.25	1.132
11840.00	100.00	-0.57	1.99	-16.49	349.97	-241.60	2.34	1.133
11855.00	100.00	-0.48	2.04	-16.98	338.12	-248.33	2.43	1.134
11870.00	100.00	-0.39	2.09	-17.98	325.97	-253.94	2.53	1.135
11885.00	100.00	-0.30	2.13	-19.07	313.63	-258.46	2.64	1.136
11900.00	100.00	-0.21	2.18	-20.28	301.23	-261.90	2.75	1.137
11915.00	100.00	-0.13	2.22	-21.60	288.88	-264.31	2.87	1.138
11930.00	100.00	-0.05	2.25	-22.98	276.66	-265.74	2.99	1.140
11945.00	100.00	0.03	2.29	-24.32	264.67	-266.25	3.13	1.141
11960.00	100.00	0.11	2.32	-25.35	252.98	-265.91	3.26	1.143
11975.00	100.00	0.18	2.35	-25.67	241.63	-264.78	3.41	1.144
11990.00	100.00	0.25	2.37	-25.15	230.69	-262.94	3.56	1.146
12005.00	100.00	0.32	2.39	-24.02	220.17	-260.45	3.72	1.148
12020.00	100.00	0.38	2.40	-22.65	210.12	-257.38	3.88	1.150
12035.00	100.00	0.44	2.41	-21.27	200.55	-253.79	4.05	1.151
12050.00	100.00	0.49	2.41	-19.98	191.47	-249.75	4.22	1.153
12065.00	100.00	0.54	2.41	-18.81	182.88	-245.31	4.40	1.155
12080.00	100.00	0.59	2.40	-18.45	174.79	-240.53	4.58	1.157
12095.00	100.00	0.62	2.38	-18.48	167.18	-235.45	4.76	1.159
12110.00	100.00	0.66	2.38	-18.51	160.06	-230.13	4.95	1.161
12125.00	100.00	0.68	2.37	-18.52	153.41	-224.59	5.14	1.163
12140.00	100.00	0.70	2.35	-18.53	147.22	-218.88	5.33	1.165
12155.00	100.00	0.71	2.32	-18.52	141.48	-213.03	5.52	1.166
12170.00	100.00	0.72	2.28	-18.50	136.16	-207.07	5.71	1.168
12185.00	100.00	0.72	2.24	-18.47	131.26	-201.03	5.89	1.170
12200.00	100.00	0.70	2.24	-18.44	126.76	-194.92	6.07	1.171
12215.00	100.00	0.68	2.11	-18.39	122.65	-188.78	6.25	1.173
12230.00	100.00	0.65	2.03	-18.34	118.90	-182.61	6.42	1.174
12245.00	100.00	0.62	1.94	-18.28	115.50	-176.44	6.58	1.176
12260.00	100.00	0.57	1.84	-18.21	112.45	-170.28	6.73	1.177
12275.00	100.00	0.51	1.74	-18.13	109.72	-164.14	6.87	1.178
12290.00	100.00	0.44	1.60	-18.05	107.29	-158.04	7.00	1.178
12305.00	100.00	0.37	1.46	-17.97	105.17	-151.97	7.11	1.179
12320.00	100.00	0.28	1.30	-17.88	103.33	-145.96	7.21	1.179
12335.00	100.00	0.18	1.13	-17.78	101.76	-140.01	7.30	1.179
12350.00	100.00	0.07	0.95	-17.69	100.45	-134.12	7.37	1.179
12365.00	100.00	-0.05	0.75	-17.58	99.40	-128.31	7.43	1.179
12380.00	100.00	-0.17	0.54	-17.48	98.58	-122.58	7.47	1.179
12395.00	100.00	-0.31	0.32	-17.37	98.00	-116.93	7.49	1.178
12410.00	100.00	-0.46	0.08	-17.26	97.64	-111.36	7.50	1.177
12425.00	100.00	-0.61	-0.18	-17.15	97.50	-105.89	7.50	1.176
12440.00	100.00	-0.78	-0.44	-17.03	97.56	-100.52	7.48	1.175
12455.00	100.00	-0.95	-0.71	-16.91	97.83	-95.25	7.44	1.174
12470.00	100.00	-1.14	-1.03	-16.79	98.28	-90.07	7.39	1.172
12485.00	100.00	-1.32	-1.32	-16.80	98.92	-85.01	7.33	1.170
12500.00	100.00	-1.52	-1.52	-16.89	99.75	-80.06	7.26	1.169
12515.00	100.00	-1.72	-1.72	-16.96	100.75	-75.22	7.18	1.167
12530.00	100.00	-1.93	-1.93	-16.99	101.91	-70.50	7.09	1.165
12545.00	100.00	-2.15	-2.15	-16.99	103.24	-65.90	6.99	1.163
12560.00	100.00	-2.37	-2.37	-16.96	104.73	-61.43	6.88	1.161
12575.00	100.00	-2.59	-2.59	-16.90	106.38	-57.09	6.77	1.159
12590.00	100.00	-2.82	-2.82	-17.05	108.17	-52.88	6.65	1.157
12605.00	100.00	-3.05	-3.05	-17.48	110.10	-48.81	6.52	1.154
12620.00	100.00	-3.28	-3.28	-17.84	112.17	-44.88	6.40	1.152
12635.00	100.00	-3.51	-3.51	-18.09	114.38	-41.10	6.27	1.150
12650.00	100.00	-3.75	-3.75	-18.24	116.71	-37.47	6.14	1.148
12665.00	100.00	-3.98	-3.98	-18.28	119.17	-33.99	6.01	1.146
12680.00	100.00	-4.22	-4.22	-19.38	121.74	-30.68	5.88	1.144
12695.00	100.00	-4.45	-4.45	-20.58	124.42	-27.53	5.76	1.142
12710.00	100.00	-4.68	-4.68	-21.66	127.20	-24.56	5.63	1.140
12725.00	100.00	-4.91	-4.91	-22.47	130.08	-21.76	5.50	1.138
12740.00	100.00	-5.14	-5.14	-22.82	133.05	-19.14	5.38	1.136
12755.00	100.00	-5.36	-5.36	-22.63	136.11	-16.71	5.26	1.134
12770.00	100.00	-5.58	-5.53	-24.84	139.23	-14.48	5.14	1.132
12785.00	100.00	-5.80	-5.69	-29.11	142.42	-12.43	5.02	1.130
12800.00	100.00	-6.00	-5.84	-36.48	145.66	-10.60	4.91	1.128
12815.00	100.00	-6.21	-6.01	-37.21	148.95	-8.97	4.80	1.127
12830.00	100.00	-6.40	-6.18	-29.80	152.27	-7.54	4.70	1.125
12845.00	100.00	-6.59	-6.35	-25.65	155.62	-6.34	4.60	1.124
12860.00	100.00	-6.77	-6.53	-22.89	158.97	-5.35	4.50	1.122
12875.00	100.00	-6.94	-6.71	-20.84	162.32	-4.58	4.41	1.121
12890.00	100.00	-7.11	-6.90	-19.22	165.65	-4.03	4.32	1.119
12905.00	100.00	-7.26	-7.10	-17.89	168.95	-3.71	4.23	1.118
12920.00	100.00	-7.40	-7.30	-16.78	172.20	-3.60	4.15	1.117
12935.00	100.00	-7.54	-7.49	-16.03	175.40	-3.72	4.08	1.116
12950.00	100.00	-7.66	-7.66	-15.28	178.51	-4.05	4.01	1.114
12965.00	100.00	-7.78	-7.78	-14.56	181.54	-4.60	3.94	1.113
12980.00	100.00	-7.88	-7.88	-13.88	184.45	-5.35	3.88	1.112
12995.00	100.00	-7.97	-7.97	-13.24	187.24	-6.30	3.82	1.111
13010.00	100.00	-8.06	-8.06	-12.65	189.90	-7.45	3.77	1.110
13025.00	100.00	-8.13	-8.13	-12.09	192.40	-8.78	3.72	1.109
13040.00	100.00	-8.20	-8.20	-11.58	194.73	-10.27	3.67	1.109
13055.00	100.00	-8.25	-8.25	-11.35	196.88	-11.93	3.63	1.108
13070.00	100.00	-8.30	-8.30	-11.21	198.84	-13.73	3.60	1.107
13085.00	100.00	-8.33	-8.33	-11.06	200.59	-15.65	3.57	1.106
13100.00	100.00	-8.36	-8.36	-10.92	202.13	-17.68	3.54	1.106
13115.00	100.00	-8.39	-8.32	-10.77	203.44	-19.81	3.52	1.105
13130.00	100.00	-8.40	-8.17	-10.92	204.53	-22.01	3.50	1.105
13145.00	100.00	-8.41	-7.99	-11.25	205.38	-24.26	3.49	1.104
13160.00	100.00	-8.41	-7.81	-11.61	206.00	-26.55	3.48	1.104
13175.00	100.00	-8.41	-7.64	-11.98	206.38	-28.85	3.47	1.103
13190.00	100.00	-8.40	-7.46	-12.37	206.53	-31.14	3.47	1.103
13205.00	100.00	-8.39	-7.29	-12.77	206.44	-33.41	3.47	1.102
13220.00	100.00	-8.37	-7.13	-13.20	206.13	-35.63	3.48	1.102
13235.00	100.00	-8.35	-6.92	-13.65	205.60	-37.78	3.49	1.102
13250.00	100.00	-8.33	-6.71	-14.13	204.86	-39.86	3.50	1.101
13265.00	100.00	-8.31	-6.51	-14.63	203.81	-41.83	3.52	1.101
13280.00	100.00	-8.28	-6.32	-15.17	202.78	-43.70	3.54	1.101
13295.00	100.00	-8.25	-6.15	-15.74	201.47	-45.43	3.56	1.101
13310.00	100.00	-8.22	-5.98	-16.34	200.00	-47.03	3.59	1.100
13325.00	100.00	-8.20	-5.82	-16.98	198.39	-48.48	3.62	1.100



13370.00	100.00	-8.11	-5.38	-19.12	192.82	-51.84	3.73	1.100
13385.00	100.00	-8.08	-5.25	-19.90	190.77	-52.62	3.77	1.100
13400.00	100.00	-8.05	-5.13	-20.69	188.72	-53.22	3.81	1.100
13415.00	100.00	-8.03	-5.02	-21.45	186.48	-53.64	3.86	1.100
13430.00	100.00	-8.01	-4.91	-22.15	184.28	-53.88	3.90	1.099
13445.00	100.00	-7.99	-4.82	-22.70	182.04	-53.95	3.95	1.099
13460.00	100.00	-7.97	-4.72	-23.02	179.80	-53.84	4.00	1.099
13475.00	100.00	-7.95	-4.64	-23.07	177.56	-53.56	4.05	1.099
13490.00	100.00	-7.94	-4.56	-22.81	175.34	-53.12	4.10	1.099
13505.00	100.00	-7.93	-4.49	-22.42	173.14	-52.52	4.15	1.099
13520.00	100.00	-7.92	-4.43	-23.63	170.98	-51.76	4.20	1.099
13535.00	100.00	-7.91	-4.37	-25.03	168.87	-50.85	4.26	1.099
13550.00	100.00	-7.91	-4.32	-26.72	166.81	-49.80	4.31	1.099
13565.00	100.00	-7.91	-4.27	-28.80	164.81	-48.62	4.36	1.098
13580.00	100.00	-7.92	-4.23	-31.51	162.88	-47.31	4.41	1.098
13595.00	100.00	-7.93	-4.20	-35.33	161.04	-45.88	4.46	1.098
13610.00	100.00	-7.94	-4.17	-40.92	159.27	-44.34	4.51	1.098
13625.00	100.00	-7.96	-4.15	-41.57	157.59	-42.70	4.55	1.098
13640.00	100.00	-7.99	-4.14	-35.87	156.00	-40.96	4.60	1.097
13655.00	100.00	-8.01	-4.13	-31.89	154.50	-39.13	4.64	1.097
13670.00	100.00	-8.04	-4.13	-29.10	153.11	-37.21	4.68	1.097
13685.00	100.00	-8.08	-4.13	-26.97	151.81	-35.23	4.72	1.097
13700.00	100.00	-8.12	-4.14	-25.26	150.62	-33.17	4.76	1.096
13715.00	100.00	-8.16	-4.16	-23.84	149.53	-31.06	4.79	1.096
13730.00	100.00	-8.21	-4.18	-22.63	148.55	-28.89	4.82	1.095
13745.00	100.00	-8.27	-4.20	-21.57	147.68	-26.68	4.85	1.095
13760.00	100.00	-8.32	-4.23	-20.64	146.91	-24.42	4.87	1.095
13775.00	100.00	-8.39	-4.22	-19.80	146.25	-22.13	4.89	1.094
13790.00	100.00	-8.45	-4.17	-19.05	145.70	-19.81	4.91	1.094
13805.00	100.00	-8.53	-4.12	-18.37	145.25	-17.47	4.93	1.093
13820.00	100.00	-8.60	-4.08	-17.74	144.91	-15.11	4.94	1.092
13835.00	100.00	-8.68	-4.04	-17.17	144.68	-12.73	4.94	1.092
13850.00	100.00	-8.77	-4.00	-16.64	144.56	-10.35	4.95	1.091
13865.00	100.00	-8.86	-3.95	-16.30	144.54	-7.97	4.95	1.090
13880.00	100.00	-8.95	-3.90	-16.55	144.62	-5.59	4.94	1.090
13895.00	100.00	-9.05	-3.85	-16.80	144.81	-3.22	4.94	1.089
13910.00	100.00	-9.16	-3.81	-17.05	145.09	-0.86	4.93	1.088
13925.00	100.00	-9.26	-3.77	-17.29	145.48	1.49	4.91	1.087
13940.00	100.00	-9.37	-3.73	-17.53	145.97	3.82	4.90	1.087
13955.00	100.00	-9.49	-3.67	-17.77	146.56	6.12	4.88	1.086
13970.00	100.00	-9.61	-3.62	-18.00	147.24	8.39	4.86	1.085
13985.00	100.00	-9.73	-3.57	-18.21	148.02	10.63	4.83	1.084
14000.00	100.00	-9.85	-3.52	-18.42	148.89	12.83	4.80	1.083
14015.00	100.00	-9.98	-3.48	-18.61	149.86	15.00	4.77	1.082
14030.00	100.00	-10.11	-3.44	-18.79	150.91	17.12	4.74	1.082
14045.00	100.00	-10.24	-3.39	-18.95	152.05	19.19	4.71	1.081
14060.00	100.00	-10.38	-3.36	-19.10	153.28	21.21	4.67	1.080
14075.00	100.00	-10.52	-3.32	-19.22	154.60	23.17	4.63	1.079
14090.00	100.00	-10.66	-3.28	-19.33	155.99	25.08	4.59	1.078
14105.00	100.00	-10.80	-3.25	-19.41	157.47	26.93	4.55	1.077
14120.00	100.00	-10.94	-3.22	-19.46	159.02	28.71	4.50	1.076
14135.00	100.00	-11.09	-3.19	-19.50	160.66	30.42	4.46	1.075
14150.00	100.00	-11.23	-3.16	-19.51	162.36	32.05	4.41	1.074
14165.00	100.00	-11.37	-3.12	-19.50	164.14	33.61	4.37	1.073
14180.00	100.00	-11.52	-3.07	-19.47	165.99	35.09	4.32	1.072
14195.00	100.00	-11.66	-3.03	-19.42	167.90	36.48	4.27	1.072
14210.00	100.00	-11.80	-2.98	-19.35	169.87	37.79	4.22	1.071
14225.00	100.00	-11.94	-2.94	-19.26	171.91	39.01	4.17	1.070
14240.00	100.00	-12.07	-2.90	-19.15	174.00	40.13	4.12	1.069
14255.00	100.00	-12.20	-2.86	-19.03	176.15	41.15	4.07	1.068
14270.00	100.00	-12.33	-2.82	-18.90	178.34	42.07	4.02	1.067
14285.00	100.00	-12.45	-2.78	-18.75	180.58	42.89	3.97	1.066
14300.00	100.00	-12.56	-2.75	-18.59	182.86	43.59	3.93	1.065
14315.00	100.00	-12.67	-2.71	-18.48	185.19	44.18	3.88	1.064
14330.00	100.00	-12.77	-2.68	-18.87	187.54	44.66	3.83	1.063
14345.00	100.00	-12.86	-2.64	-19.27	189.92	45.02	3.78	1.063
14360.00	100.00	-12.94	-2.61	-19.68	192.32	45.26	3.73	1.062
14375.00	100.00	-13.01	-2.57	-20.09	194.75	45.36	3.69	1.061
14390.00	100.00	-13.06	-2.54	-20.50	197.18	45.35	3.64	1.060
14405.00	100.00	-13.11	-2.51	-20.91	199.62	45.20	3.60	1.059
14420.00	100.00	-13.14	-2.48	-21.31	202.06	44.91	3.55	1.059
14435.00	100.00	-13.16	-2.45	-21.70	204.49	44.49	3.51	1.058
14450.00	100.00	-13.16	-2.42	-22.05	206.90	43.94	3.47	1.057
14465.00	100.00	-13.15	-2.38	-22.37	209.29	43.24	3.43	1.056
14480.00	100.00	-13.13	-2.35	-22.63	211.66	42.40	3.39	1.056
14495.00	100.00	-13.09	-2.32	-22.83	213.98	41.42	3.35	1.055
14510.00	100.00	-13.03	-2.30	-22.96	216.26	40.30	3.32	1.054
14525.00	100.00	-12.96	-2.27	-22.99	218.49	39.03	3.28	1.053
14540.00	100.00	-12.87	-2.24	-22.94	220.65	37.63	3.25	1.053
14555.00	100.00	-12.77	-2.21	-22.79	222.74	36.08	3.22	1.052
14570.00	100.00	-12.66	-2.18	-22.57	224.75	34.39	3.19	1.051
14585.00	100.00	-12.53	-2.14	-22.26	226.66	32.57	3.16	1.051
14600.00	100.00	-12.39	-2.08	-21.90	228.48	30.61	3.14	1.050
14615.00	100.00	-12.24	-2.03	-21.49	230.18	28.52	3.11	1.049
14630.00	100.00	-12.08	-1.98	-21.05	231.77	26.31	3.09	1.049
14645.00	100.00	-11.91	-1.93	-20.58	233.22	23.97	3.07	1.048
14660.00	100.00	-11.72	-1.88	-20.09	234.54	21.52	3.05	1.048
14675.00	100.00	-11.53	-1.83	-19.60	235.70	18.96	3.04	1.047
14690.00	100.00	-11.34	-1.77	-19.11	236.71	16.30	3.02	1.046
14705.00	100.00	-11.13	-1.72	-18.62	237.55	13.55	3.01	1.046
14720.00	100.00	-10.92	-1.67	-18.14	238.22	10.72	3.00	1.045
14735.00	100.00	-10.71	-1.62	-17.66	238.71	7.81	3.00	1.045
14750.00	100.00	-10.49	-1.57	-17.19	239.00	4.84	2.99	1.044
14765.00	100.00	-10.27	-1.52	-16.73	239.10	1.83	2.99	1.044
14780.00	100.00	-10.04	-1.47	-16.28	239.00	-1.23	2.99	1.044
14795.00	100.00	-9.81	-1.41	-15.84	238.70	-4.31	3.00	1.043
14810.00	100.00	-9.58	-1.36	-15.41	238.18	-7.40	3.00	1.043
14825.00	100.00	-9.35	-1.31	-14.99	237.46	-10.49	3.01	1.042
14840.00	100.00	-9.11	-1.26	-14.58	236.52	-13.56	3.02	1.042
14855.00	100.00	-8.87	-1.21	-14.18	235.36	-16.60	3.04	1.042
14870.00	100.00	-8.64	-1.16	-13.79	234.00	-19.59	3.06	1.041
14885.00	100.00	-8.40	-1.11	-13.41	232.42	-22.52	3.08	1.041
14900.00	100.00	-8.16	-1.06	-13.04	230.63	-25.38	3.10	1.041
14915.00	100.00	-7.92	-1.01	-12.67	228.64	-28.14	3.13	1.040
14930.00	100.00	-7.69	-0.96	-12.31	226.46	-30.80	3.16	1.040
14945.00	100.00	-7.45	-0.91	-11.96	224.08	-33.34	3.20	1.040
14960.00	100.00	-7.21	-0.86	-11.62	221.52	-35.75	3.24	1.040
14975.00	100.00	-6.97	-0.81	-11.28	218.78	-38.01	3.28	1.040
14990.00	100.00	-6.74	-0.76	-10.95	215.89	-40.12	3.32	1.040
15005.00	100.00	-6.50	-0.71	-10.65	212.84	-42.06	3.37	1.040
15020.00	100.00	-6.27	-0.67	-10.34	209.65	-43.83	3.42	1.040
15035.00	100.00	-6.04	-0.62	-10.03	206.33	-45.41	3.48	1.040
15050.00	100.00	-5.81	-0.57	-9.72	202.90	-46.79	3.54	1.040
15065.00	100.00	-5.58	-0.53	-9.40	199.36	-47.98	3.60	1.040
15080.00	100.00	-5.35	-0.48	-9.08	195.74	-48.96	3.67	1.040
15095.00	100.00	-5.13	-0.44	-8.77	192.04	-49.74	3.74	1.040
15110.00	100.00	-4.90	-0.40	-8.45	188.29	-50.30	3.82	1.040
15125.00	100.00	-4.68	-0.36	-8.13	184.49	-50.65	3.90	1.040
15140.00	100.00	-4.46	-0.32	-7.82	180.66	-50.78	3.98	1.041
15155.00	100.00	-4.24	-0.28	-7.50	176.81	-50.70	4.07	1.041
15170.00	100.00	-4.03	-0.24	-7.18	172.96	-50.41	4.16	1.041
15185.00	100.00	-3.81	-0.21	-6.86	169.12	-49.91	4.25	1.042
15200.00	100.00	-3.60	-0.17	-6.54	165.30	-49.20	4.35	1.042

\*\*IMPORTANT NOTE: AVG PWR GAIN \_MUST\_ BE IN THE RANGE 0.8-1.2 FOR A VALID NEC MODEL (IDEALLY = 1)!  
VALUES OUTSIDE THIS RANGE INDICATE A FLAWED MODEL, USUALLY A RESULT OF INCORRECT SEGMENTATION.  
SEE DISCUSSION, p.101, NEC 4.1 USER'S MANUAL, LLNL UCRL-MA-109338 Pt. I (Gerald J. Burke), 1992.